

# Digital Audio and Compact Disc Technology

**Second edition**

**Edited by Luc Baert, Luc  
Theunissen and Guido  
Vergult, Sony Service  
Centre (*Europe*)**

**BH** NEWNES

Newnes  
An imprint of Butterworth-Heinemann Ltd  
Linacre House, Jordan Hill, Oxford OX2 8DP



PART OF REED INTERNATIONAL BOOKS

OXFORD LONDON BOSTON  
MUNICH NEW DELHI SINGAPORE SYDNEY  
TOKYO TORONTO WELLINGTON

First published 1988  
Second edition 1992

© Sony Service Centre (Europe) NV 1988, 1992

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means and whether or not transiently or incidentally to some other use of this publication) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988 or under the terms of a licence issued by the Copyright Licensing Agency Ltd, 90 Tottenham Court Road, London, England W1P 9HE. Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to the publishers

**British Library Cataloguing in Publication Data**  
Digital Audio and Compact Disc  
Technology. – 2Rev. ed  
I. Baert, Luc  
621.38932

ISBN 0 7506 0614 2

Printed and bound in Great Britain by  
Thomson Litho Ltd, East Kilbride, Scotland

# Preface

The past century has witnessed a number of inventions and developments which have made music regularly accessible to more people than ever before. Not the least of these were the inventions of the conventional analog phonograph and the development of broadcast radio. Both have undergone successive changes or improvements, from the 78 rpm disc to the 33 $\frac{1}{3}$  rpm disc, and from the AM system to the FM stereo system. These improvements resulted from demands for better and better quality.

Now, another change has taken place which will enable us to achieve the highest possible audio fidelity yet – the introduction of digital technology, specifically pulse code modulation (PCM). Research and development efforts, concentrated on consumer products, have begun to make the extraordinary advantages of digital audio systems easily accessible at home. Sony is proud to have been one of the forerunners in this field, and co-inventor of the compact disc digital audio system, which will lead to an entirely new level of quality music.

Sony Service Centre (Europe) NV

# A Short History of Audio Technology

## **Early Years: From Phonograph to Stereo Recording**

The evolution of recording and reproduction of audio signals started in 1877, with the invention of the phonograph by T. A. Edison. Since then, research and efforts to improve techniques have been determined by the ultimate aim of recording and reproducing an audio signal faithfully, i.e., without introducing distortion or noise of any form.

With the introduction of the gramophone, a disc phonograph, in 1893 by P. Berliner, the original form of our present record was born. This model could produce a much better sound and could also be reproduced easily.


Around 1925 electric recording was started, but an acoustic method was still mainly used in the sound reproduction system: where the sound was generated by a membrane and a horn, mechanically coupled to the needle in the groove in playback. When recording, the sound picked up was transformed through a horn and membrane into a vibration and coupled directly to a needle which cut the groove onto the disc.

Figure 1 shows Edison's original phonograph, patented in 1877, which consisted of a piece of tin foil wrapped around a rotating cylinder.


Vibration of his voice spoken into a recording horn (as shown) caused the stylus to cut grooves into a tin foil. The first sound recording made was Edison reciting 'Mary Had a Little Lamb' (Edison National History Site).

Figure 2 shows the Berliner gramophone, manufactured by US Gramophone Company, Washington, DC. It was hand-powered and required an operator to crank the handle up to a speed of 70 revolutions per minute (rpm) to get a satisfactory playback (Smithsonian Institution).

## 2 A Short History of Audio Technology



**Figure 1** *Edison's phonograph*



**Figure 2** *Berliner gramophone*

Further developments such as the electric crystal pick-up and, in the 1930s, broadcast AM radio stations made the SP (standard playing 78 rpm record) popular. Popularity increased with the development, in 1948 by CBS, of the  $33\frac{1}{3}$  rpm long-playing record (LP), with about 25 minutes of playing time on each side. Shortly after this, the EP (extended play) 45 rpm record was introduced by RCA with an improvement in record sound quality. At the same time, the lightweight pick-up cartridge, with only a few grams of stylus pressure, was developed by companies like General Electric and Pickering.

The true start of progress towards the ultimate aim of faithful recording and reproduction of audio signals was the introduction of stereo records in 1956. This began a race between manufacturers to produce a stereo reproduction tape recorder, originally for industrial master use. However, the race led to a simplification of techniques which, in turn, led to development of equipment for domestic use.

Broadcast radio began its move from AM to FM, with consequent improvement of sound quality, and in the early 1960s stereo FM broadcasting became a reality. In the same period the compact cassette recorder which would eventually conquer the world was developed by Philips.

## Developments in Analog Reproduction Techniques

The three basic media available in the early 1960s: tape, record and FM broadcast, were all analog media. Developments since then include:

### Developments in turntables

There has been remarkable progress since the stereo record appeared. Cartridges, which operate with stylus pressure of as little as 1 gram were developed and tonearms which could trace the sound groove perfectly with this one gram pressure were also made. The hysteresis synchronous motor and DC servo motor were developed for quieter, regular rotation and elimination of rumble. High-quality heavyweight model turntables, various turntable platters, and insulators were developed to prevent unwanted vibrations from reaching the stylus. With the introduction of electronic technology, full automation was performed. The direct drive system with the electronically controlled servo motor, the BSL motor (brushless and slotless linear motor) and the quartz locked DC servo motor were finally adopted together with the linear tracking arm and electronically controlled tonearms (biotracer). So, enormous progress was achieved since the beginning of the gramophone: in the acoustic recording period, disc capacity was 2 minutes on each side at 78 rpm, and the frequency range was 200 Hz–3 kHz with a dynamic range of



**Photo 1** *PS-X75 analog record player*

## 4 A Short History of Audio Technology

18 dB. At its latest stage of development, the LP record frequency range is 30 Hz–15 kHz, with a dynamic range of 65 dB in stereo.

### Developments in tape recorders

In the 1960s and 1970s, the open reel tape recorder was the instrument used both for record production and for broadcast so efforts were constantly made to improve the performance and quality of the signal. Particular attention was paid to the recording and reproduction heads, recording tape as well as




**Photo 2** *TC-766-2 analog domestic reel-to-reel tape recorder*

tape path drive mechanism with, ultimately, a wow and flutter of only 0.02% wrms at 38 cm/s, and of 0.04% wrms at 19 cm/s. Also the introduction of compression/expansion systems such as Dolby, dBx, etc. improved the available signal-to-noise ratios.

Professional open reel tape recorders were too bulky and too expensive for general consumer use, however, but since its invention in 1963 the compact cassette recorder began to make it possible for millions of people to enjoy recording and playing back music with reasonable tone quality and easy operation. The impact of the compact cassette was enormous and tape recorders for recording and playing back these cassettes became quite indispensable for music lovers, and for those who use the cassette recorders for a myriad of purposes such as taking notes for study, recording speeches, dictation, for 'talking letters' and for hundreds of other applications.

Inevitably, the same improvements used in open reel tape recorders eventually found their way into compact cassette recorders.



**Photo 3** Audio tapes, elcasetts, compact cassettes and microcassettes



## 6 A Short History of Audio Technology

### Limitations of Analog Audio Recording

Despite the spectacular evolution of techniques and the improvements in equipment, by the end of the 1970s the industry had almost reached the level above which few further improvements could be performed without increasing dramatically the price of the equipment. This was because quality, dynamic range, distortion (in its broadest sense) are all determined by the characteristics of the medium used (record, tape, broadcast) and by the processing equipment. Analog reproduction techniques had just about reached the limits of their characteristics.

Figure 3 represents a standard analog audio chain, from recording to reproduction, showing dynamic ranges in the three media: tape, record, broadcast.

Lower limit of dynamic range is determined by system noise and especially the lower frequency component of the noise. Distortion by system non-linearity generally sets the upper limit of dynamic range.

The strength and extent of a pick-up signal from a microphone is determined by the combination of the microphone sensitivity and the quality of the microphone pre-amplifier, but it is possible to maintain a dynamic range in excess of 90 dB by setting the levels carefully. However, the major problems




Figure 3 Typical analog audio systems, showing dynamic range

in microphone sound pick-up are the various types of distortion inherent in the recording studio, which cause a narrowing of the dynamic range, i.e., there is a general minimum noise level in the studio, created by, say, artists or technical staff moving around, or the noise due to air currents and breath, and all types of electrically induced distortions.

Up to the pre-mixing and level amplifiers no big problems are encountered. However, depending on the equipment used for level adjustment, the low *and* high limits of dynamic range are affected by the use of equalization. The type and extent of equalization depend on the medium. Whatever, control amplification and level compression are necessary, and this affects the sound quality and the audio chain. Furthermore, if you consider the fact that for each of the three media (tape, disc, broadcast) master tape and mother tape are used, you can easily understand that the narrow dynamic range available from conventional tape recorders becomes a 'bottle neck' which affects the whole process.

To summarize, in spite of all the spectacular improvements in analog technology, it is clear that the original dynamic range is still seriously affected in the analog reproduction chain.


Similar limits to other factors affecting the system: frequency response, signal-to-noise ratio, distortion, etc. exist simply due to the analog processes involved. These reasons prompted manufacturers to turn to digital techniques for audio reproduction.

### **First Development of PCM Recording Systems**

The first public demonstration of pulse code modulated (PCM) digital audio was in May 1967, by NHK (Japan Broadcasting Corporation) and the record medium used was a 1-inch, 2-head, helical scan VTR. The impression gained by most people who heard it was that the fidelity of the sound produced by the digital equipment could not be matched by any conventional tape recorder. This was mainly because the limits introduced by the conventional tape recorder simply no longer occurred.

As shown in Figure 4a, the main reason why conventional analog tape recorders cause such a deterioration of the original signal is firstly that the magnetic material on the tape actually contains distortion components before anything is actually recorded. Secondly, the medium itself is non-linear, that is, it is not capable of recording and reproducing a signal with total accuracy. Distortion is, therefore, built-in to the very heart of every analog tape recorder. In PCM-recording (Figure 4a), however, the original bit value pattern corresponding to the audio signal, and thus the audio signal itself, can be fully recovered, even if the recorded signal is distorted by tape non-linearities and other causes.

## 8 A Short History of Audio Technology



**Figure 4** Showing (a) conventional analog and (b) PCM digital tape recording

After this demonstration at least, there were no grounds for doubting the high sound quality achievable by PCM techniques. The engineers and music lovers who were present at this first public PCM playback demonstration, however, had no idea when this equipment would be commercially available, and many of these people had only the vaguest concept of the effect which PCM recording systems would have on the audio industry. In fact, it would be no exaggeration to say that owing to the difficulty of editing, the weight, size, price, and difficulty in operation, not to mention the necessity of using the highest-quality ancillary equipment (another source of high costs), it was at that time very difficult to imagine that any meaningful progress could be made.

Nevertheless, highest-quality record production at that time was by the direct cutting method, in which the lacquer master is cut without using master and mother tapes in the production process: the live source signal is fed directly to the disc cutting head after being mixed. Limitations due to analog tape recorders were thus side-stepped. Although direct cutting sounds quite simple in principle, it is actually extremely difficult in practice. First of all, all the required musical and technical personnel, the performers, the mixing and cutting engineers, have to be assembled together in the same place at the same time. Then the whole piece to be recorded must be performed right through from beginning to end with no mistakes, because the live source is fed directly to the cutting head.

If PCM equipment could be perfected, high-quality records could be produced while solving the problems of time and value posed by direct cutting. PCM recording meant that the process after the making of the master tape could be completed at leisure.

In 1969, Nippon Columbia developed a prototype PCM recorder, loosely based on the PCM equipment originally created by NHK: a 4-head VTR with 2-inch tape was used as a recording medium, with a sampling rate of 47.25 kHz using a 13-bit linear analog-to-digital converter. This machine was the starting-point for the PCM recording systems which are at present marketed by Sony, after much development and adaptation.

### **Development of Commercial PCM Processors**

In a PCM recorder, there are three main parts: an encoder which converts the audio source signal into a digital PCM signal, a decoder to convert the PCM signal back into an audio signal and, of course, there has to be a recording medium, using some kind of magnetic tape for record and reproduction of the PCM encoded signal.

The time period occupied by one bit in the stream of bits composing a PCM encoded signal is determined by the sampling frequency and the number of quantization bits. If, say, a sampling frequency of 50 kHz is chosen (sampling period  $20\ \mu\text{s}$ ), and that a 16-bit quantization system is used, then the time period occupied by one bit when making a two-channel recording will be about  $0.6\ \mu\text{s}$ . In order to ensure the success of the recording, detection bits for the error-correction system will also have to be included. As a result, it is necessary to employ a record/reproduction system which has a bandwidth of between about 1 and 2 MHz.

Bearing in mind this bandwidth requirement, the most suitable practical recorder is a video tape recorder (VTR). The VTR was specifically designed for recording TV pictures, in the form of video signals. To successfully record a video signal, a bandwidth of several megahertz is necessary, and it is a happy coincidence that this makes the VTR eminently suitable for recording a PCM encoded audio signal.

The suitability of the VTR as an existing recording medium meant that the first PCM tape recorders were developed as two-unit systems comprising a VTR and a digital audio processor. The latter was connected directly to an analog hi-fi system for actual reproduction. Such a device, the PCM-1, was first marketed by Sony in 1977.

In the following year, the PCM-1600 digital audio processor for professional applications was marketed. In April 1978, the use of 44.056 kHz as a sampling frequency (the one used in the above-mentioned models) was accepted by the AES (Audio Engineering Society).



**Photo 4** *PCM-1 digital audio processor*

At the 1978 CES (Consumer Electronics Show) held in the USA, an unusual display was mounted. The most famous names among the American speaker manufacturers demonstrated their latest products using a PCM-1 digital audio processor and a consumer VTR as the sound source. Compared with the situation only a few years ago, when the sound quality available from tape recorders was regarded as being of relatively low standard, the testing of speakers using a PCM tape recorder marked a total reversal of thought. The audio industry had made a major step towards true fidelity to the original sound source, through the total redevelopment of the recording medium which used to cause most degradation of the original signal.

At the same time a committee for the standardization of matters relating to PCM audio processors using consumer VTRs was established, in Japan, by 12 major electronics companies. In May 1978 they reached agreement on the EIAJ (Electronics Industry Association of Japan) standard. This standard basically agreed on a 14-bit linear data format for consumer digital audio applications.


The first commercial processor for domestic use according to this EIAJ standard, which gained great popularity, was the now famous PCM-F1 launched in 1982. This unit could be switched from 14-bit into 16-bit linear coding/decoding format so, in spite of being basically a product designed for the demanding hi-fi enthusiast, its qualities were so outstanding that it was

immediately used on a great scale in the professional audio recording business as well, thus quickening the acceptance of digital audio in the recording studios.

In the professional field the successor to the PCM-1600, the PCM-1610, used a more elaborate recording format than EIAJ and consequently necessitated professional VTRs based on the U-Matic standard. It quickly became a de facto standard for two-channel digital audio production and compact disc mastering.



**Photo 5** *PCM-F1 digital audio processor*



**Photo 6** *PCM-1610 digital audio processor*

### Stationary Head Digital Tape Recorders

The most important piece of equipment in the recording studio is the multi-channel tape recorder: different performers are recorded on different channels – often at different times – so that the studio engineer can create the required ‘mix’ of sound before editing and dubbing. The smallest number of channels used is generally 4, the largest 32.

A digital tape recorder would be ideal for studio use because dubbing (re-recording of the same piece) can be carried out more or less indefinitely. On an analog tape recorder (Figure 5), however, distortion increases with each dub. Also, a digital tape recorder is immune to cross-talk between channels, which can cause problems on an analog tape recorder.

It would, however, be very difficult to satisfy studio standard requirements using a digital audio processor combined with a VTR. For a studio, a fixed head digital tape recorder would be the answer. Nevertheless, the construction of a stationary head digital tape recorder poses a number of special problems. The most important of these concerns the type of magnetic tape and the heads used.


The head-to-tape speed of a helical scan VTR (Figure 5) used with a digital audio processor is very high, around 10 metres per second. However, on a stationary head recorder, the maximum speed possible is around 50 centimetres per second, meaning that information has to be packed much more closely on the tape when using a stationary head recorder; in other words, it has to be capable of much higher recording densities. As a result of this, a great deal of research was carried out in the 1970s into new types of modulation recording systems, and special heads capable of handling high-density recording.

Another problem is generated when using a digital tape recorder to edit audio signals – it is virtually impossible to edit without introducing ‘artificial’ errors in the final result. Extremely powerful error-correcting codes were invented capable of eliminating these errors.

The digital multi-channel recorder had finally developed after all the problems outlined above had been resolved. A standard format for stationary head recorders, called DASH (digital audio stationary head) was agreed upon by major manufacturers like Studer, Sony and Matsushita. Example of such a machine is the 24-channel Sony PCM-3324.

### Development of the Compact Disc

In the 1970s the age of the video disc began, with three different systems being pursued: the optical system, where the video signal is laid down as a series of fine grooves on a sort of record, and is read off by a laser beam; the



**Figure 5** Analog audio and video tape recording



## 14 A Short History of Audio Technology



**Photo 7** *PCM-3324 digital audio stationary head (DASH) recorder*

capacitance system, which uses changes in electrostatic capacitance to plot the video signal; and the electrical system, which uses a transducer. Engineers then began to think that because the bandwidth needed to record a video signal on a video disc was more than the one needed to record a digitized sound signal, similar systems could be used for PCM/VTR recorded material. Thus the digital audio disc (DAD) was developed, using the same technologies as the optical video discs: in September 1977, Mitsubishi, Sony

and Hitachi demonstrated their DAD systems at the Audio Fair. Because everyone knew that the new disc systems would eventually become widely used by the consumer, it was absolutely vital to reach some kind of agreement on standardization.

Furthermore, Philips from the Netherlands, who had been involved in the development of video disc technology since the early 1970s had by 1978 also developed a DAD, with a diameter of only 11.5 cm, whereas most Japanese manufacturers were thinking of a 30 cm DAD, in analogy with the analog LP. Such a large record however would hold up to 15 hours of music, so it would be rather impractical and expensive.

During a visit of Philips executives to Tokyo, Sony was confronted with the Philips idea, and they soon joined forces to develop what was to become the now famous compact disc, which was finally adopted as a world-wide standard. The eventual disc size was decided upon as 12 cm, in order to give it a capacity of 74 minutes: the approximate duration of Beethoven's Ninth Symphony.

The compact disc was finally launched on the consumer market in October 1982, and in a few years, it gained great popularity with the general public, becoming an important part of the audio business.


### **Peripheral Equipment for Digital Audio Production**

It is possible to make a recording with a sound quality extremely close to the original source, when using a PCM tape recorder, as digital tape recorders do not 'colour' the recording a failing inherent in analog tape recorders. More important, a digital tape recorder offers scope for much greater freedom and flexibility during the editing process.

There follows a brief explanation of some peripheral equipment used in a studio or a broadcasting station as part of a digital system for the production of software.

- **Digital mixer.** A digital mixer which processed the signal fed to it digitally would prevent any deterioration in sound quality, and would allow the greatest freedom for the production of software. The design and construction of a digital mixer is an extremely demanding task. However, multi-channel mixers suitable for use in studios and broadcasting stations have been produced and are starting to replace analog mixing tables in demanding applications.
- **Digital editing console.** One of the major problems associated with using a VTR-based recording system is the difficulty in editing. The signal is recorded onto a VTR cassette, which means that normal cutting and splicing of the tape for editing purposes is impossible. Therefore, one of

## 16 A Short History of Audio Technology



**Photo 8** *Digital editing console*



**Photo 9** *Digital reverberator*

the most pressing problems after development of PCM recording systems is the design of an electronic editing console. The most popular editing console associated with the PCM-1610 recording system is Sony's DAE-1100.

- **Digital reverberator.** A digital reverberator is based on a totally different concept from conventional reverb units, which mostly use a spring or a steel plate to achieve the desired effect. Such mechanical reverbs are limited in the reverb effect and suffer significant signal degradation. Reverb effect available from a digital reverberation unit covers an extremely wide and precisely variable range, without signal degradation.
- **Sampling frequency conversion and quantization processing.** A sampling frequency unit is required to connect together two pieces of digital recording equipment which use different sampling frequencies. Similarly, a quantization processor is used between two pieces of equipment using different quantization bit numbers. These two devices allow free transfer of information between digital audio equipment of different standards.

### **Outline of a Digital Audio Production System**

Several units from the conventional analog audio record production system can already be replaced by digital equipment in order to improve the quality of the end product, as shown in Figure 6.

Audio signals from the microphone, after mixing, are recorded on a multi-channel digital audio recorder. The output from the digital recorder is then mixed into a stereo signal through the analog mixer, with or without the use of a digital reverberator.

The analog output signal from the mixer is then converted into a PCM signal by a digital audio processor and recorded on a VTR.

Editing of the recording is performed on a digital audio editor by means of digital audio processors and VTRs. The final result is stored on a VTR-tape or cassette. The cutting machine used is a digital version.

When the mixer is replaced by a digital version and – in the distant future – a digital microphone is used, the whole production system will be digitized.

### **Digital Audio Broadcasting**

Since 1978, FM broadcasting stations have expressed a great deal of interest in digital tape recorders, realizing the benefits they could bring almost as soon as they had been developed. Figure 7 shows an FM broadcast set-up using digital tape recorders to maintain high-quality broadcasts.






Figure 6 Digital audio editing and record production



**Figure 7** *Mixed analog and digital audio broadcasting system*



**Figure 8** *Digital audio broadcasting system*

In the near future, high-quality broadcasts will probably be made through completely digitized PCM systems, as shown in Figure 8. A bandwidth of several megahertz would be needed, however, a much higher frequency range than used at present in FM broadcasting. To broadcast such a wide bandwidth, a transmitting frequency with a wavelength of less than one centimetre would have to be used. Because of these factors, the most effective method for broadcasting a PCM signal, also from the point of view of areas which could be covered, would probably be via satellite. A great deal of research has been carried out in this field in recent years.

A standard for multi-channel digital audio broadcasting has been developed jointly by manufacturers and broadcasters from various countries.

### **R-DAT and S-DAT: New Digital Audio Tape Recorder Formats**

Further investigation to develop small, dedicated, digital audio recorders which would not necessitate a video recorder has led to a parallel development of both rotary-head and stationary-head approaches, resulting in the so-called R-DAT (rotary head digital audio tape recorder), and S-DAT (stationary head digital audio tape recorder) formats.

Like its professional counterpart, the S-DAT system relies on multiple-track thin-film heads to achieve a very high packing density, whereas the R-DAT system is actually a miniaturized rotary-head recording system, similar to video recording systems, optimized for audio applications.

The R-DAT system, launched first on the market, uses a small cassette of only  $73 \times 54 \times 10.5$  mm – about one half of the well-known analog compact cassette. Tape width is 3.81 mm – about the same as the compact cassette. Other basic characteristics of R-DAT are:

- multiple functions: a variety of quantization modes and sampling rates; several operating modes such as extra-long playing time, 2- or 4-channel recording, direct recording of digital broadcasts
- very high sound quality can be achieved using a 48 kHz sampling frequency and 16-bit linear quantization
- high-speed search facilities
- very high recording density, hence reduced running cost (linear tape speed only 0.815 cm/s)
- very small mechanism.
- SCMS: Serial Copy Management System, a copy system that allows the user to make a single copy of a copyrighted digital source.

A description of the R-DAT format and system is given in Chapter 17.

The basic specifications of the S-DAT system have been initially determined: in this case, the cassette will be reversible (as the analog compact cassette), using the same 3.81-mm tape.

Two or four audio channels will be recorded on 20 audio tracks. The width of the tracks will be only  $65 \mu\text{m}$  (they are all recorded on a total width of only 1.8 mm!) and, logically, various technological difficulties hold up its practical realization in the short term.

### **Summary of Development of Digital Audio Equipment at Sony**

#### **October 1974**

First stationary digital audio recorder, the X-12DTC, 12-bit



**Photo 10** *DTC-55ES R-DAT player*

**September 1976**

FM format 15-inch digital audio disc read by laser. Playing time: 30 minutes at 1800 rpm, 12-bit, 2-channel

**October 1976**

First digital audio processor, 12-bit, 2-channel, designed to be used in conjunction with a VTR

**June 1977**

Professional digital audio processor PAU-1602, 16-bit, 2-channel, purchased by NHK (Japan Broadcasting Corporation)

**September 1977**

World's first consumer digital audio processor PCM-1, 13-bit, 2-channel 15-inch digital audio disc read by laser. Playing time: 1 hour at 900 rpm

**March 1978**

Professional digital audio processor PCM-1600

**April 1978**

Stationary-head digital audio recorder X-22, 12-bit, 2-channel, using ¼-inch tape

World's first digital audio network

**October 1978**

Long-play digital audio disc read by laser. Playing time: 2½ hours at 450 rpm

Professional, multi-channel, stationary-head audio recorder PCM-3224, 16-bit, 24-channel, using 1-inch tape

Professional digital audio mixer DMX-800, 8-channel input, 2-channel output, 16-bit

Professional digital reverberator DRX-1000, 16-bit



## **22 A Short History of Audio Technology**

### **May 1979**

Professional digital audio processor PCM-100 and consumer digital audio processor PCM-10 designed to EIAJ (Electronics Industry Association of Japan) standard

### **October 1979**

Professional, stationary-head, multi-channel digital audio recorder PCM-3324, 16-bit, 24-channel, using 1/2-inch tape

Professional stationary-head digital audio recorder PCM-3204, 16-bit, 4-channel, using 1/4-inch tape

### **May 1980**

Willi Studer of Switzerland agrees to conform to Sony's digital audio format on stationary-head recorder

### **June 1980**

Compact disc digital audio system mutually developed by Sony and Philips

### **October 1980**

Compact disc digital audio demonstration with Philips, at Japan Audio Fair in Tokyo

### **February 1981**

Digital audio mastering system including digital audio processor PCM-1610, digital audio editor DAE-1100 and digital reverberator DRE-2000

### **Spring 1982**

PCM adapter PCM-F1 which makes digital recordings and playbacks on a home VTR

### **October 1982**

Compact disc player CDP-101 is launched onto the Japanese market and as of March 1983 it is available in Europe

### **1983**

Several new models of CD players with sophisticated features: CDP-701, CDP-501, CDP-11S  
PCM-701 encoder

**November 1984**

Portable CD player: the D-50

Car CD players: CD-X5 and CD-XR7

**1985**

Video 8 multi-track PCM-recorder (EV-S700)

**March 1987**

First R-DAT player DTC-1000ES launched onto the Japanese market

**July 1990**

Second generation R-DAT player DTC-55ES available on the European market

**March 1991**

DAT Walkman: TCD-D3

Car DAT player: DTX-10

# 1

## Introduction

For many years, two main advantages of the digital processing of analog signals have been known.

First, if the transmission system is properly specified and dimensioned, transmission quality is independent of the transmission channel or medium. This means that, in theory, factors which affect the transmission quality (noise, non-linearity, etc.) can be made arbitrarily low by proper dimensioning of the system.

Second, copies made from an original recording in the digital domain, are identical to that original; in other words, a virtually unlimited number of copies, which all have the same basic quality as the original, can be made. This is a feature totally unavailable with analog recording.

A basic block diagram of a digital signal processing system is shown in Figure 1.1.


Digital audio processing does require an added circuit complexity, and a larger bandwidth than analog audio processing systems, but these are minor disadvantages when the extra quality is considered.

Perhaps the most critical stages in digital audio processing are the conversions from analog to digital signals, and vice versa. Although the principles of A/D and D/A conversion may seem relatively simple, in fact, they are technically speaking very difficult and may cause severe degradation of the original signal. Consequently, these stages often generate a limiting factor that determines the overall system performance.


Conversion from analog to digital signals is done in several steps:

- filtering – this limits the analog signal bandwidth, for reasons outlined below
- sampling – converts a continuous-time signal into a discrete-time signal

## 28 Principles of Digital Signal Processing



**Figure 1.1** Basic digital signal processing system



1 analog signal. continuous in time  
continuous in value

2 sampled signal. discrete in time  
continuous in value

3 digital signal. discrete in time  
discrete in value

**Figure 1.2** An analog-to-digital conversion system

- quantization – converts a continuous-value signal into a discrete-value signal
- coding – defines the code of the digital signal according to the application that follows.

Figure 1.2 shows the block diagram of an analog-to-digital conversion system.

# 2

## Principles of Sampling

### The Nyquist Theorem

By definition, an analog signal varies continuously with time. To enable it to be converted into a digital signal, it is necessary that the signal is first sampled, i.e., at certain points in time a sample of the input value must be taken (Figure 2.1). The fixed time intervals between each sample are called **sampling intervals** ( $t_s$ ).

Although the sampling operation may seem to introduce a rather drastic modification of the input signal (as it ignores all the signal changes that occur between the sampling times), it can be shown that the sampling process in principle removes *no information whatsoever*, as long as the sampling frequency is at least present in the input signal. This is the famous **Nyquist theorem** on sampling (also called the Shannon theorem).

The Nyquist theorem can be verified if we consider the frequency spectra of the input and output signals (Figure 2.2).

An analog signal  $i_{(t)}$  which has a maximum frequency  $f_{\max}$ , will have a






Figure 2.1



**Figure 2.2** Showing the sampling process in (a) time domain and (b) frequency domain

spectrum having any form between 0 Hz and  $f_{\max}$  (Figure 2.2.1a); the sampling signal  $s(t)$ , having a fixed frequency  $f_s$ , can be represented by one single line at  $f_s$  (Figure 2.2.1b). The sampling process is equivalent to a multiplication of  $i(t)$  and  $s(t)$ , and the spectrum of the resultant signal (Figure 2.2.3b) can be seen to contain the same spectrum as the analog signal, together with repetitions of the spectrum modulated around multiples of the sampling frequency. As a consequence, low-pass filtering can completely isolate and thus completely recover the analog signal.

The pictures in Figure 2.3 show two sine waves (bottom traces) and their sampled equivalents (top traces).



**Figure 2.3** Two examples of sine waves together with sampled versions (a) (top) 1 kHz sine wave (b) (bottom) 10 kHz sine wave. Sampling frequency  $f_s$  is 44.056 kHz




Figure 2.4 If sampling frequency is too low, aliasing occurs




Figure 2.5 Characteristic of an anti-aliasing filter

Although sampling in Figure 2.3b seems much coarser than in Figure 2.3a, in both cases restitution of the original signal is perfectly possible.

Figure 2.2.3b also shows that  $f_s$  must be greater than  $2f_{\max}$  otherwise the original spectrum would overlap with the modulated part of the spectrum, and consequently be inseparable from it (Figure 2.4).

For example, a 20 kHz signal sampled at 35 kHz produces a 5 kHz difference frequency. This phenomenon is known as **aliasing**.



To avoid aliasing due to harmonics of the analog signal, a very sharp cut-off filter (known as an anti-aliasing filter) is used in the signal path to remove harmonics before sampling takes place. Characteristic of a typical anti-aliasing filter is shown in Figure 2.5.

## Sampling Frequency

From this, it is easy to understand that the selection of the sampling frequency is very important. On one hand, selecting too high a sampling rate would increase the hardware costs dramatically. On the other hand, since ideal low-pass filters do not exist, a certain safety margin must be incorporated in order to avoid any frequency higher than  $\frac{1}{2}f_s$  passing through the filter with insufficient attenuation.

### EIAJ format

For an audio signal with a typical bandwidth of 20 Hz to 20 kHz, the lowest sampling frequency which corresponds to the Nyquist theorem is 40 kHz. At this frequency a very steep and, consequently, very expensive anti-aliasing filter, is required. Therefore a sampling frequency of approximately 44 kHz is typically used, allowing use of an economical 'anti-aliasing filter'; flat until 20 kHz but with sufficient attenuation (60 dB) at 22 kHz to make possible aliasing components inaudible.

Furthermore, because the first commercially available digital audio recorders stored the digital signal using a standard helical scan video recorder, there had to be a fixed relationship between sampling frequency ( $f_s$ ) and horizontal video frequency ( $f_h$ ), so these frequencies could be derived from the same master clock by frequency division.

For the NTSC 525-line television system, a sampling frequency of 44,055944... Hz was selected, whereas for the PAL 625-line system, a frequency of 44,100 Hz was chosen. The difference between these two frequencies is only 0.1%, which is negligible for normal use (the difference translates as a pitch difference at playback, and 0.1% is entirely imperceptible).


### Compact disc sampling rate

For compact disc, the same sampling rate as used in the PCM-F1 format, i.e., 44.1 kHz, was commonly agreed upon by the establishers of the standard.

### Video 8 PCM

The video 8 recording standard also has a provision for PCM recording. The PCM data is recorded in a time-compressed form, into a 30° tape section of

### 34 Principles of Digital Signal Processing



**Figure 2.6** Showing how PCM coded audio signals are recorded on a section of tape in a Video 8 track

each video channel track (Figure 2.6). However, sampling frequency must be reduced to allow the data to fit.

Nevertheless, as the sampling frequency is exactly twice the video horizontal frequency ( $f_h$ ), the audio frequency range is still more than 15 kHz, which is still acceptable for hi-fi recording purposes. Table 2.1 lists the horizontal frequencies for PAL and NTSC television standards, giving resultant sampling frequencies.

Also, since only 30° of the track are used for the audio recording, a multi-channel (6 channels) PCM recording is possible when the whole video recording area is used for PCM.

**Table 2.1** *Horizontal and sampling frequencies of Video 8 recorders, on PAL and NTSC television standards*

	PAL	NTSC
$f_h$	15.625	15.734365
$f_s$	31.250	31.468530

### Sampling rate for professional application

A sampling frequency of 32 kHz has been chosen by the EBU for PCM communications for broadcast and telephone, since an audio frequency range of up to 15 kHz is considered to be adequate for television and FM radio broadcast transmissions.

As we saw in Chapter 1, stationary-head digital audio recorders are most suited to giving a multi-track recording capability in the studio. One of the aspects of such studio recorders is that the tape speed must be adjustable, in order to allow easy synchronization between several machines and correct tuning. Considering a speed tuning range of, say, 10%, a sampling frequency of 44 kHz could decrease to less than 40 kHz, which is too low to comply with the Nyquist theorem. Therefore, such machines should use a higher sampling rate which at the lowest speed must still be above  $2f_s$ .

After a study of all aspects of this matter, 48 kHz has been selected as recommended sampling frequency for studio recorders. This frequency is compatible with television and motion-picture system frame frequencies (50 and 60 Hz) and has an integer relationship (3/2) with the 32 kHz sampling of the PCM network used by broadcast companies. The relationships between sampling frequency and frame frequencies (1/960, 1/800) enable the application of time coding, which is essential for editing and synchronization of the tape recorder. As there is no fixed relationship between 44.1 kHz (CD sampling frequency) and 48 kHz, Sony's studio recorders can use either frequency.

The reason why so much importance was attached to the integer relation of sampling frequencies is conversion: it is then possible to economically dub or

## 36 Principles of Digital Signal Processing

convert the signals in the digital mode without any deterioration. Newly developed sampling rate converters, however, allow to convert also between non-related sampling rates, so that this issue has become less important than it used to be.


### Sampling rates for R-DAT and S-DAT formats

In the DAT specification, multiple sampling rates are possible to enable different functions:

- 48 kHz, for highest-quality recording and playback
- 32 kHz, for high-quality recording with longer recording time or for recording on four tracks and for direct (digital) recording of digital broadcasts
- 44.1 kHz playback-only, for reproduction of commercial albums released on R-DAT or S-DAT cassettes.


### Sample-Hold Circuits

In the practice of analog-to-digital conversion, the sampling operation is performed by **sample-and-hold circuits**, that store the sampled analog voltage for a time; during which the voltage can be converted by the A/D converter into a digital code. The principle of a sample-and-hold circuit is relatively simple and is shown in Figure 2.7.



**Figure 2.7** Basic sample-and-hold circuit


**Figure 2.8** Sine wave before (top) and after (bottom) sample-hold



**Figure 2.9** FET input sample-hold circuit

A basic sample-and-hold circuit is a ‘voltage memory’ device that stores a given voltage in a high-quality capacitor. To sample the input voltage, switch S closes momentarily: when S re-opens, capacitor C holds the voltage until S closes again to pass the next sample. Figure 2.8 is a photograph showing a sine wave at the input (top) and the output (bottom) of a sample-and-hold circuit.

Practical circuits have buffer amplifiers at input, in order not to load the source, and output, to be able to drive a load such as an A/D converter. The output buffer amplifier must have a very high input impedance, and very low bias current, so that the charge of the hold capacitor does not leak away. Also, the switch must be very fast and have low off-stage leakage. An actual sample-and-hold circuit may use an analog (JFET-switch) and a high-quality capacitor, followed by a buffer amplifier (voltage-follower), as shown in Figure 2.9.



**Figure 2.10** *The effect of using a sample-and-hold circuit as a deglitcher*

Sample-and-hold circuits are not only used in A/D conversion but also in D/A conversion, to remove transients (glitches) from the output of the D/A converter. In this case, a sample-and-hold circuit is often called a **deglitcher** (Figure 2.10).

### Aperture Control

The output signal of a sampling process is in fact a pulse amplitude modulated (PAM) signal. It can be shown that, for sinusoidal input signals, the frequency characteristic of the sampled output is:

$$H(\omega_v) = \frac{t_o}{t_s} \cdot \frac{\sin \frac{t_o}{2} \omega_v}{\frac{t_o}{2} \omega_v}$$

In which  $\omega_v$  = angular velocity of input signal (=  $2\pi f_v$ )

$t_o$  = pulse width of the sampling pulse

$t_s$  = sampling period.


At the output of a sample-and-hold circuit or a D/A converter, however,  $t_o = t_s$ . Consequently:

$$H(\omega_v)_{t_o = t_s} = \frac{\sin \frac{t_s}{2} \omega_v}{\frac{t_s}{2} \omega_v}$$

This means that at maximum admissible input frequency (which is half the sampling frequency),  $\omega_v = \frac{\pi}{t_s}$ , and consequently:

$$H\left(\frac{\pi}{t_s}\right)_{t_0 = t_s} = \frac{\sin \frac{\pi}{2}}{\frac{\pi}{2}} \approx 0.64$$

This decreased frequency response can be corrected by an **aperture circuit**, which decreases  $t_0$  and restores a normal PAM signal (Figure 2.11).



**Figure 2.11** Basic circuit and waveforms of aperture control circuit


## 40 Principles of Digital Signal Processing

In most practical circuits  $t_o = \frac{t_s}{4}$ , which leads to:

$$H\left(\frac{\pi}{t_s}\right)_{t_s} = \frac{t_s}{4} = \frac{\sin \frac{\pi}{8}}{\frac{\pi}{8}} \approx 0.97$$

This is an acceptable value: reducing  $t_o$  further would also reduce the average output voltage too much and thus worsen the signal-to-noise ratio.

Figure 2.12 shows the frequency response for some values of  $t_o$ .



**Figure 2.12** Showing output characteristic of an aperture control circuit, as functions of aperture time and frequency response

### Characteristics and Terminology of Sample-Hold Circuits

In a sample-and-hold circuit, the **accuracy** of the output voltage depends on the quality of the buffer amplifiers, on the leakage current of the holding capacitor and of the sampling switch. Unavoidable leakage generally causes the output voltage to decrease slightly during the 'hold' period, in a process known as **droop**.

In fast applications, **acquisition time** and **settling time** are also important. Acquisition time is the time needed after the transition from hold to sample




periods for the output voltage to match the input, within a certain error band. Settling time is the time needed after the transition from sample to hold periods to obtain a stable output voltage. Both times obviously define the maximum sampling rate of the unit.

**Aperture time** is the time interval between beginning and end of the transition from sample to hold periods; also terms like **aperture uncertainty** and **aperture jitter** are used to indicate variations in the aperture time and consequently variations of the sample instant itself.

# 3

## Principles of Quantization

Even after sampling the signal is still in the analog domain: the amplitude of each sample can vary *infinitely* between analog voltage limits. The decisive step to the digital domain is now taken by **quantization** (see Figure 3.1), i.e.,



**Figure 3.1** Principle of quantization

replacing the *infinite* number of voltages by a *finite* number of corresponding values.

In a practical system the analog signal range is divided into a number of regions (in our example, 16), and the samples of the signal are assigned a certain value (say,  $-8$  to  $+7$ ) according to the region in which they fall. The values are denoted by digital (binary) numbers. In Figure 3.1, the 16 values are denoted by a 4-bit binary number, as  $2^4 = 16$ .

The example shows a **bipolar** system in which the input voltage can be either positive or negative (the normal case for audio). In this case, the coding system is often the **2's complement** code, in which positive numbers are indicated by the natural binary code while negative numbers are indicated by complementing the positive codes (i.e., changing the state of all bits) and adding one. In such a system, the most significant bit (MSB) is used as a **sign bit**, and is 'zero' for positive values but 'one' for negative values.

The regions into which the signal range is divided are called **quantization intervals**, sometimes represented by the letter  $Q$ . A series of  $n$  bits represent-




Figure 3.2 Quantization stage characteristic

## 44 Principles of Digital Signal Processing

ing the voltage corresponding to a quantization interval is called a **word**. In our simple example a word consists of four bits. Figure 3.2 shows a typical quantization stage characteristic.

In fact, quantization can be regarded as a mechanism in which some information is thrown away, keeping only as much as necessary to retain a required accuracy (or fidelity) in an application.

### Quantization Error


By definition, because all voltages in a certain quantization interval are represented by the voltage at the *centre* of this interval, the process of quantization is a non-linear process and creates an error, called **quantization error** (or, sometimes, **round-off error**). The maximum quantization error is obviously equal to half the quantization interval  $Q$ , except in the case that the input voltage widely exceeds the maximum quantization levels ( $+$  or  $-V_{\max}$ ), when the signal will be rounded to these values. Generally, however, such overflows or underflows are avoided by careful scaling of the input signal.

So, in the general case, we can say that:

$$-Q/2 < e_{(n)} < Q/2$$

where  $e_{(n)}$  is the quantization error for a given sample  $n$ .

It can be shown that, with most types of input signals, the quantization errors for the several samples will be *randomly* distributed between these two limits, or in other words, its probability density function is flat (Figure 3.3).



**Figure 3.3** Probability density function of quantization error

There is a very good analogy between quantization error in digital systems and noise in analog systems: one can indeed consider the quantized signal as a perfect signal plus quantization error (just like an analog signal can be considered to be the sum of the signal without noise *plus* a noise signal) (see Figure 3.4). In this manner, the quantization error is often called **quantization noise**, and a 'signal-to-quantization noise' ratio can be calculated.

### Calculation of Theoretical Signal-to-Noise Ratio

In an n-bit system, the number of quantization intervals N can be expressed as:

$$N = 2^n \quad (1)$$

If the maximum amplitude of the signal is V, the quantization interval Q can be expressed as:

$$Q = \frac{V}{N-1} \quad (2)$$

As the quantization noise is equally distributed within  $\pm Q/2$ , the quantization noise power  $N_a$  is:

$$N_a = \frac{2}{Q} \int_0^{Q/2} x^2 dx = \frac{2}{Q} \left( \frac{(Q/2)^3}{3} \right) = \frac{1}{12} Q^2 \quad (3)$$

If we consider a sinusoidal input signal with p-p amplitude V, the signal power is:


$$S = \frac{1}{2} \int_0^{2\pi} \left( \frac{V}{2} \sin x \right)^2 dx = \frac{1}{8} V^2 \quad (4)$$

Consequently, the power ratio of signal-to-quantization noise is:

$$\frac{S}{N_a} = \frac{V^2/8}{Q^2/12} = \frac{V^2/8}{V^2/(N-1)^2 \cdot 12} \approx \frac{3}{2} N^2 \text{ (for } N \gg 1) \quad (5)$$

Or by substituting equation (1):

$$\frac{S}{N_a} = \frac{3}{2} \left( 2^{2n} \right) = 3 \left( 2^{2n-1} \right)$$



**Figure 3.4** Analogy between quantization error and noise

**Table 3.1** Truth table for 16-bit 2's complement binary system

0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	= +32767
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	= +32766
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	1	= +32765
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	= +32764
⋮																	
⋮																	
⋮																	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	= +3
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	= +2
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	= +1
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	= 0
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	= -1
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	= -2
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	1	= -3
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	= -4
⋮																	
⋮																	
⋮																	
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	= -32765
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	= -32766
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	= -32767
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	= -32768

Expressed in decibels, this gives:

$$S/N \text{ (dB)} = 10 \log (S/N_a) = 10 \log 3(2^{2n-1})$$

Working this out gives:

$$S/N \text{ (dB)} = 6.02 \times n + 1.76$$

A 16-bit system, therefore, gives a theoretical signal-to-noise ratio of 98 dB; a 14-bit system gives 86 dB.

In a 16-bit system, the digital signal can take  $2^{16}$  (i.e., 65,535) different values, according to the truth table shown in Table 3.1.

### Masking of Quantization Noise

Although, generally speaking, the quantization error is randomly distributed between + and  $-Q/2$  (see Figure 3.1) and is consequently similar to analog white noise, there are some cases in which it may become much more noticeable than the theoretical signal-to-noise figures would indicate.

The reason is mainly that, under certain conditions, quantization can create harmonics in the audio passband which are not directly related to the input signal; and audibility of such distortion components is much higher than in the 'classical' analog cases of distortion. Such distortion is known as **granulation noise**, and, in bad cases, it may become audible as beat tones.

Auditory tests have shown that to make granulation noise just as perceptible as 'analog' white noise, the measured signal-to-noise ratio should be up to 10–12 dB higher. To reduce this audibility, there are two possibilities:

- a) to increase the number of bits sufficiently (which is very expensive)
- b) to 'mask' the digital noise by a small amount of analog white noise, known as '**dither noise**'.

Although such an addition of 'dither noise' actually worsens the overall signal-to-noise ratio by several dB, the highly audible granulation effect can be very effectively masked by it. The technique of adding 'dither' is well known in the digital signal processing field; particularly in video applications, where it is used to reduce the visibility of the noise in digitized video signals.

## Conversion Codes

In principle, any digital coding system can be adopted to indicate the different analog levels in A/D or D/A conversion, as long as they are properly defined. Some, however, are better for certain applications than others. Two main groups exist: unipolar codes and bipolar codes. Bipolar codes give information on both the magnitude and the sign of the signal, which makes them preferable for audio applications.

### Unipolar codes

Depending upon application, the following codes are popular:

#### *Natural binary code*

The MSB has a weight of 0.5 (i.e.,  $2^{-1}$ ), the second bit has a weight of 0.25 ( $2^{-2}$ ), and so on, until the least significant bit (LSB) which has a weight of  $2^{-n}$ . Consequently, the maximum value that can be expressed (when all bits are one) is  $1 - 2^{-n}$ , i.e., full-scale minus one LSB.

#### *BCD code*

The well-known 4-bit code in which the maximum value is 1001 (decimal 9), after which the code is reset to 0000. A number of such 4-bit codes is combined in case we want, for instance, a direct read-out on a numeric scale such as in digital voltmeters. Because of this maximum of ten levels, this code is not used for audio purposes.



*Gray code*

Used when the advantage of changing only one bit per transition is important, for instance in position encoders where inaccuracies might otherwise give completely erroneous codes. It is easily convertible to binary. Not used for audio.

**Bipolar codes**

These codes are similar to the unipolar natural binary code, but one additional bit, the sign bit, is added. Structure of the most popular codes is compared in Table 3.2.

*Sign magnitude*

The magnitude of the voltage is expressed by its normal (unipolar) binary code, and a sign bit is simply added to express polarity.

An advantage is that the transition around zero is simple; however, it is more difficult to process and there are two codes for zero.

*Offset binary*

This is a natural binary code, but with zero at minus full scale; this makes it relatively easy to implement and to process.

*Two's complement*

Very similar to offset binary, but with the sign bit inverted. Arithmetically, a two's complement code word is formed by complementing the positive value and adding 1 LSB. For example:

$$+2 = 0010$$

$$-2 = 1101 + 1 = 1110$$

It is a very easy code to process, for instance, positive and negative numbers added together always give zero (disregarding the extra carry). For example:

$$\begin{array}{r} 0010 \\ + 1110 \\ \hline 0000 \end{array}$$

It is the code almost universally used for digital audio; there is however (as with offset binary), a rather big transition at zero – all bits change from 1 to 0.

*One's complement*

Here negative values are full complements of positive values. This code is not commonly used.

Table 3.2 Common bipolar codes

Decimal fraction						
Number	Positive reference	Negative reference	Sign + magnitude	Two's complement	Offset binary	One's complement
+7	$+\frac{7}{8}$	$-\frac{7}{8}$	0 1 1 1	0 1 1 1	1 1 1 1	0 1 1 1
+6	$+\frac{6}{8}$	$-\frac{6}{8}$	0 1 1 0	0 1 1 0	1 1 1 0	0 1 1 0
+5	$+\frac{5}{8}$	$-\frac{5}{8}$	0 1 0 1	0 1 0 1	1 1 0 1	0 1 0 1
+4	$+\frac{4}{8}$	$-\frac{4}{8}$	0 1 0 0	0 1 0 0	1 1 0 0	0 1 0 0
+3	$+\frac{3}{8}$	$-\frac{3}{8}$	0 0 1 1	0 0 1 1	1 0 1 1	0 0 1 1
+2	$+\frac{2}{8}$	$-\frac{2}{8}$	0 0 1 0	0 0 1 0	1 0 1 0	0 0 1 0
+1	$+\frac{1}{8}$	$-\frac{1}{8}$	0 0 0 1	0 0 0 1	1 0 0 1	0 0 0 1
0	0+	0-	0 0 0 0	0 0 0 0	1 0 0 0	0 0 0 0
0	0-	0+	1 0 0 0	(0 0 0 0)	(1 0 0 0)	1 1 1 1

-1	$-\frac{1}{8}$	$+\frac{1}{8}$	1001	1111	0111	1110
-2	$-\frac{2}{8}$	$+\frac{2}{8}$	1010	1110	0110	1101
-3	$-\frac{3}{8}$	$+\frac{3}{8}$	1011	1101	0101	1100
-4	$-\frac{4}{8}$	$+\frac{4}{8}$	1100	1100	0100	1011
-5	$-\frac{5}{8}$	$+\frac{5}{8}$	1101	1011	0011	1010
-6	$-\frac{6}{8}$	$+\frac{6}{8}$	1110	1010	0010	1001
-7	$-\frac{7}{8}$	$+\frac{7}{8}$	1111	1001	0001	1000
-8	$-\frac{8}{8}$	$+\frac{8}{8}$		(1000)	(0000)	

---

# 4

## Overview of A/D Conversion Systems

### Linear (or Uniform) Quantization


In all the examples seen so far, the quantization intervals  $Q$  were identical. Such quantization systems are commonly termed **linear** or **uniform**. Regarding simplicity and quality, linear systems are certainly best. However, linear systems are rather costly in terms of required bandwidth and conversion accuracy. Indeed, a 16-bit audio channel with a sampling frequency of 44.056 kHz gives a bit stream of at least  $16 \times 44.056 = 705 \times 10^3 \text{ bit s}^{-1}$ , which requires a bandwidth of 350 kHz – 17.5 times the bandwidth of the original signal. In practice, a wider bandwidth than this is required because more bits are needed for synchronization, error correction and other purposes.

Since the beginning of PCM telephony, ways to reduce the bandwidths that digitized audio signals require have been developed. Most of these techniques can also be used for digital audio.

### Companding Systems

If, in a quantizer, the quantization intervals  $Q$  are not identical, we talk about **non-linear quantization**. It is, for instance, perfectly possible to change the quantization intervals according to the level of the input signal. In general, in such systems, small-level signals will be quantized with more closely spaced intervals, while larger signals can be quantized with bigger quantization intervals. This is possible because the larger signals more or less mask the unavoidably higher noise levels of the coarser quantization.

Such a non-linear quantization system can be thought to consist of a linear system, to which a compander has been added. In such a system, the input signal is first compressed, following some non-linear law  $F(x)$ , then linearly




**Figure 4.1** *Non-linear quantization*

quantized, processed and then after reconversion, expanded by the reverse non-linearity  $F^{-1}(y)$  (see Figure 4.1). The overall effect is analogous to compressors used in the analog field (e.g., Dolby, dBx and others).

The non-linear laws which compressors follow can be shown in graphical forms as curves. One compressor curve used extensively in digital telephony in North America for the digitization of speech, is the ' $\mu$ -law' curve. This curve is characterized by the formula:

$$F(x) = V \frac{V_{\log}(1 + \mu x/V)}{\log(1 + \mu)}$$

Curves for this equation are shown in Figure 4.2 for several values of  $\mu$ . In Europe, the 'A law' curve is more generally used (Figure 4.3).



**Figure 4.2** *Characteristics of  $\mu$ -law compressors*




Figure 4.3 A-law characteristic curve

The (dual) formula for the 'A law' is:

$$F(x) = Ax/1 + \log A \text{ for } 0 < x < V/a$$

$$F(x) = V + V \log (Ax/V)/1 + \log A \text{ for } V/a < x < V$$

In practice, it is important that the non-linearities at the input and the output of any audio system are very closely matched. This is difficult to achieve with analog techniques so compressors are usually built in to the conversion process.


The big advantage of these companded systems is that signal-to-noise ratio becomes less dependent on the level of the input signal; the disadvantage, however, is that the noise level follows the level of the signal, which may lead to audible noise modulation.

### Floating-Point Conversion

A special case of non-linear quantization, used in professional audio systems, is the 'floating-point converter' (Figure 4.4).

Sampled signal is sent through several selectable paths, each with a different gain; depending on the input level of the signal. Path, and hence gain, is selected by a logic monitor circuit in order to make maximum use of the linear A/D converter without overloading it. The output from the A/D converter, called 'mantissa' in an analogy with logarithmic annotation, is meaningless without a way to indicate the gain that was originally selected. This information is provided by a logic output from the monitor circuit, called 'exponent'. Exponent and mantissa, taken together, give an unambiguous digital word that can be reconverted to the original signal by selecting the corresponding (inverse) gains in the decoding stage. In this way two bits of exponent can indicate four different gains. If we select these gains as 0, 6, 12 and 18 dB for instance, the two additional bits provide an increase of 18 dB over the dynamic range of the basic system.

Because the signal level determines basic system gain, noise modulation is unavoidable. This may become audible, for instance, with a high-level,



**Figure 4.4** *Floating-point converter principle*

## 56 Principles of Digital Signal Processing

low-frequency, signal: in this case, noise modulation will not be masked by the signal.

Due to effects of noise modulation, a distinction must be made between the dynamic range and the signal-to-noise ratio. The dynamic range can be defined as:


$$\frac{\text{maximum signal level (RMS)}}{\text{RMS level of quantization noise *without* signal}}$$

whereas the signal-to-noise ratio is:

$$\frac{\text{signal level (RMS)}}{\text{RMS level of quantization noise *with* signal}}$$

A curve for the signal-to-noise ratio of a typical floating-point converter with a 10-bit mantissa, a 3-bit exponent and 6 dB gain steps is shown in Figure 4.5. Although, theoretically, this system provides the same dynamic range as a 17-bit linear system (i.e., over 100 dB), the signal-to-noise ratio is unacceptable for high-quality purposes.

In spite of this, high-quality floating-point converters having, say, a 13-bit mantissa and 3-bit exponent are still considered for digital audio purposes, as they are considerably cheaper than linear systems.



**Figure 4.5** Signal-to-noise ratio of a floating-point converter



## Block Floating-Point Conversion

When a low bandwidth is of utmost importance, **block conversion** can be used. This technique is also known as **near-instantaneous companding** (in contrast to basic floating point or other companding systems). The term 'near-instantaneous' is used to describe the fact that not every sample is scaled by an exponent, but a number of successive samples (usually 32). Each block of samples is then followed by a scale factor word, so that, at the receiving end, each block can be correctly scaled up again (Figure 4.6).


This system is rather expensive as far as hardware is concerned, but permits significant reductions in bit rates. Consequently, a typical application is digital transmission of audio signals in radio networks.

Subjective listening tests have shown that an original 14-bit system compressed to 10 bits is almost indistinguishable from a 13-bit linear system, although the signal-to-noise ratio limitations of a floating-point converter remain valid.

An example of such a system is the BBC's NICAM-3 (near-instantaneous companding audio multiplex) which permits transmission of six audio channels over one (standard) telephony 2048 kbits/s circuit.

## Differential PCM and Delta Modulation

Instead of transmitting the exact binary value of each sample, it is possible to transmit only the difference between the current sample and the previous one. As this difference is generally small, a smaller number of bits can be used with no apparent degradation in performance. Operation is fairly straightforward: one sample is stored for the complete sample period, then added to



**Figure 4.6** A block floating-point converter




Figure 4.7 1-bit D/A converter

the received difference signal to obtain the next sample. This sample is then stored until the next received difference signal.

Differential PCM, in fact, is a special type of **predictive encoding**. In such encoding schemes, a prediction is generated for the current sample, based upon past data; the correcting signal is simply the difference between the prediction and the actual signal.

As sampling rate increases, the differences between previous and present samples become smaller, so that, in the extreme for very high sampling rates, only 1 bit is needed for the error signal to indicate the sign of the error; in this case we talk about **delta modulation**.

Figure 4.7 shows a basic single-bit A/D converter. The input signal is compared with the output of a 1-bit D/A converter, the resulting voltage is then compared with a reference and the output used to increment or decrement the DAC value. For any input signal the system needs to perform a certain number of iterations to obtain the required resolution. Each iteration results in a high or low signal at the output of the A/D converter. Looking at the output we see a pulse train whose mean value equals the level of the input signal. The analog input has been converted to a binary bit stream. The typical sampling frequency in 1-bit converters is several MHz.

Because the serial bit stream is of little practical use, it is mostly converted to a multibit format (e.g. 16 bit) with a much lower sampling rate. This is done in a digital filter, a so called decimation filter which includes noise shaping (Figure 4.8).




Figure 4.8 Block diagram of 1-bit A/D converter

In a further step, the transmitted data can be used to indicate not only the sign of the error, but also the step size. For example, a continuous series of ones means that the signal is quickly increasing, so the step size can be increased; if ones and zeros are alternating, step size can be reduced. Such strategies are called **adaptive differential PCM** (the quantization interval is changed) or **adaptive delta modulation** (the step size is changed). Although these techniques have some interesting theoretical and practical properties, it is presently difficult to use them for high-quality applications.

# 5

## Operation of A/D – D/A Converters

Some of the most important components in digital audio systems are the converters. Previous chapters have shown the need for high resolution to obtain a satisfactory signal-to-noise ratio.

In video applications, an 8-bit conversion is more than sufficient. A 14-bit conversion (or an equivalent) seems a minimum for good audio performance, and, for professional use, 16-bit conversion is required to leave a margin for further processing (e.g., filtering, mixing).

In the PCM-F1 and compact disc system, 16-bit converters are used, while the PCM video 8 system uses a 10-bit converter.

### **A/D Converters**

Fundamentally, A/D converters operate in one of two general ways. They either: convert the analog input signal to a frequency or a set of pulses whose time is measured to provide a representative digital output, or: compare the input signal with a variable reference, using an internal D/A converter to obtain the digital output.

#### **Basic types of A/D converters**

Voltage-to-frequency, ramp, and integrating-ramp methods are the three leading conversion processes that use the time-measurement method. Successive approximation and parallel/modified parallel circuits rely on comparison methods.

#### *Dual-slope integrating A/D converters*

The dual-slope integrating A/D converter contains an integrator, some control logic, a clock, a comparator, and an output counter, as shown in

Figure 5.1. A graph of integrator output voltage against time is shown in Figure 5.2.


The input analog signal is initially switched to the integrator, and the output of the integrator ramps up for a time  $t_1$ . The slope of the ramp, and hence the integrator output voltage at the end of this time, depends on the amplitude of the analog input signal and the time constant  $\tau$  of the integrator:

$$\frac{V_{IN}}{\tau}$$

So the integrator output voltage  $V_0$  at the end of time  $t_1$  is:

$$\frac{V_{IN}}{\tau} t_1$$

The reference signal is then switched to the integrator input, and the integrator output voltage ramps down until it returns to the starting voltage. The slope of the ramp during time  $t_2$  similarly depends on the integrator time



**Figure 5.1** Block diagram of a dual-slope integrating A/D converter

## 62 Principles of Digital Signal Processing

constant and the integrator input voltage, this time the reference signal amplitude:

$$\frac{V_{\text{REF}}}{\tau}$$

So the integrator output voltage at the beginning time  $t_2$  is:


$$\frac{V_{\text{REF}}}{\tau} t_2$$

But as these voltages are the same:

$$\frac{V_{\text{IN}}}{\tau} t_1 = \frac{V_{\text{REF}}}{\tau} t_2$$

Therefore:

$$\frac{V_{\text{IN}}}{V_{\text{REF}}} = \frac{t_2}{t_1}$$



**Figure 5.2** Showing integrator output voltage as a function of time, during conversions

which shows that time  $t_2$  is totally dependent on the input signal amplitude, and independent of integrator time constant. By counting clock pulses during time  $t_2$  a digital measure of the analog input signal's amplitude is made.

Average conversion time, i.e., time the converter takes to perform the conversion of an applied input signal, is two clock periods times the number of quantization levels. Thus, for a 12-bit converter with a 1 MHz clock, the average conversion time is:  $2 \times 1 \mu\text{s} \times 4096$  or 8.192 ms. The precise conversion time, however, depends on the applied input signal amplitude.

Due to this long conversion time integrating converters are not useful for digitizing high-speed, rapidly varying signals, although they are useful to 14-bit accuracy, offering high noise rejection and excellent stability with both time and temperature. They can be modified to increase conversion speeds and are used mostly in 8- to 12-bit converters for digital voltmeters (DVMs), digital panel meters (DPMs) and digital multimeters (DMMs). However, basic dual-slope integrating A/D converters are too slow for general computer applications.


#### *Successive-approximation A/D converters*

The main reasons that the successive-approximation technique is used almost universally in A/D conversion systems are: the reliability of the conversion technique, simplicity, and inherent high-speed data conversion. Conversion time is equal to the clock period times the number of bits being converted. Thus, for a 1 MHz clock, a 12-bit converter would take  $12 \mu\text{s}$  to convert an applied analog signal.


A successive approximation converter consists of a comparator, a register, control logic and a D/A converter. Output of the D/A converter is compared with the input analog voltage (Figure 5.3). Each bit line in the D/A converter corresponds to a bit position in the register. Initially, the converter is clear.

When an input signal is applied the control logic instructs the register to change its MSB to 1. This is changed by the D/A converter to an analog voltage equivalent to one-half the converter's full-scale range. If the input voltage is greater than this, the next most significant bit of the register becomes 1. If, however, the input is less, the next most significant bit remains 0. Then the circuit 'tries' the following bits through to the LSB, at which stage the conversion is complete. Thus the number of approximations occurring in any conversion equals the number of bits in the digital output. Figure 5.4 shows operation of the successive approximation A/D converter graphically.

Main advantage of the successive-approximation converter is speed and this is limited by the settling time of the DAC. Accuracy is limited by the accuracy of the DAC, and a high susceptibility to noise is its major drawback. As only one comparator is used and ancillary hardware is limited to logic, register and D/A converter, the successive-approximation technique provides an inexpensive A/D converter.



**Figure 5.3** Successive approximation A/D converter



**Figure 5.4** Illustration of successive approximation conversion. The digitally generated voltage gets closer to the analog input voltage in a series of approximations; each approximation is half the preceding one


### Other types of A/D converters

#### Voltage-to-frequency converters

Figure 5.5 shows a typical voltage-to-frequency converter. Here, the input analog signal is integrated and fed to a comparator. When the comparator changes its state, the integrator is reset and the process repeats itself. The counter counts the number of integration cycles for a given time to provide a digital output.

The principal advantage of this type of conversion is its excellent noise





**Figure 5.5** Voltage-to-frequency A/D converter

rejection due to the fact that the digital output represents the average value of the input signal. Voltage-to-frequency conversion, however, is too slow for use in data-acquisition system applications because it operates bit-serially (with a maximum of approximately 1000 conversions/s). Its applications are mostly in digital voltmeters (DVMs) using converters with resolutions of 10 bits or less.

#### *Ramp converters*

Ramp conversion works by continuously comparing a linear reference ramp signal with the input signal using a comparator (Figure 5.6). The comparator initiates a counter when changing state and the counter counts clock pulses during the time the comparator is logically HIGH; the count is therefore proportional to the magnitude of the input signal. The counter output is the digital representation of the analog input.

This method is slightly faster than the previous one, but it requires a highly linear ramp source in order to be effective. It does offer good 8- to 12-bit differential linearity for applications requiring high accuracy.

#### *Parallel A/D converters*

Parallel-series and straight parallel converters are used primarily where extremely high speed is required, taking advantage of the fact that the propagation time through a chain of amplifiers is equal to the square root of the number of stages times the individual setting time, as opposed to adding up the times of each stage. By adding a comparator for every binary-weighted network, as shown in Figure 5.7, it is possible to take advantage of this higher




Figure 5.6 Block diagram of a ramp converter




Figure 5.7 Parallel A/D converter




Figure 5.8 Sequential parallel A/D conversion


speed. Parallel A/D converters are often called **flash converters** because of their high operating speeds.

The parallel A/D converter of Figure 5.7 uses one comparator for each input quantization level (i.e., a 6-bit converter would have 6 comparators). Conversion is straightforward; all that is required besides the comparators is logic for decoding the comparator outputs.

Because only comparators and logic gates stand between the analog inputs and digital outputs, extremely high speeds of up to 50,000,000 samplings/s can be obtained at low resolutions of 6 bits or less. The fact that the number of comparator and logic elements increases with resolution obviously makes this converter increasingly impractical for resolutions greater than 6 bits.

Modified parallel designs can provide a good tradeoff between hardware complexity and the resolution/speed combination at a slight addition in hardware and a sacrifice in speed. They can provide up to 100,000 conversions/s for up to 14-bit resolutions. Sequential conversion (Figure 5.8), for example, is often used for such applications. However, because of the increase in the number of comparators and the need to use an amplifier for every weighting network, cost is considerably more than that of a successive approximation.

The first 4-bit converter in the circuit in Figure 5.8 provides the 4 most significant bits in parallel. These outputs are converted back to an analog voltage which is subtracted from the input. The difference is applied to the next converter and the process is continued until the required 10 bits are



**Figure 5.9** First order Delta-Sigma modulator

obtained. This approach gives a reasonable tradeoff among speed, cost, and accuracy.

#### *Delta-sigma modulator*


A delta-sigma modulator is the key device in a 1 bit A/D converter. Figure 5.9 shows a first order delta-sigma modulator. Operation is performed at each clock cycle, which corresponds to the oversampling frequency. At the beginning of each clock cycle, the differential amplifier outputs the difference between the input voltage  $V$  and the output voltage of the single-bit D/A converter. The integrator adds the voltage  $a$  to its own output from the preceding clock cycle. This voltage  $b$  is provided to the zero comparator. The output of the comparator will be logically HIGH or LOW, depending on voltage  $b$  being higher or lower than 0 V. The output then becomes a piece of single-bit A/D data, which is also used to determine the output of the 1 bit DAC for the next clock cycle. The 1 bit DAC outputs a positive full-scale voltage if its input is HIGH and a negative full-scale voltage if its input is LOW. Table 5.1 shows an example of actual operation in which the input is 0.6 V, with the full-scale voltage being  $\pm 1$  V and all initial values 0.

The 1 bit A/D converter outputs only HIGH or LOW, which has no meaning in itself, this only becomes meaningful when a string of 1 bit data is averaged.

Because of the high sampling frequency (64 times oversampling) a very gentle low pass filter can be used, resulting in low phase distortion. Compared to successive approximation A/D converters single bit A/D converters provide better performance while circuit complexity and cost remain equal.

**Table 5.1** Operation example of  $\Delta$ – $\Sigma$  modulator

Clock	d	a	b	c
0	0	0.6	0.6	1
1	1	–0.4	0.2	1
2	1	–0.4	–0.2	0
3	–1	1.6	1.4	1
4	1	–0.4	1.0	1
5	1	–0.4	0.6	1
6	1	–0.4	0.2	1
7	1	–0.4	–0.2	0
8	–1	1.6	1.4	1
9	1	–0.4	1.0	1
10	1	–0.4	1.0	1
11	1	–0.4	0.2	1
12	1	–0.4	–0.2	0
13	–1	1.6	1.4	1
14	1	–0.4	1.0	1
15	1	–0.4	0.6	1

 0.6 V fixed input,  $\pm 1$  V full scale voltage

**Figure 5.10**  $\Delta$ – $\Sigma$  modulator or noise shaper

### Noise shaping

A delta-sigma modulator is sometimes also called a noise shaper because it passes signals and noise according to different transfer functions (Figure 5.10). The signal transfer function for the modulator simplifies to:

$$\frac{Y(s)}{X(s)} = \frac{1}{s+1}$$

This is the s-domain representation of a first-order low pass filter. Deriving the noise transfer function for the same modulator produces:

$$\frac{Y(s)}{N(s)} = \frac{s}{s+1}$$




Figure 5.11 Transfer functions of noise shaper

This is the s-domain representation of a simple high-pass filter. Plotting the transfer functions gives the result shown in Figure 5.11. The signal is attenuated at higher frequencies, while the noise is shaped so that very little of its content is in the low frequency region. By using higher order delta-sigma modulators the in-band noise can even be reduced further, however out-of-band noise will increase. In practice a third or fourth order delta-sigma modulator is used to avoid stability problems while still using most of the noise shaping capabilities.


### Sony A/D Converter

The converter currently used in most Sony digital recorders is of the **dual-slope single-integration** type. By combining on one chip for counter, latch and control logic (using I<sup>2</sup>L techniques) with very accurate current sources and comparators (using ECL techniques) a 16-bit dual-slope single-integration A/D converter is produced. Further, by using double counters, the conversion time is kept sufficiently low. Figure 5.12 shows a block diagram.

In a standard 16-bit converter of this type, required clock frequency needs to be:

$$65,536 \times 44 \text{ kHz} = 2.89 \text{ GHz}$$

which cannot be accomplished. However, the double counter conversion principle means that much lower clock frequencies can be used.



The main building blocks of this converter are:

- two constant-current sources ( $I_0$  and  $i_0$ ), in which the ratio:

$$\frac{I_o + i_o}{i_o} = 128 = (2^7)$$

So:

$$I_o = (2^7 - 1) i_o$$

Or:

$$I_o + i_o = 128i_o$$

has been set extremely accurately.

- a 9-bit counter and a 7-bit counter
- a 9-bit latch and a 7-bit latch
- a 16-bit shift register
- 2 comparators
- a reference-voltage source
- a clock oscillator

The nine higher bits correspond with the 9-bit dataword from counter C1, the seven lower bits with the 7-bit dataword from counter C2. When both datawords are combined, the 16 bits form the output data. Figure 5.13 gives the timing diagram of one conversion cycle. Operation of a cycle is as follows:




Figure 5.13 Timing diagram of the conversion cycle

Switch S1 is closed and capacitor C is charged to the input voltage ( $V_{in}$ ). This is the **sampling** time. Next, switch S1 is opened and capacitor C holds the input voltage ( $V_{in}$ ). This is the **hold** time.

At time  $t_2$ , both switches S2 and S3 are closed and capacitor C is discharged by the reference currents  $I_o$  and  $i_o$ . The upper 9-bit counter simultaneously starts counting.

When the output of the integrator ( $V_H$ ) exceeds the reference voltage  $V_1$ , switch S2 is opened by comparator 1 and current source  $I_o$  is disabled. At this time ( $t_3$ ), the 9-bit counter is also disabled. The contents of this counter become the 9 MSBs of the A/D converter's output.

From time  $t_3$  on, only  $i_o$  is used for discharging the capacitor C and the 7-bit counter starts counting. When the output voltage of the comparator ( $V_H$ ) exceeds the reference voltage  $V_o$ , switch S3 is opened by comparator 2 and the current source  $i_o$  is disabled. At this time ( $t_4$ ) the 7-bit counter stops counting and its contents become the 7 LSBs of the converter's output. The contents of both counters are output serially as a 16-bit word, starting with the MSB.

Double counter conversion method reduces the required clock frequency






Figure 5.14 Video 8 analog-to-digital converter

from 2.8 GHz for a single counter, 16-bit system, to  $\pm 28$  MHz. This type of converter is used in all Sony's EIAJ-type PCM adapters as well as in professional recorders such as PCM-3324 and PCM-1630.

### Video 8 PCM Converter

Here, too, a dual-slope integration conversion is applied, but with a few differences (Figure 5.14). A 10-bit A/D conversion is applied with two 5-bit converters. The ratio between the two discharging constant currents is:

$$I_o = (2^5 - 1) \times i_o$$

Furthermore, the converter circuit is in LSI form, comprising A/D and D/A conversion circuits, and aperture and sample/hold amplifiers.

### D/A Conversion in Digital Audio Equipment

Although in different digital audio systems the applied circuits may differ slightly, the basic operating principle of all systems is that of the A/D




Figure 5.15 Integrating D/A converter




Figure 5.16 Timing diagram of the integrating D/A converter

integrating converter, switched in a feedback loop. A basic block diagram is shown in Figure 5.15, and a timing diagram is given in Figure 5.16.

The edge of the conversion command (CC) signal starts the D/A conversion cycle. Timing signals are generated internally. After a delay  $t_1$ , a discharge pulse, of length  $t_2$ , and a counter set pulse,  $t_3$ , are generated.

After a delay  $t_4$ , the integration current starts and the counters start counting. Delay  $t_5$  is variable as it depends on the value of the digital input word.

Upon the conversion command, capacitor  $C$ , the integrating capacitor, is discharged by a closing switch  $S1$  (a field effect transistor) with the discharge signal. The counters are simultaneously loaded with the digital word which is to be converted, upon application of the counter set signal.

The integration current start signal closes internal switches S2 and S3, and capacitor C starts to charge. When the counter set signal ends, the counters start counting down. Initially, both constant currents,  $I_o$  and  $i_o$ , flow to charge capacitor C, but as each counter reaches zero its corresponding current is stopped. The final charge across the capacitor is the analog value representing the digital input word. The relation between the two constant currents is determined by the word length of each counter. In this example the converter has 16-bit resolution, and counting is performed by two 8-bit counters. So,  $I_o = 256i_o$ .


### Oversampling

The output of a digital-to-analog converter cannot be used directly; filtering is necessary. The converter output produces the frequency spectrum shown in Figure 5.17, where the baseband audio signal ( $0-f_m$ ) is reproduced symmetrical around the sampling frequency ( $f_s$ ) and its harmonics. The low-pass reconstruction filter must reject everything except the baseband signal.


A sampling frequency ( $f_s$ ) of 44,100 Hz and a maximum audio frequency ( $f_m$ ) of 20,000 Hz mean that a low-pass filter with a flat response to 20 kHz and a high attenuation at  $f_s - f_m$  ( $44,100 - 20,000 = 24,100$  Hz) is needed. An analog filter can be made to have such a sharp roll-off, but the phase response will introduce an audible phase distortion and group delay.

One approach to getting round this problem is **oversampling**.


Oversampling is the use of a sampling rate greatly in excess of that stipulated by the Nyquist theorem. Practical implementations use a  $\times 2$  oversampling ( $f_s = 88.2$  kHz) or a  $\times 4$  oversampling frequency ( $f_s = 176.5$  kHz). Output spectrum of the D/A converter in a  $\times 2$  oversampling system is shown in Figure 5.18, where the large separation between baseband and sidebands allows a low-pass filter with a gentle roll-off to be used. This improves the phase response of the filter.



**Figure 5.17** Spectrum of a sampled baseband audio signal. A filter must reject all frequencies above a cut-off frequency  $f_m$



**Figure 5.18** In a  $\times 2$  oversampling system the effective sampling frequency becomes twice that of the actual sampling frequency. A simple low-pass filter can be used to reject all unwanted signal frequencies



**Figure 5.19** Timing diagram of an oversampling system. Words at a sampling frequency of 44.1 kHz have interpolated samples added, such that the effective sampling rate is 88.2 kHz

Digital words are input at the standard sampling rate of 44.1 kHz (i.e., no extra samples need be taken at the A/D conversion stage), and extra samples are generated at a rate of 88.2 kHz (Figure 5.19). The missing samples are computed by digital simulation of the analog reconstruction process. A **digital transversal filter** (also known as a **finite impulse response filter**) is well suited for this purpose.


### Analog versus digital filters

The discrete-time signal produced by sampling an analog input signal (Figure 5.20) is defined as an infinite series of numbers, each corresponding to a sampling point at time  $t = T_n$  for  $-\infty < n < +\infty$ . Such a series is always referred to by its value at  $t = T_n$  which is  $x(n)$ .

The series  $x(n)$  is defined as:

$$x(n) = \dots, x(-2), x(-1), x(0), x(1), x(2), \dots$$

with element  $x(n)$  occurring at time  $t = T_n$ .



**Figure 5.20** Showing how a continuous value and continuous time analog signal is first converted to a discrete time but continuous value set of signals

### Analog filters

The first-order low-pass analog filter shown in Figure 5.21 is often described as a function of  $s$ , the independent variable in the complex frequency domain. The transfer function of such a filter is given by:

$$f(s) = \frac{V_o}{V_i} = \frac{1}{1+s} = \frac{1}{1+j\frac{\omega}{\omega_0}}$$

where:

$\omega$  = angular frequency =  $2\pi f$

and:


$\omega_0$  is the angular frequency at the filter's cut-off frequency  $f_c = \frac{1}{RC}$

Knowing this, the cut-off frequency of the filter can be calculated as follows:


$$2\pi f_c = \frac{1}{RC}$$

so:

$$f_c = \frac{1}{2\pi RC}$$



**Figure 5.21** Simple first-order low-pass filter



T = Unit delay (sampling period)

⊕ = Adder

△ = Multiplier (coefficient =  $a_i$  or  $-b_j$ )

**Figure 5.22** Recursive digital filter

### Digital filter

A digital filter is a processing system which generates the output sequence,  $y(n)$ , from an input sequence,  $x(n)$ , where:

$$y(n) = \underbrace{\sum_{i=0}^M a_i x(n-i)}_{\text{present and past input samples}} - \underbrace{\sum_{j=0}^N b_j y(n-j)}_{\text{past output samples}}$$

The coefficients  $a_0, a_1, \dots, a_M$  and  $b_0, b_1, \dots, b_N$  are constants which describe the filter response.

When  $N > 0$ , indicating that past output samples are used in the calculation of the present output sample, the filter is said to be **recursive** or **cyclic**. An example is shown in Figure 5.22. When only present and past input samples are used in the calculation of the present output sample, the filter is said to be **non-recursive** or **non-cyclic**: because no past output samples are involved in the calculation, the second term then becomes zero (as  $N = 0$ ). An example is shown in Figure 5.23.

Generally, digital audio systems use non-recursive filters and an example, used in the CDP-102 compact disc player, is shown in Figure 5.24 as a block

diagram. IC309 is a CX23034, a 96th-order filter which contains 96 multipliers. The constant coefficients are contained in a ROM look-up table. Also note that the CX23034 operates on 16-bit wide data words, which means that all adders and multipliers are 16-bit devices.




Figure 5.23 Non-recursive digital filter




Figure 5.24 CDP-102 digital filter

# 6

## Codes for Digital Magnetic Recording

The binary data representing an audio signal can be recorded on tape (or disc) in two ways: either directly, or after frequency modulation.

When frequency modulation is used, say, in helical-scan recorders, data can be modulated as they are, usually in a **non-return-to-zero** format (see further). If they are recorded directly, however, say, in stationary head recorders and compact disc, they have to be transformed to some new code to obtain a recording signal which matches as well as possible the properties of the recording channel.

This code should have a format which allows the highest bit density permitted by the limiting characteristics of the recording channel (frequency response, dropout rate, etc.) to be obtained. Also, its DC content should be eliminated, as magnetic recorders cannot reproduce DC.

Coding of binary data in order to comply with the demands of the recording channel is often referred to as **channel coding**.

### **Non-Return to Zero (NRZ)**

This code is one of the oldest and best known of all channel codes. Basically, a logic 1 is represented by positive magnetization, and a logic 0 by negative magnetization.

A succession of the same logic levels, though, presents no change in the signal, so that there may be a significant low-frequency content, which is undesirable for stationary-head recording.

In helical-scan recording techniques, on the other hand, the data are FM-converted before being recorded, so this property is less important. NRZ



is commonly used in such formats as PCM-1600 and the EIAJ-format PCM-100 and PCM-10 recorders.

Several variations of NRZ also exist for various applications.

### **Bi-Phase**

Similar to NRZ, but extra transitions are added at the beginning of every data bit interval. As a result, DC content is eliminated and synchronization becomes easier, but the density of signal transitions increases.

This code (and its variants) is also known as **Manchester code**, and is used in the video 8 PCM recording format, where bits are modulated as a 2.9 MHz signal for a logic 0 and as 5.8 MHz for a logic 1.

### **Modified Frequency Modulation (MFM)**

Also called **Miller code** or **delay modulation**. Ones are coded with transitions in the middle of the bit cell, isolated zeros are ignored, and between pairs of zeros a transition is inserted. It requires almost the same low bandwidth as NRZ, but has a reduced DC content. The logic needed for decoding is more complicated.

A variation is the so-called **modified modified frequency modulation** ( $M^2FM$ ).

### **3-Position Modulation (3PM)**

This is a code which permits very high packing densities, but which requires rather complicated hardware. In principle, 3PM code is obtained by dividing the original NRZ data into blocks of 3; each block is then converted to a 6-bit 3PM code, which is designed to optimize the maximum and minimum run lengths. In this way, the minimum possible time between transitions is two times the original (NRZ) clock period, whereas the maximum is six times the original.

For detection, on the other hand, a clock frequency twice that of the original signal is needed, consequently reducing the jitter margin of the system. This clock is normally recovered from the data itself, which have a high harmonic content around the clock frequency.

### **High Density Modulation – 1 (HDM – 1)**

This is a variation upon the 3PM system. The density ratio is the same as 3PM, but clock recovery is easier and the required hardware simpler. It is proposed by Sony for stationary-head recording.

**Eight-to-Fourteen Modulation (EFM)**

This code is used for the compact disc digital audio system. The principle is similar again to 3PM, but each block of 8 data bits is converted into 14 channel bits, to which 3 extra bits are added for merging (synchronization) and low-frequency suppression. In this way, a good compromise is obtained between clock accuracy (and possible detection errors), minimum DC current (in disc systems, low frequencies in the signal give noise in the servo systems), and hardware complexity. Also this modulation system is very well suitable for combination with the error-correction system used in the same format.

# 7

## Principles of Error Correction

### Types of Code Errors

When digital signals are sent through a transmission channel, or recorded and subsequently played back, many types of code errors can occur. Now, in the digital field, even small errors can cause disastrous audible effects: even one incorrectly detected bit of a data word will create an audible error if it is, say, the MSB of the word. Such results are entirely unacceptable in the high quality expected from digital audio, and a lot of effort must be made to detect, and subsequently correct, as many errors as possible without making the circuit over-complicated or the recorded bandwidth too high.

There are a number of causes of code errors:

#### Dropouts

Dropouts are caused by dust or scratches on the magnetic tape or CD surface, or microscopic bubbles in the disc coating.

Tape dropout causes relatively long-time errors, called **bursts**, in which long sequences of related data are lost together. On discs dropouts may cause either burst or single random errors.

#### Jitter

Tape jitter causes random errors in the timing of detected bits and, to some extent, is unavoidable, due to properties of the tape transportation mechanism. **Jitter margin** is the maximum amount of jitter which permits correct detection of data. If the minimum run length of the signal is  $\tau$ , then the jitter margin will be  $\tau/2$ . Figure 7.1 shows this with an NRZ signal.




Figure 7.1 Illustrating jitter margin




Figure 7.2 Illustrating the cause of intersymbol interference

### Intersymbol interference

In stationary-head recording techniques, a pulse is recorded as a positive current followed by a negative current (see Figure 7.2). This causes the actual period of the signal that is read on the tape ( $T_1$ ) to be longer than the bit period itself ( $T_0$ ). Consequently, if the bit rate is very high, the detected pulse will be wider than the original pulse. Interference, known as **intersymbol interference** or **time crosstalk** may occur between adjacent bits. Intersymbol interference causes random errors, depending upon the bit situation.

### Noise

Noise may have similar effects to dropouts (differentiation between both is often difficult), but random errors may also occur in the case of pulse noise.


### Editing

Tape editing always destroys some information on the tape, which consequently must be corrected. Electronic editing can keep errors to a minimum, but tape-cut editing will always cause very long and serious errors.

### Error Compensation

Errors must be detected by some error-detection mechanism: if misdetection occurs, the result is audible disturbance. After detection, an error-correction circuit attempts to recover the correct data. If this fails, an error-concealment mechanism will cover up the faulty information so, at least, there is no audible disturbance.

These three basic functions: detection, correction and concealment, are illustrated in Figure 7.3.



**Figure 7.3** Three basic functions of error compensation: detection, correction and concealment

## Error Detection

### Simple parity checking

To detect whether a detected data word contains an error, a very simple way is to add one extra bit to it before transmission. The extra bit is given the value 0 or 1, depending upon the number of 1s in the word itself. Two systems are possible: **odd parity** and **even parity** checking.

- **Odd parity:** where the total number of 1s is odd.

Example:

<u>1110</u>	<u>0</u>
data	parity
<u>1001</u>	<u>1</u>
data	parity

- **Even parity:** where the total number of 1s is even.

Example:

<u>1110</u>	<u>1</u>
data	parity
<u>1001</u>	<u>0</u>
data	parity


The detected word must also have the required number of 1s. If this is not the case, there has been a transmission error.

This rather elementary system has two main disadvantages:

- 1 even if an error is detected, there is no way of knowing which bit was faulty
- 2 if two bits of the same word are faulty, the errors compensate each other and no errors are detected.

### Extended parity checking

To increase the probability of detecting errors, we can add more than one parity bit to each block of data. Figure 7.4 shows a system of extended parity, in which  $M-1$  blocks of data, each of  $n$ -bits, are followed by block  $m$  — the parity block. Each bit in the parity block corresponds to the relevant bits in each data block, and follows the odd or even parity rules outlined previously.



**Figure 7.4** *Extended parity checking*

If the number of parity bits is  $n$ , it can be shown that (for reasonably high values of  $n$ ) the probability of detecting errors is  $\frac{1}{2}^n$ .

### Cyclic redundancy check code (CRCC)

The most efficient error-detection coding system used in digital audio is **cyclic redundancy check code (CRCC)**, which relies on the fact that a bit stream of  $n$  bits can be considered an algebraic polynomial in a variable  $x$  with  $n$  terms. For example, the word 10011011 may be written as follows:

$$\begin{aligned} M(x) &= 1x^7 + 0x^6 + 0x^5 + 1x^4 + 1x^3 + 0x^2 + 1x^1 + 1x^0 \\ &= x^7 + x^4 + x^3 + x + 1 \end{aligned}$$

Now to compute the cyclic check on  $M(x)$ , another polynomial  $G(x)$  is chosen. Then, in the CRCC encoder,  $M(x)$  and  $G(x)$  are divided:


$$M(x)/G(x) = Q(x) + R(x)$$

where  $Q(x)$  is the quotient of the division, and  $R(x)$  is the remainder.

Then (Figure 7.5), a new message  $U(x)$  is generated as follows:

$$U(x) = M(x) + R(x)$$

so that  $U(x)$  can always be divided by  $G(x)$  to produce a quotient with no remainder.




**Figure 7.5** CRCC checking principle

## 88 Principles of Digital Signal Processing

It is this message  $U(x)$  that is recorded or transmitted. If, on playback or at the receiving end, an error  $E(x)$  occurs, the message  $V(x)$  is detected instead of  $U(x)$ , where:

$$V(x) = U(x) + E(x)$$

In the CRCC decoder,  $V(x)$  is divided by  $G(x)$ , and the resultant remainder  $E(x)$  shows there has been an error.



**Figure 7.6** Generation of a transmission polynomial

Example (illustrated in Figure 7.6):

the message is  $M(x) = x^9 + x^5 + x^2 + 1$

the check polynomial is  $G(x) = x^5 + x^4 + x^2 + 1$

Now, before dividing by  $G(x)$  we multiply  $M(x)$  by  $x^5$ ; or, in other words, we shift  $M(x)$  five places to the left, in preparation of the five check bits that will be added to the message:

$$x^5 M(x) = x^{14} + x^{10} + x^7 + x^5$$

Then the division is made:

$$x^5 M(x)/G(x) = \frac{(x^9 + x^8 + x^7 + x^3 + x^2 + x + 1)}{\text{quotient}} + \frac{(x + 1)}{\text{remainder}}$$



So that:

$$\begin{aligned} U(x) &= x^5 M(x) + (x + 1) \\ &= x^{14} + x^{10} + x^7 + x^5 + x + 1 \end{aligned}$$

which can be divided by  $G(x)$  to leave no remainder.

Figure 7.6 shows that, in fact, the original data are unmodified (only shifted), and that the check bits follow at the end.

CRCC checking is very effective in detection of transmission error. If the number of CRCC bits is  $n$ , detection probability is  $1 - 2^{-n}$ . If, say,  $n$  is 16, as in the case of the Sony PCM-1600, detection probability is  $1 - 2^{-16} = 0.999985$  or 99.9985%. This means that the CRCC features almost perfect detection capability. Only if  $E(x)$ , by coincidence, is exactly dividable by  $G(x)$ , will no error be detected. This obviously occurs only rarely and, knowing the characteristics of the transmission (or storage) medium, polynomial  $G(x)$  can be chosen such that the possibility is further minimized.

Although CRCC error-checking seems rather complex, the divisions can be done relatively simply using modulo-2 arithmetic. In practical systems LSIs are used which perform the CRCC operations reliably and fast.

## Error Correction

In order to ensure later correction of binary data, the input signal must be encoded by some encoding scheme. The data sequence is divided into message blocks, then, each message block is transformed into a longer one, by adding additional information, in a process called **redundancy**.

The ratio  $\frac{\text{data} + \text{redundant data}}{\text{data}}$  is known as the **code rate**.

There is a general theory, called the **coding theorem**, which says that the probability of decoding an error can be made as small as possible by increasing the code length and keeping the code rate less than the channel capacity.

When errors are to be corrected, we must not only know that an error has occurred, but also exactly which bit or bits are wrong. As there are only two possible bit states (0 or 1), correction is then just a matter of reversing the state of the erroneous bits.

Basically, correction (and detection) of code errors can be achieved by adding to the data bits an additional number of redundant check bits. This redundant information has a certain connection with the actual data, so that, when errors occur, the data can be reconstructed again. The redundant information is known as the error-correction code. As a simple example, all data could be transmitted twice, which would give a redundancy of 100%. By comparing both versions, or by CRCC, errors could easily be detected, and if

some word were erroneous, its counterpart could be used to give the correct data. It is even possible to record everything *three* times; this would be still more secure. These are however rather wasteful systems, and much more efficient error-correction systems can be constructed.

The development of strong and efficient error-correction codes has been one of the key research points of digital audio technology. A lot of experience has been used from computer technology, where the correction of code errors is equally important, and where a lot of research has been spent in order to optimize correction capabilities of error-correction codes. Design of strong codes is a very complex matter however, which requires thorough study and use of higher mathematics: algebraic structure has been the basis of the most important codes. Some codes are very strong against 'burst' errors, i.e., when entire clusters of bits are erroneous together (such as during tape dropouts), whereas others are better against 'random' errors, i.e., when single bits are faulty.


Error-correction codes are of two forms, in which:

- 1 data bits and error-correction bits are arranged in separate blocks; in this case we talk about **block codes**. Redundancy that follows a data block is only generated by the data in that particular block
- 2 data and error correction are mixed in one continuous data stream; in this case we talk about **convolutional codes**. Redundancy within a certain time unit does not only depend upon the data in that same time unit, but also upon data occurring a certain time before. They are more complicated, and often superior in performance to block codes.

Figure 7.7 illustrates the main differences between block and convolutional error-correcting codes.



(a) Block Code



(b) Convolutional Code

**Figure 7.7** Main differences between block and convolutional error-correcting codes

**Combinational (horizontal/vertical) parity checking**

If, for example, we consider a binary word or message consisting of 12 bits, these bits could be arranged in a  $3 \times 4$  matrix as shown in Figure 7.8.

Then, to each row and column one more bit can be added to make parity for that row or column even (or odd). Then, in the lower right-hand corner, a final bit can be added that will give the last column an even parity as well; because of this the last row will also have even parity.

1	0	1	0		0
1	0	1	1		1
0	0	1	0		1
<hr/>					
0	0	1	1		0

**Figure 7.8** *Combinational parity checking*

If this entire array is transmitted in sequence (row by row, or column by column), and if during transmission an error occurs to one bit, parity check on one row and on one column will fail; the error will be found at the intersection and, consequently, it can be corrected. The entire array of 20 bits, of which 12 are data bits, form a code word, which is referred to as a (20,12) code. There are  $20 - 12 = 8$  redundant digits.

All error-correcting codes are more or less based on this idea, although better codes, i.e., codes using fewer redundant bits than the one given in our example, can be constructed.

**Crossword code**

Correction of errors to single bits is just one aspect of error-correcting codes. In digital recording, very often errors come in bursts, with complete clusters of faulty bits. It will be obvious that, in view of the many possible combinations, the correction of such bursts or errors is very complicated and demands powerful error-correcting codes.

One such code, developed by Sony for use in its PCM-1600 series, is the **crossword code**. This uses a matrix scheme similar to the previous example, but it carries out its operations with whole words instead of individual bits, with the resultant advantage that large block code constructions can be easily realized so that burst error correction is very good. Random error correction, too, is good. Basically, the code allows detection and correction of all types of errors with a high probability of occurrence, and that only errors with a low probability of occurrence may pass undetected.




Figure 7.9 Illustration of a crossword code

A simple illustration of a crossword code is given in Figure 7.9, where the decimal numbers represent binary values or words.

Figure 7.10 shows another simple example of the crossword code, in binary form, in which four words  $M_1$  to  $M_4$  are complemented in the coder by four parity or information words  $R_5$  to  $R_8$ , so that:

$$R_5 = M_1 \oplus M_2$$


$$R_6 = M_3 \oplus M_4$$

$$R_7 = M_1 \oplus M_3$$

$$R_8 = M_2 \oplus M_4$$

where the symbol  $\oplus$  denotes modulo-2 addition.

All eight words are then recorded, and at playback received as  $U_1$  to  $U_8$ .



**Figure 7.10** Crossword code using binary data

In the decoder, additional words are constructed, called syndrome words, as follows:

$$S_1 = U_1 \oplus U_2 \oplus U_5$$

$$S_2 = U_3 \oplus U_4 \oplus U_6$$

$$S_3 = U_1 \oplus U_3 \oplus U_7$$

$$S_4 = U_2 \oplus U_4 \oplus U_8$$

By virtue of this procedure, if all received words  $U_1$  to  $U_8$  are correct, all syndromes must be zero. On the other hand, if an error  $E$  occurs in one or more words, we can say that:

$$U_i = M_i \oplus E_i \text{ for } i = 1 \text{ to } 4$$

$$U_i = R_i \oplus E_i \text{ for } i = 5 \text{ to } 8$$

Now:

$$\begin{aligned}
 S_1 &= U_1 \oplus U_2 \oplus U_5 \\
 &= M_1 \oplus E_1 \oplus M_2 \oplus E_2 \oplus R_5 \oplus E_5 \\
 &= E_1 \oplus E_2 \oplus E_5
 \end{aligned}$$

## 94 Principles of Digital Signal Processing

as we know that  $M_1 \oplus M_2 \oplus R_5 = 0$ . Similarly:

$$S_2 = E_3 \oplus E_4 \oplus E_6$$

$$S_3 = E_1 \oplus E_3 \oplus E_7$$

$$S_4 = E_2 \oplus E_4 \oplus E_8$$

Correction can then be made, because:

$$U_1 \oplus S_3 = M_1 \oplus E_1 \oplus E_1 = M_1$$

Of course, there is still a possibility that simultaneous errors in all words compensate each other to give the same syndrome patterns as in our example. The probability of this occurring, however, is extremely low and can be disregarded.

In practical decoders, when errors occur, the syndromes are investigated and a decision is made whether there is a good probability of successful correction. If the answer is yes, correction is carried out; if the answer is no, a concealment method is used. The algorithm the decision-making process follows must be initially decided using probability calculations, but once it is fixed it can easily be implemented, for instance, in a P-ROM.

Figure 7.11 shows the decoding algorithm for this example crossword code. Depending upon the value of the syndrome(s), decisions are made for correction according to the probability of miscorrection; the right column shows the probability for each situation to occur.

### b-adjacent code

A code which is very useful for correcting both random and burst errors has been described by D. C. Bossen of IBM, and called **b-adjacent code**. The b-adjacent error-correction system is used in the EIAJ format for home-use helical-scan digital audio recorders.

In this format two parity words, called P and Q, are constructed as follows:

$$P_n = L_n \oplus R_n \oplus L_{n+1} \oplus R_{n+1} \oplus R_{n+2}$$

$$Q_n = T^6 L_n \oplus T^5 R_n \oplus T^4 L_{n+1} \oplus T^3 R_{n+1} \oplus T^2 L_{n+2} \oplus T R_{n+2}$$

where T is a specific matrix of 14 words of 14 bits;  $L_n$ ,  $R_n$ , etc. are data words from, respectively, the left and the right channel.

### CIRC code and other codes

Many other error-correcting codes exist, as most manufacturers of professional audio equipment design their own preferred error-correction system.





Figure 7.11 Decoding algorithm for crossword code

Most, however, are variations on the best-known codes, with names such as Reed-Solomon code, BCH (Bose-Chaudhuri-Hocquenghem) code after the researchers who invented them.

Sony developed (together with Philips) the CIRC (cross-interleave Reed-Solomon code) for the compact disc system. R-DAT tape format uses a double Reed-Solomon code, for extremely high detection and correction capability. The DASH format for professional stationary head recorders uses a powerful combination of correction strategies, to allow for quick in/out and editing (both electric and tape splice).



**Figure 7.12** Three types of error concealment (a) muting (b) previous word holding (c) linear interpolation

### Error Concealment

Next comes a technique which prevents the uncorrected code errors from affecting the quality of the reproduced sound. This is known as **concealment**, and there are 4 typical methods.


- 1 **muting:** the erroneous word is muted, i.e., set to zero (Figure 7.12a). This is a rather rough concealment method, and consequently used rarely
- 2 **previous word holding:** the value of the word before the erroneous word is used instead (Figure 7.12b) so that there is usually no audible difference. However, especially at high frequencies where sampling frequency is only 2 or 3 times the signal frequency, this method may give unsatisfactory results
- 3 **linear interpolation** (also called **averaging**): the erroneous word is replaced by the average value of the preceding and succeeding words (Figure 7.12c). This method gives much better results than the two previous methods
- 4 **higher-order polynomial interpolation:** gives an estimation of the correct value of the erroneous word by taking into account a number of preceding and following words. Although much more complicated than previous methods, it may be worthwhile to use it in very critical applications.



## Interleaving

In view of the high recording density used to record digital audio on magnetic tape, dropouts could destroy many words simultaneously, as a burst error. Error correction that could cope with such a situation would be prohibitively complicated and, if it failed, concealment would not be possible as methods like interpolation demand that only one sample of a series is wrong.

For this reason, adjacent words from the A/D converter are not written next to each other on the tape, but at locations a sufficient distance apart to make sure that they cannot suffer from the same dropout. In effect, this method converts possible long burst errors into a series of random errors. Figure 7.13 illustrates this in a simplified example. Words are arranged in **interleave blocks**, which must be at least as long as the maximum burst error. Practical interleaving methods are much more complicated than this example, however.



**Figure 7.13** Showing how interleaving of data effectively changes burst errors into random errors

# 8

## Overview of the Compact Disc Medium

It is the compact disc that has introduced most people to digital audio reproduction. Table 8.1 is a comparison of LP and CD systems, showing that CD is far superior to LP in each aspect of dynamic range, distortion, frequency response, and wow and flutter specifications. In particular, CD exhibits a remarkably wide dynamic range (90 dB) throughout the entire audible frequency spectrum. In contrast, dynamic range of LP is 70 dB at best. Harmonic distortion of CD reproduction is less than 0.01%, which is less than one hundredth of that of LP. Wow and flutter are simply too minute to be measured in a CD system. This is because, in playback, digital data are first stored in a RAM and then released in perfect, uniform sequence determined by a reference clock of quartz precision.

With a mechanical system like that of LP, the stylus must be in physical contact with the disc. Therefore, both the stylus and the disc will eventually wear out, causing serious deterioration of sound quality. With the CD's optical system, however, lack of contact between the disc and the pick-up means that there is no sonic deterioration no matter how many times the disc is played.

Mechanical (and, for that matter, variable capacitance) systems are easily affected by dust and scratches, as signals are impressed directly on the disc surface. A compact disc, however, is covered with a protective layer (the laser optical pickup is focused underneath this) so that the effect of dust and scratches is minimized. Furthermore, a powerful error-correction system, which can correct even large burst errors, makes the effect of even severe disc damage insignificant in practice.

**Table 8.1** System comparison between CD and LP

	CD system	Conventional LP player
<b>Specifications</b>		
Frequency response	20 Hz–20 kHz $\pm$ 0.5 dB	30 Hz–20 kHz $\pm$ 3 dB
Dynamic range	More than 90 dB	70 dB (at 1 kHz)
S/N	90 dB (with MSB)	60 dB
Harmonic distortion	Less than 0.01%	1–2%
Separation	More than 90 dB	25–30 dB
Wow and flutter	Quartz precision	0.03%
<b>Dimensions</b>		
Disc	12 cm (diameter)	30 cm (diameter)
Playing time (on one side)	60 minutes (maximum 74 minutes)	20–25 minutes
<b>Operation/reliability</b>		
Durability disc	Semi-permanent	High-frequency response is degraded after being played several tens of times
Durability stylus	Over 5000 hours	500–600 hours
Operation	– Quick and easy access due to micro computer control – A variety of programmed play possible – Increased resistivity to external vibration	– Needs stylus pressure adjustment – Easily affected by external vibration
Maintenance	Dust, scratches, and fingerprints are made almost insignificant	Dust and scratches cause noise




**Photo 8.1** *CD player*

### Main Parameters


Main parameters of CD compared to LP are shown in Table 8.2. Figure 8.1 compares CD and LP disc sizes. Figure 8.2 compares track pitch and groove dimensions of a CD with an LP; 60 tracks of the CD would fit into one track of an LP.

**Table 8.2** *Parameter comparison between CD and LP*

	CD	LP
Disc diameter	120 mm	305 mm
Rotation speed	568–228 rpm (at $1.4 \text{ ms}^{-1}$ ) 486–196 rpm (at $1.2 \text{ ms}^{-1}$ )	$33\frac{1}{3}$ rpm
Playing time (maximum)	74 min	32 min (one side)
No. of tracks	20,625	1060 maximum
Track spacing	$1.6 \mu\text{m}$	$85 \mu\text{m}$
Lead-in diameter	46 mm	302 mm
Lead-out diameter	116 mm	121 mm
Total track length	5300 mm	705 m maximum
Linear velocity	$1.2$ or $1.4 \text{ ms}^{-1}$	$528\text{--}211 \text{ mms}^{-1}$



**Figure 8.1** A comparison of CD and LP sizes




**Figure 8.2** Track comparison between CD and LP

## Optical Discs

Figure 8.3 gives an overview of the optical discs available. The CD single is the digital equivalent of a 45 rpm single. It can contain about 20 minutes of music and is fully compatible with any CD player. A CD Video (CDV) contains 20 minutes of digital audio which can be played back on an ordinary CD player and 6 minutes of video with digital audio. To play back the video part you need a Video Disc Player or a Multi Disc Player (MDP).

Multi Disc Players are capable of playing both Compact Discs and Laser



**Figure 8.3** Optical discs

Discs (LD). Optical discs containing video signals can be distinguished from disc containing only digital audio by their colour. CDV and LD have a gold shine, while CD and CD single have a silver shine.

### Recording and Readout System on a CD

The data on a compact disc are recorded on the master by using a laser beam photographically to produce pits in the disc surface, in a clockwise spiral track starting at the centre of the disc. Length of the pits and the distance between them from the recorded information, as shown in Figure 8.4.

In fact, on the user disc, the pits are actually bumps. These can be identified by focusing a laser beam onto the disc surface: if there is no bump on the surface, most of the light that falls on the surface (which is highly reflective) will return in the same direction. If there is a bump present however, the light will be scattered and only a small portion will return in the original direction (Figure 8.5). The disc has a 1 mm thick protective transparent layer over the signal layer, i.e., the pits. More important, the spot size of the laser beam is about 1 mm in diameter at the surface of the disc, but is as small as  $1.7\text{ }\mu\text{m}$  across at the signal layer. This means that a dust particle or a scratch on the disc surface is literally out of focus to the sensing mechanism. Figure 8.6 illustrates this. Obviously, control of focus must be extremely accurate.




Figure 8.4 Pits on a CD, viewed from label side





Figure 8.5 CD laser beam reflection (a) from disc surface (b) from pit



**Figure 8.6** Showing how a dust particle on the disc surface is out of focus

## Signal Parameters

Before being recorded, the digital audio signal (which is a 16-bit signal) must be extended with several additional items of data. These include:

- error correction data
- control data (time, titles, lyrics, graphics and information about the recording format or emphasis)
- synchronization signals, used to detect beginning of each data block
- merging bits: added between each data symbol to reduce the DC component of the output signal.

## Audio Signal

The audio signal normally consists of two channels of audio, quantized with a 16-bit linear quantization system at a sampling frequency of 44.1 kHz. During






Figure 8.7 CD pre-emphasis and de-emphasis characteristics

recording, pre-emphasis (slight boost of the higher frequencies) may be applied. Pre-emphasis standards agreed for the compact disc format are  $50\mu s$  and  $15\mu s$  (or 3183 Hz and 10,610 Hz).

Consequently, the player must in this case apply a similar de-emphasis to the decoded signal to obtain a flat frequency response (Figure 8.7).

A specific control code recorded along with the audio signal on the compact disc is used to inform the player whether pre-emphasis is used, and so the player switches in the corresponding de-emphasis circuit to suit.

Alternatively, audio information on the CD may comprise four music channels instead of two; this is also identified by a control code to allow automatic switching of players equipped with a 4-channel playback facility. Although, on launching CD, there were no immediate plans for 4-channel discs or players, the possibility for later distribution was already provided in the standard.

### Additional information on the CD

Before the start of the music programme, a 'lead-in' signal is recorded on the CD. When a CD is inserted, most players immediately read this lead-in signal which contains a 'table of contents' (TOC). The TOC contains information on the contents of the disc, such as the starting-point of each selection or track, number of selections, duration of each selection. This information can be displayed on the player's control panel, and/or used during programme search operation.

At the end of the programme, a lead-out signal is similarly recorded which informs the player that playback is complete.

Furthermore, **music start flags** between selections inform the player that a new selection follows.

Selections recorded on the disc can be numbered from 1 through 99. In each track, up to 99 indexes can be given, which may separate specific sections of the selection. Playing time is also encoded on the disc in minutes, seconds and 1/75ths of a second; before each selection, this time is counted down.

There is further space available to encode other information, such as: titles, performer names, lyrics and even graphic information which may all be displayed, for instance on a TC screen during playback.

## Compact Disc Production

### Compact disc 'cutting'

Figure 8.8 is a block diagram comparing CD digital audio recording and playback systems with analog LP systems.

The two systems are quite similar and, in fact, overlap can occur at record production stage. However, where LP masters are mechanically cut, CD masters are 'cut' in an electro-optical photographic process: no 'cutting' of the disc surface actually takes place.

The CD disc production process follows seven main stages, illustrated in Figure 8.9:

- 1 a glass plate is polished for optimum smoothness
- 2 a photo-resist coating is applied to its surface. The roughness of the glass surface and the thickness of the coating determines the depth of the pits on the compact disc
- 3 the photo-resistive coating is then exposed to a laser beam, the intensity of which is modulated with digitized audio information
- 4 the photo-resist layer is developed and the pits of information are revealed
- 5 the surface is silvered to protect the pits
- 6 the surface is plated with nickel to make a metal master




Figure 8.8 A comparison of CD and LP recording and playback systems




Figure 8.9 Stages in the 'cutting' of a compact disc


7 the metal master is then used to make mother plates. These mothers are in turn used to make further metal masters, or stampers.

### Compact disc stamping

The stamping process, although named after the analogous stage in LP record production, is, in fact, an injection moulding, compression moulding

## 112 The Compact Disc

or polymerization process, producing plastic discs (Figure 8.10). The signal surface of each disc is then coated with a reflective material (vaporized aluminium) to enable optical read-out, and further protected with transparent plastic layer which also supports the disc label.



**Figure 8.10** Stages in 'stamping' a compact disc

# 9

## Compact Disc Encoding


A substantial amount of information is added to the audio data before the compact disc is recorded. Figure 9.1 illustrates the encoding process and shows the various information to be recorded.

There are usually two audio channels with 16-bit coding, sampled at 44.1 kHz. So, the bit rate, after combining both channels, is:

$$44.1 \times 16 \times 2 = 1.4112 \times 10^6 \text{ bits}^{-1}$$

### CIRC Encoding

Most of the errors which occur on a medium such as CD are random. However, from time to time burst errors may occur due to fingerprints, dust or scratches on the disc surface. To cope with both random and burst errors, Sony and Philips developed the cross interleave Reed-Solomon error-correction code (CIRC). CIRC is a very powerful combination of several error correction techniques.



**Figure 9.1** Encoding process in compact disc production


**Table 9.1** *Specifications of CIRC system in the compact disc*

Aspect	Specification
Maximum correctable burst error length	4000 bits (i.e., 2.5 mm on the disc surface)
Maximum interpolatable burst error length	12,300 bits (i.e., 7.7 mm on the disc surface)
Sample interpolation rate	One sample every 10 hours at a BER of $10^{-4}$  1000 samples every minute at a BER of $10^{-3}$
Undetected error samples	Less than one every 750 hours at a BER of $10^{-3}$  Negligible at a BER of $10^{-4}$
Code rate	On average, four bits are recorded for every three data bits

It is useful to be able to measure an error-correcting system's ability to correct errors, and as far as the compact disc medium is concerned it is the maximum length of a burst error which is critical. Also, the greater the number of errors received, the greater the probability of some errors being uncorrectable. The number of errors received is defined as the **bit error rate** (BER). An important system specification, therefore, is the number of data samples per unit time, called the **sample interpolation rate**, which have to be interpolated (rather than corrected) for given BER values. The lower this rate is, the better the system. Then, if burst errors cannot be corrected, an important specification is the maximum length of a burst error which can be interpolated. Finally, it is important to know the number of undetected errors, resulting in audible clicks. Any specification of an error-correcting system must take all these factors into account. Table 9.1 is a list of all relevant specifications of the CIRC system used in CD.

The CIRC principle is as follows (refer to Figure 9.2):

- the audio signal is sampled (digitized) at the A/D converter and these 16-bit samples are split up into two 8-bit words called **symbols**



**Figure 9.2** CIRC encoder

- six of 16-bit samples, from each channel, i.e., twenty-four 8-bit symbols are applied to the CIRC encoder, and stored in a RAM memory
- the first operation in the CIRC encoder is called **scrambling**. The scrambling operation consists of a two-symbol delay for the even samples and a mixing up of the connections to the C2 encoder



## 116 The Compact Disc

- the 24 scrambled symbols are then applied to the C2 encoder which generates four 8-bit parity symbols called Q words. The C2 encoder inserts the Q words between the 24 incoming symbols, so that at the output of the C2 encoder 28 symbols result
- between the C2 and the C1 decoder there are twenty-eight 8-bit delay lines with unequal delays. Due to the different delays, the sequence of the symbols is changed completely, according to a determined pattern
- the C1 encoder generates further four 8-bit parity symbols known as P words, resulting in a total of thirty-two 8-bit symbols.
- after the C1 encoder, the even words are subjected to a one-symbol delay, and all P and Q control words are inverted. The resultant sequenced thirty-two 8-bit symbols is called a **frame** and is a CIRC-encoded signal and is applied to the EFM modulator. On playback, the CIRC decoding circuit restores the original 16-bit samples which are then applied to the D/A converter.

The C2 encoder outputs twenty-eight 8-bit symbols for 24 symbols at its input: it is therefore called a (24, 28) encoder. The C1 encoder outputs 32 symbols for 28 symbols input: it is a (28, 32) encoder.

The bit rate at the output of the CIRC encoder is:

$$1.4112 \times \frac{32}{24} = 1.8816 \times 10^6 \text{ bit s}^{-1}$$


### The Control Word

One 8-bit control word is added to every 32-symbol block of data from the encoder. The compact disc standard defines eight additional channels of information or **subcodes** that can be added to the music information; these subcodes are called P, Q, R, S, T, U, V and W. At the time of writing, only the P and Q subcodes are commonly used:

- the P subcode is a simple music track separator flag that is normally 0 (during music and in the lead-in track) but is 1 at the start of each selection. It can be used for simple search systems. In the lead-out track, it switches between 0 and 1 in a 2 Hz rhythm to indicate the end of the disc.
- the Q subcode is used for more sophisticated control purposes; it contains data such as track number and time.

The other subcodes carry information relating to possible enhancements, such as text and graphics but will not be discussed here.

Each subcode word is 98 bits long: and, as each bit of the control word corresponds to each subcode (i.e., P, Q, R, S, T, U, V, W), a total of 98



**Figure 9.3** Showing how one of each of the six subcode bits are present in every frame of information. A total of 98 frames must therefore be read to read all six subcode words


complete data blocks or frames must be read from the disc to read each subcode word. This is illustrated in Figure 9.3.

After addition of the control word, the new data rate becomes:

$$1.811600 \times \frac{33}{32} = 1.9404 \times 10^6 \text{ bit s}^{-1}$$

### The Q Subcode and its Usage

Figure 9.4a illustrates the structure of the 98-bit Q subcode word. The R, S, T, U, V, and W subcode words are similar. The first two bits are synchronizing bits, S0 and S1. They are necessary to allow the decoder to distinguish the control word in a block from the audio information, and always contain the same data.



**Figure 9.4** *Formats of data in the Q subcode (a) overall format (b) mode 1 data format in the lead-in track (c) mode 1 data format in music and lead-out tracks*

The next four bits are control bits, indicating the number of channels and pre-emphasis used, as follows:

- 0000 2 audio channels/no pre-emphasis
- 1000 4 audio channels/no pre-emphasis
- 0001 2 audio channels/with pre-emphasis
- 1001 4 audio channels/with pre-emphasis

Four address bits indicate the mode of the subsequent data to follow. For the Q subcode, three modes are defined.

At the end of the subcode word a 16-bit CRCC error-correction code, calculated on control, address and data information, is inserted. The CRCC uses the polynomial  $P(X) = X^{16} + X^{12} + X^5 + 1$ .

The three modes of data in Q subcode words are used to carry various information.

#### **Mode 1 (address = 0001)**

This is the most important mode, and the only one which is of use during normal playback. At least 9 out of 20 consecutive subcode words must carry data in mode-1 format. Two different situations are possible, depending whether the subcode is in the lead-in track or not.

When in the lead-in track, the data are in the format illustrated in Figure 9.4b. The 72-bit section comprises nine 8-bit parts:

- **TNO** – containing information relating to track number: two digits in BCD form (i.e.,  $2 \times 4$  bits). Is 00 during lead-in.
- **POINT/PMIN/PSEC/PFRAME** – containing information relating to the table of contents (TOC). They are repeated three times.

POINT indicates the successive track numbers, while PMIN, PSEC and PFRAME indicate the starting time of that track. Furthermore, if POINT = A0, PMIN gives the physical track number of the first piece of music (PSEC and PFRAME are zero); if POINT = A1, PMIN indicates the last track on the disc, and if POINT = A2, the starting-point of the lead-out track is given in PMIN, PSEC and PFRAME.

Table 9.2 shows the encoding of the TOC on a disc which contains 6 pieces of music.

- **ZERO** – eight bits, all 0.

In music and lead-out tracks, data are in the format illustrated in Figure 9.4c. The 72-bit section now comprises:

- **TNO** – current track number: two digits in BCD form (01 to 99).
- **POINT** – index number within a track: two digits in BCD form (01 to 99). If POINT = 00 it indicates a pause in between tracks.
- **MIN/SEC/FRAME** – indicates running time within a track: each part, of digits in BCD form. There are 75 frames in a second (00 to 74). Time is counted down during a pause, with a value zero at the end of the pause. During lead-in and lead-out tracks, the time increases.
- **AMIN/ASEC/AFRAME** – indicates the running time of the disc in same format as above. At the start of the programme area, it is set to zero.
- **ZERO** – eight bits, all 0.

Figure 9.5 shows a timing diagram of P subcode and Q subcode status during complete reading of a disc containing four selections (of which selections three and four fade out and in consecutively without an actual pause).

### Mode 2 (address = 0010)

If mode 2 data are present, at least 1 out of 100 successive subcode words must contain it. It is of importance only to the manufacturer of the disc, containing the disc catalogue number. The 98-bit, Q subcode word in mode 2 is shown in Figure 9.6. Structure is similar to that of mode 1, with the following differences:

- **N1 to N13** – catalogue number of the disc expressed in 13 digits of BCD, according to the UPC/EAN standard for bar coding. The catalogue

**Table 9.2** *Table of contents (TOC) information, on a compact disc with six pieces of music*


Frame number	POINT	PMIN, PSEC, PFRAME
n	01	00, 02, 32
n + 1	01	00, 02, 32
n + 2	01	00, 02, 32
n + 3	02	10, 15, 12
n + 4	02	10, 15, 12
n + 5	02	10, 15, 12
n + 6	03	16, 28, 63
n + 7	03	16, 28, 63
n + 8	03	16, 28, 63
n + 9	04	16, 28, 63
n + 10	04	16, 28, 63
n + 11	04	16, 28, 63
n + 12	05	16, 28, 63
n + 13	05	16, 28, 63
n + 14	05	16, 28, 63
n + 15	06	49, 10, 33
n + 16	06	49, 10, 33
n + 17	06	49, 10, 33
n + 18	A0	01, 00, 00
n + 19	A0	01, 00, 00
n + 20	A0	01, 00, 00
n + 21	A1	06, 00, 00
n + 22	A1	06, 00, 00
n + 23	A1	06, 00, 00
n + 24	A2	52, 48, 41
n + 25	A2	52, 48, 41
n + 26	A2	52, 48, 41
n + 27	01	00, 02, 32
n + 28	01	00, 02, 32
.	.	.
.	.	.
.	.	.

number is constant for any one disc. If no catalogue number is present, N1 to N13 are all zero, or mode 2 subcode words may not even appear.


- **ZERO** – these 12 bits are zero.

#### **Mode 3 (address = 0111)**

Like mode 2 data, if mode 3 is present, at least 1 out of 100 successive subcode words will contain it.



**Figure 9.5** *Timing diagram of P and Q subcodes*



**Figure 9.6** *Q subcode format with mode 2 data*


Mode 3 is used to assign each selection with a unique number, according to the 12-character International Standard Recording Code (ISRC), defined in DIN-31-621.

If no ISRC number is assigned, mode 3 subcode words are not present. During lead-in and lead-out tracks, mode 3 subcode words are not used, and the ISRC number must only change immediately after the track number (TNO) has been changed.

The 98-bit, Q subcode word in mode 3 is shown in Figure 9.7. Structure is similar to that of mode 1, with the following differences:

- **I1 to I12** – the 12 characters of the selection’s ISRC number. Characters I1 and I2 give the code corresponding to country. Characters I3 to I5 give a

## 122 The Compact Disc



**Figure 9.7** Q subcode format with mode 3 data

**Table 9.3** Format of characters I1 to I5 in the ISRC code

Character	Binary	Octal	Character	Binary	Octal
0	000000	00	I	011001	31
1	000001	01	J	011010	32
2	000010	02	K	011011	33
3	000011	03	L	011100	34
4	000100	04	M	011101	35
5	000101	05	N	011110	36
6	000110	06	O	011111	37
7	000111	07	P	100000	40
8	001000	10	Q	100001	41
9	001001	11	R	100010	42
A	010001	21	S	100011	43
B	010010	22	T	100100	44
C	010011	23	U	100101	45
D	010100	24	V	100110	46
E	010101	25	W	100111	47
F	010110	26	X	101000	50
G	010111	27	Y	101001	51
H	011000	30	Z	101010	52


code for the owner. Characters I6 and I7 give the year of recording. Characters I8 to I12 give the recording's serial number.

Characters I1 to I5 are coded in a 6-bit format according to Table 9.3, while characters I6 to I12 are 4-bit BCD numbers.

- **00** – these two bits are zero.
- **ZERO** – these four bits are zero.

### EFM Encoding

EFM, or **eight-to-fourteen modulation**, is a technique which converts each 8-bit symbol into a 14-bit symbol, with the purpose of aiding the recording and playback procedure by reducing required bandwidth, reducing the



**Figure 9.8** *Timing diagram of EFM encoding and merging bits*

signal's DC content, and adding extra synchronization information. A timing diagram of signals in this stage of CD encoding is given in Figure 9.8.

The procedure is to use 14-bit codewords to represent all possible combinations of the 8-bit code. An 8-bit code represents 256 (i.e.,  $2^8$ ) possible combinations, as shown in Table 9.4. A 14-bit code, on the other hand, represents 16,384 (i.e.,  $2^{14}$ ) different combinations, as shown in Table 9.5. Out of the 16,384 14-bit codewords, only 256 are selected, having combinations which aid processing of the signal.

**Table 9.4** *An 8-bit code*[illegible]



**Table 9.5** *A 14-bit code*

MSB	13SB	12SB	11SB	10SB	9SB	8SB	7SB	6SB	5SB	4SB	3SB	2SB	LSB	N <sup>0</sup>
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0	0	0	1	1
0	0	0	0	0	0	0	0	0	0	0	0	1	0	2
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
1	1	1	1	1	1	1	1	1	1	1	1	1	0	16382
1	1	1	1	1	1	1	1	1	1	1	1	1	1	16383

**Table 9.6** *Examples of 8-bit to 14-bit encoding*

8-bit word	14-bit word
0 0 0 0 0 0 1 1	0 0 1 0 0 1 0 0 0 0 0 0 0 0
0 1 0 0 1 1 1 0	0 1 0 0 0 0 0 1 0 0 1 0 0 0
1 0 1 0 1 0 1 0	1 0 0 1 0 0 0 1 0 0 0 1 0 0
1 1 1 1 0 0 1 0	0 0 0 0 0 0 1 0 0 0 1 0 0 1

For instance, by choosing codewords which give low numbers of individual bit inversions (i.e., 1 to 0, or 0 to 1) between consecutive bits, the bandwidth is reduced. Similarly, by choosing codewords with only limited numbers of consecutive bits with the same logic level, overall DC content is reduced.


A ROM-based look-up table, say, can then be used to assign all 256 combinations of the 8-bit code to the 256 chosen combinations within the 14-bit code. Some examples are listed in Table 9.6.

In addition to EFM modulation, three extra bits, known as **merging bits**, are added to each 14-bit symbol, with the purpose of further lowering DC content of the signal. Exact values of the merging bits depend on the adjacent symbols.

Finally, the data bits are changed from NRZ into NRZI (non-return to zero inverted) format, by converting each positive-going pulse of the NRZ signal into a single transition. The resultant signal has a minimum length of 3T (i.e., three clock periods), and a maximum of 11T (i.e., 11 clock periods), as shown in Figure 9.9.

Bit rate is now:

$$1.9404 \times \frac{17}{8} = 4.12335 \times 10^6 \text{ bit s}^{-1}$$




**Figure 9.9** Minimum and maximum pit length

### The Sync Word

To the signal, comprising 33 symbols of 17 bits (i.e., a total 561 bits) a sync word and its three merging bits are added, giving 588 bits in total (Figure 9.10). Sync words have two main functions: (1) they indicate the start of each frame (2) sync word frequency is used to control the player's motor speed.

The 588 bit long signal block is known as an information **frame**.



**Figure 9.10** Adding the sync word

### Final Bit Rate

The final bit rate, recorded on the CD, consequently becomes:

$$4.12335 \times \frac{588}{561} = 4.3218 \times 10^6 \text{ bit s}^{-1}$$

The frame frequency  $F_{\text{frame}}$ , is:

$$\frac{4.3218}{588} = 7350 \text{ Hz}$$

And, as subcodes are in blocks of 98 frames, the subcode frequency  $F_{\text{sc}}$ , is:

$$= \frac{7350}{98} = 75 \text{ Hz}$$

Playing time is calculated by counting blocks of subcode (i.e., 75 blocks = 1 second). A 60-minute long CD contains consequently:

$$60 \times 60 \times 7350 = 26,460,000 \text{ frames}$$

As each frame comprises  $33 \times 8 = 264$  bits of information, a one-hour long CD actually contains 6,985,440,000 bits of information, or 873,180,000 bytes! Of this, the subcode area contains some 25.8 kbyte (200 Mbits). This gigantic data storage capacity of the CD medium is also used for more general purposes on the CD-ROM (compact disc read only memory), which is derived directly from the audio CD.

# 10

## Opto-electronics and the Optical Block

As the compact disc player uses a laser beam to read the disc, we will sketch some basic principles of opto-electronics – the technological marriage of the fields of optics and electronics. The principles are remarkably diverse, involving such topics as the nature of optical radiation, the interaction of light with matter, radiometry, photometry and the characteristics of various sources and sensors.

### The Optical Spectrum

By convention, electromagnetic radiation is specified according to its wavelength ( $\lambda$ ). The frequency of a specific electromagnetic wavelength is given by:


$$f = \frac{c}{\lambda}$$

where  $f$  is frequency in Hz,  $c$  is velocity of light ( $3 \times 10^8 \text{ ms}^{-1}$ ),  $\lambda$  is wavelength in m.

The optical portion of the electromagnetic spectrum extends from 10 nm to  $10^6$  nm and is divided into three major categories: ultraviolet (UV), visible and infrared (IR).

Ultraviolet (UV) are those wavelengths, falling below the visible spectrum and above x-rays. UV is classified according to its wavelength as extreme or shortwave UV (10 to 200 nm), far (200 to 300 nm) and near or long-wave UV (300 to 370 nm).

Visible are those wavelengths between 370 to 750 nm and they can be perceived by the human eye. Visible light is classified according to the various



**Photo 10.1** *Optical block of a compact disc player*

colours its wavelengths elicit in the mind of a standard observer. The major colour categories are: violet (370 to 455 nm), blue (456 to 492 nm), green (493 to 577 nm), yellow (578 to 597 nm), orange (598 to 622 nm) and red (623 to 750 nm).


Infrared (IR) are those wavelengths above the visible spectrum and below microwaves. IR is classified according to its wavelength as near (750 to 1500 nm), middle (1600 to 6000 nm), far (6100 to 40000 nm) and far-far (41000 to  $10^6$  nm).

## **Interaction of Optical Waves with Matter**


An optical wave may interact with matter by being reflected, refracted, absorbed or transmitted. The interaction normally involves two or more of these effects.

### **Reflection**

Some of the optical radiation impinging upon any surface is reflected away from the surface. Amount of reflection varies according to the properties of the surface and the wavelength and in real circumstances may range from more than 98% to less than 1% (a **lampblack** body). Reflection from a surface may be diffuse, specular or a mixture of both.



**Figure 10.1** Reflection of light from a diffuse reflector



**Figure 10.2** Reflection of light from a specular reflector

A diffuse reflector has a surface which is rough when compared to the wavelength of the impinging radiation (Figure 10.1).

A specular, sometimes called regular, reflector, on the other hand has a surface which is smooth when compared to the wavelength of the impinging radiation. A perfect specular reflector will thus reflect an incident beam without altering the divergency of the beam.

A narrow beam of optical radiation impinging upon a specular reflector obeys two rules, illustrated in Figure 10.2.

- 1 the angle of reflection is equal to the angle of incidence
- 2 the incident ray and the reflected ray lie in the same plane as a normal line extending perpendicularly from the surface.

### Absorption

Some of the optical radiation impinging upon any substance is absorbed by the substance. Amount of absorption varies according to the properties of the substance and the wavelength and in real circumstances any range from less than 1% to more than 98%.

### Transmission

Some of the optical radiation impinging upon a substance is transmitted into the substance. The penetration depth may be shallow (transmission = 0) or deep (transmission more than 75%).

The reflection ( $\rho$ ), the absorption ( $\alpha$ ) and the transmission ( $\sigma$ ) are related in the expression:

$$\rho + \alpha + \sigma = 1$$

### Refraction


A ray of optical radiation passing from one medium to another is bent at the interface of the two mediums if the angle of incidence is not  $90^\circ$ .

The index of refraction  $n$ , is the sine of the angle of incidence divided by the sine of the angle of refraction, as illustrated in Figure 10.3. Refractive index varies with wavelength and ranges from 1.0003 to 2.7.

### Optical Components

Optical components are used both to manipulate and control optical radiation and to provide optical access to various sources and sensors.

Glass is the most common optical material at visible and near-infrared wavelengths, but other wavelengths require more exotic materials such as calcium aluminate glass (for middle infrared), lithium fluoride (for UV).




**Figure 10.3** *Illustrating the index of refraction*



**The thin simple lens**

Figure 10.4 shows how an optical ray passes through a thin simple lens.

A lens may be either positive (converging) or negative (diverging). The focal point of a lens is that point at which the image of an infinitely distant point source is reproduced.

**Lens (diameter  $D$ )**

**Figure 10.4** Showing how light is refracted through a thin simple lens

Both the source and the focal point lie on the lens axis. The focal length ( $f$ ) is the distance between the lens and the focal point. The  $f$ /number of a lens defines its light-collecting ability and is given by:

$$f/\text{number} = \frac{f}{D}$$

where  $f$  is the focal length,  $D$  is the diameter of the lens.


A small  $f$ /number denotes a large lens diameter for a specified focal length and a higher light-collecting ability than a large  $f$ /number.

Numerical aperture (NA) is a measure of the acceptance angle of a lens and is given by:

$$NA = n \sin \theta$$

where  $n$  is the refractive index of the object or image medium (for air,  $n = 1$ ),  $\theta$  is half the maximum acceptance angle (shown in Figure 10.5). The relation of the focal length ( $f$ ) to the distances between the lens and the object being imaged ( $s$ ) and the lens and the focused image ( $s'$ ) is given by the gaussian form of the thin lens equation:

$$1/s + 1/s' = 1/f$$



**Figure 10.5** *Acceptance angle of a lens*

The combined focal length for two thin lenses in contact or close proximity and having the same optical axis is given by:

$$1/f = 1/f_1 + 1/f_2$$

The relationship between the focal length ( $f$ ) and the refractive index ( $n$ ) is:

$$1/f = (n - 1)(1/r_1 - 1/r_2)$$

where  $r_1$  is the radius on the left lens surface,  $r_2$  is the radius on the right lens surface.


### **The cylindrical lens**

A cylindrical lens is a section of a cylinder and therefore magnifies in only one plane. An optical beam which enters the cylindrical lens of Figure 10.6 is focused only in the horizontal plane. As a result the cross-section of the beam after passing through the lens is elliptic, with the degree varying according to the distance from the lens. By detecting the elliptic degree, a useful measure of whether or not a beam is focused on a surface can be made.

### **The prism**

A prism is an optically transparent body used to refract, disperse or reflect an optical beam. The simplest prism is the right-angle prism, shown in Figure 10.7.

An optical ray perpendicularly striking one of the shorter faces of the prism is totally internally reflected at the hypotenuse, undergoes a  $90^\circ$  deviation, and emerges from the second shorter face.




**Figure 10.6** Operation of a cylindrical lens

Operation of a totally internally reflecting prism is dependent upon the fact that a ray impinging upon the surface of a material having a refractive index ( $n$ ) smaller than the refractive index ( $n'$ ) of the medium in which the ray is propagating, will be totally internally reflected when the angle of incidence is greater than a certain critical angle ( $\theta_c$ ), given by:


$$\sin \theta_c = \frac{n'}{n}$$

### The collimator

The combination of two simple lenses is commonly used to increase the diameter of a beam while reducing its divergence. Such a **collimator** is shown in Figure 10.8.




**Figure 10.7** *Right-angle prism*



$$\frac{\alpha}{\beta} = \frac{f_1}{f_2}$$

**Figure 10.8** *Principle of a collimator*




**Figure 10.9** A diffraction grating used with a prism (part of a CD player optical pick-up)

### Diffraction gratings

Diffraction gratings are used to split optical beams and usually comprise a thin plane parallel plate, one surface of which is coated with a partially reflecting film of thin metal with thin slits. Figure 10.9 shows a diffraction grating used with a prism.


The slits are spaced only a few wavelengths apart. When the beam passes through the grating it diffracts at different angles, and appears as a bright main beam with successively less intensive side beams, as shown in Figure 10.10.



**Figure 10.10** Light passing through a diffraction grating

### 1/4 wave plate

When linear polarized light is passed through an anisotropic crystal (Figure 10.11), the polarization plane will be contorted during the traverse of the crystal. The thickness  $d$ , of the crystal required to obtain a contortion of more than  $180^\circ$ , is equal to one wavelength of the light. In order to obtain a contortion of more than  $45^\circ$ , only  $1/4$  of  $d$  is therefore required, and a crystal with this thickness is used in an optical pick-up in a CD player, and is called a **1/4 wave-plate, quarter wave plate, or QWP**.



**Figure 10.11** *Light passing through an anisotropic crystal becomes rotated in polarization*

### The Injection Laser Diode (ILD)

The basic operation of any laser consists of pumping the atoms into a stimulated state, from which electrons can escape and fall to the lower energy state by giving up a photon of the appropriate energy. In a solid-state laser, the input energy populates some of the usually unpopulated bands. When a photon of energy equal to the band gap of the crystal passes through, it stimulates other excited photons to fall in step with it. Thus a small **priming** signal will emerge with other coherent photons.

The laser can be operated in a continuous wave (CW) oscillator mode if the ends of the laser path are optically flat, parallel and reflective, so forming an optical resonant cavity. A spontaneously produced photon will rattle back and forth between the ends, acquiring companions due to stimulated emission.


This stimulated emission can be like an avalanche, completely draining the high-energy states in a rapid burst of energy. On the other hand, certain types of lasers can be produced which will operate in an equilibrium condition, giving up photons at just the input energy pumping rate. The **injection laser diode (ILD)** is such a device.

The material in an injection laser diode is heavily doped so that under forward bias, the region near the junction has a very high concentration of holes and electrons. This produces the inversion condition with a large population of electrons in a high-energy band and a large population of holes in the low-energy band. In this state, the stimulated emission of photons can overcome photon absorption and a net light flux will result.

In operation, the forward current must reach some threshold: beyond which the laser operates with a single 'thread' of light, and the output is relatively stable but low. As the current is increased, light output increases rapidly.

ILD characteristic is highly temperature-sensitive. A small current variation or a modest temperature change can cause the output to rise so rapidly that it destroys the device. A photodiode, monitoring the light output, is commonly used in a feedback loop to overcome this problem.

Like the LED, the ILD must be driven from a current source, rather than a voltage source, to prevent thermal runaway. With a voltage source, as the device junction begins to warm the forward voltage drop decreases, which



**Figure 10.12** *Characteristic of a typical ILD*

tends to increase the current, in turn decreasing the forward voltage drop, and so on until the current tends towards infinity and the device is destroyed.

In addition, the ILD has a tendency to deteriorate with operation. Deterioration is greatly accelerated when operating the ILD outside of its optimum limits. A typical ILD characteristic is shown in Figure 10.12.

### **The ILD with a double heterostructure (DH)**

A very narrow P-N junction layer of GaAs semiconductor is sandwiched between layers of AlGaAs.

The properties of the outer semiconductor layers confine the electrons and holes to the junction layer, leading to an inverted population at a low input current.

### **Quantum aspects of the laser**

A laser (light amplification by stimulated emission of radiation) is a maser (microwave amplification of stimulated emission of radiation), operating at optical frequencies.

Because the operations of masers and lasers are dependent upon quantum processes and interactions, they are known as quantum electronic devices. The laser, for example, is a quantum amplifier for optical frequencies, whereas the maser is a quantum amplifier for microwave frequencies.

Masers and lasers utilize a solid or gaseous active medium, and their operations are dependent on Planck's law:

$$\Delta E = E_2 - E_1 = hf$$

An atom can make discontinuous jumps or transitions from one allowed energy level ( $E_2$ ) to another ( $E_1$ ), accompanied by either the emission or absorption of a photon of electromagnetic radiation at frequency  $f$ .

The energy difference  $E$  is commonly expressed in electronvolts (abbreviation: eV) and:

$$1 \text{ eV} = 1.6 \times 10^{-19} \text{ J}$$

The constant  $h$  is Planck's constant and equals  $6.6262 \times 10^{-34} \text{ Js}$ . The frequency  $f$  (in Hertz) of the radiation and the associated wavelength  $\lambda$  (in metres) are related by the expression:

$$\lambda = \frac{c}{f}$$

where  $c$  (the velocity of light) is  $3 \times 10^8 \text{ ms}^{-1}$ .



## 140 The Compact Disc

Example:

$$\begin{aligned}\Delta E &= E_2 - E_1 = 1.6 \text{ eV} \\ &= 1.6 \times 1.6 \times 10^{-19} \text{ J} \\ &= 2.5632 \times 10^{-19} \text{ J}\end{aligned}$$

But,  $\Delta E$  also equals:

$$hf = h \frac{c}{\lambda}$$

So:

$$\begin{aligned}\lambda &= \frac{hc}{\Delta E} \\ &= \frac{6.6262 \times 10^{-34} \times 3 \times 10^8}{2.5632 \times 10^{-19}} \text{ m} \\ &= 775 \times 10^{-9} \text{ m} \\ &= 775 \text{ nm}\end{aligned}$$


### TOP: T-type Optical Pick-up

The schematic of an optical pick-up of the three-beam type used in CD players is shown in Figure 10.13. This drawing shows the different optical elements composing a pick-up and indicates the laser beam route through the unit.

The laser beam is generated by the laser diode. It passes through the diffraction grating, generating two secondary beams called **side beams**, which are used by a tracking servo circuit to maintain correct tracking of the disc.

The beam enters a polarizing prism (called a **beam splitter**) and only the vertical polarized light passes. The light beam, still divergent at this stage, is converged into a parallel beam by the collimation lens and passed through the 1/4 wave plate where the beam's polarization plane is contorted by 45°. The laser beam is then focused by a simple lens onto the pit surface of the disc. The simple lens is part of a servo-controlled mechanism known as a **2-axis device**.

The beam is reflected by the disc mirrored surface, converged by the 2-axis device lens into a parallel beam, and re-applied to the 1/4 wave plate. Again, the polarization plane of the light is contorted by 45°, so the total amount of contortion becomes 90°, i.e., the vertically polarized laser beam has been twisted to become horizontally polarized.




**Figure 10.13** *A three-beam optical pick-up*


After passing through the collimation lens the laser beam is converged onto the slating surface of the polarizing prism. Now polarized horizontally, the beam is reflected internally by the slanted surface of the prism towards the detector part of the pick-up device.

In the detector part, the cylindrical lens focuses the laser beam in only one plane, onto six photo-detectors in a format shown in Figure 10.14, i.e., four main spot detectors (A, B, C and D) and two side spot detectors (E and F), enabling read-out of the pit information from the disc.

The T-type optical pick-up (TOP) is shown in detail in Figure 10.15.



**Figure 10.14** Showing relative positions of the six photo-detectors of a CD optical pick-up




**Figure 10.15** T-type optical pick-up (TOP)

### FOP: Flat-type Optical Pick-up

Later models use a flat-type optical pick-up (FOP) shown in Figure 10.16. In the FOP a non-polarizing prism is used and no  $1/4$  wave plate. The non-polarizing prism is a half mirror which reflects half of the incident light and lets pass the other half (Figure 10.17).

This means that half of the light passes through the prism and returns after being reflected by the mirror. This secondary beam, 50% of the original, is



**Figure 10.16** Flat-type optical pick-up (FOP)

reflected again for 50% and passed through for 50%, so that the resulting light beam intensity is  $1/2 \times 1/2 = 1/4$  of the original beam (Figure 10.18).

The new principle enables the elimination of the influence of double refraction (i.e. the change of the deflection angle when reflected by the disc surface), caused by discs with mirror impurities.

### 2-axis device

Optical pick-ups contain an actuator for objective lens position control. The compact disc player, due to the absence of any physical contact between the disc and the pick-up device, has to contain auto-focus and auto-tracking functions.

These functions are performed by the focus and tracking servo circuits via the 2-axis device, enabling a movement of the objective lens in two axes: vertically for focus correction and horizontally for track following. Figure 10.19 shows such a 2-axis device construction.

The principle of operation is that of the moving coil in a magnetic field. Two coils, the **focus coil** and the **tracking coil**, are suspended between magnets (Figure 10.20) creating two magnetic fields. A current through either coil, due to the magnetic field, will cause the coil to be subjected to a force, moving the coil in the corresponding direction.




Figure 10.17 Beam splitting in the flat-type optical pick-up






Figure 10.18 Light distribution in FOP



**Figure 10.19** Construction of a 2-axis device, used to focus the laser beam onto the surface of a compact disc




**Figure 10.20** Operating principle of a 2-axis device

# 11

## The Servo Circuits in CD Players


A feedback control circuit is one in which the value of a controlled variable signal is compared with a reference value. The difference between these two signals generates an actuating error signal which may then be applied to the control elements in the control system. Principle is shown in Figure 11.1. The amplified actuating error signal is said to be fed back to the system, thus tending to reduce the difference. Supplementary power for signal amplification is available in such systems.

The two most common types of feedback control systems are **regulators** and **servo circuits**. Fundamentally, both systems are similar, but the choice of systems depends on the nature of reference inputs, the disturbance to which the control is subjected, and the number of integrating elements in the control.



**Figure 11.1** *Feedback control system: block diagram*

Regulators are designed primarily to maintain the controlled variable or system output very nearly equal to a desired value in the presence of output disturbances. Generally, a regulator does not contain any integrating elements. An example of a regulator is shown in Figure 11.2, a stabilized power supply with series regulator.



**Figure 11.2** A voltage regulator

The non-inverting input of a comparator is connected to a reference voltage ( $V_{ref}$ ), and a fraction of the output voltage  $V_{out}$  is fed back to the comparator's inverting input. Closed-loop gain of this circuit equals:

$$G = \frac{R1 + R2}{R2}$$


and, the output voltage equals:

$$V_{out} = G \cdot V_{ref}$$

A servo circuit, on the other hand, is a feedback control system in which the controlled variable is mechanical, usually a displacement or a velocity. Ordinarily in a servo circuit, the reference input is the signal of primary importance; load disturbances, while they may be present, are of secondary importance. Generally, one or more integrating elements are contained in the forward transfer function of the servo circuit.

An example of a servo circuit is shown in Figure 11.3, where a motor is driven at a constant speed. This circuit is a phase-locked system consisting of a phase-frequency detector, an amplifier with a filter, a motor and an encoder. The latter is a device which emits a number of pulses per revolution of the motor shaft. Therefore, the frequency of the encoder signal is directly proportional to the motor speed.





**Figure 11.3** Possible motor speed control servo circuit

Objective of the system is to synchronize the feedback frequency with the reference frequency. This is done by comparing the two signals and correcting the motor velocity according to any difference in frequency or phase.

### Summary of the Servo Circuits in a CD Player

For this explanation, the Sony CDP-101 CD player is used as an example. It uses four distinct servo circuits, as shown in Figure 11.4. These are:


- 1 **focus servo circuit:** this servo circuit controls vertical movement of the 2-axis device and guarantees that the focal point of the laser beam is precisely on the mirror surface of the compact disc
- 2 **tracking servo circuit:** this circuit controls the horizontal movement of the 2-axis device and forces the laser beam to follow the tracks on the compact disc
- 3 **sled servo circuit:** this circuit drives the sled motor which moves the optical block across the compact disc
- 4 **disc motor servo circuit:** this circuit controls the speed of the disc motor, guaranteeing that the optical pick-up follows the compact disc track at a constant linear velocity.

The optical pick-up is the source of the feedback signals for all four servo circuits.

### The Focus Servo Circuit

#### Detection of the correct focal points

The reflected laser beam is directed to the main spot detector (Figure 11.5a), an array of four photodiodes, labelled A, B, C and D. When the focus is OK,



**Figure 11.4** Servo circuits in the CDP-101 compact disc player

the beam falls equally on the four diodes, and the focus error signal:  $(A + C) - (B + D)$  is zero.

On the other hand, when the beam is out of focus (Figures 11.5 b and c), an error signal is generated, because the beam passes through a cylindrical lens, which makes the beam elliptic in shape (Figure 11.6). The resultant focus error signal from the main spot detector:  $(A + C) - (B + D)$  is therefore not zero.

### The focus search circuit




When a disc is first loaded in the player the distance between the 2-axis device and the disc is too large: the focus error signal is zero (as shown in Figure 11.7a) and the focus servo circuit is inactive.

Therefore, a focus search circuit is used which, after the disc is loaded, moves the 2-axis device slowly closer to the disc. Outputs of the four photo-diodes are combined in a different way (i.e.,  $A + B + C + D$ ) to form a radio frequency (RF) signal, which represents the data bits read from the disc. When the RF signal exceeds a threshold level (Figure 11.7b), the focus servo is enabled and now controls the 2-axis device for a zero focus error signal.


### The Tracking Servo Circuit

Figure 11.8 shows the three possible tracking situations as the optical pick-up follows the disc track. In Figure 11.8a and b the main spot detector is not

## 150 The Compact Disc



**Figure 11.5** Detection of correct focus (a) arrangement of optical pick-up: focus is correct (b) and (c) focus is not correct



**Figure 11.6** Showing how elliptical beams are produced by the cylindrical lens, when the optical pick-up is out of focus

correctly tracked, and so one or other of the side spot detectors gives a large output signal as the pit is traversed. In Figure 11.8c, on the other hand, the main spot detector is correctly tracked, and both side spot detectors give small output signals.


Side spot detectors consist of two photo-diodes (E and F) and generate a tracking error signal:

$$TE = E - F$$

The tracking servo acts in such a way that the tracking error signal is as small as possible, i.e., the main spot detector is exactly on the pits of the track. Tracking error, focus error, and resultant focus signals are shown, derived from the optical pick-up's photodiode detectors, in Figure 11.9.


### The Sled Servo Motor

The 2-axis device allows horizontal movement over a limited number of tracks, giving a measure of fine tracking control. Another servo circuit, called the sled servo circuit, is used to move the complete optical unit across the disc for coarse tracking control. It uses the same tracking error signal as the tracking servo of the 2-axis device.




**Figure 11.7** Signals within the focus servo circuit (a) a focus error signal detects when the pick-up is in focus by means of combining the photo-detector outputs as  $(A + C) - (B + D)$ : zero voltage means focus has been obtained (b) a radio frequency signal, obtained by combining the photo-detector outputs as  $(A + B + C + D)$ , must exceed a threshold level before the focus servo is activated


However, the output of the tracking servo circuit is linearly related to the tracking error signal, whereas the output of the sled servo circuit has a built-in hysteresis: Only when the TE signal exceeds a fixed threshold level does the sled servo drive the sled motor. Tracking error and sled motor drive signals are shown in Figure 11.10.



**Figure 11.8** Three possible tracking situations (a) and (b) mis-tracking (c) correctly tracking



**Figure 11.9** Showing how the various error signals are obtained from the photo-detectors of the CD optical pick-up



**Figure 11.10** *Tracking error and sled motor drive signals within the CD player*

### The Disc Motor Servo Circuit

In Chapter 2 we saw how each frame of information on the disc starts with a sync word. One of the functions of the sync words is to control the disc motor.

The sync word frequency is compared against a fixed frequency (derived from a crystal oscillator) in a phase comparator and the motor is driven according to any frequency or phase difference.

As the length of the tracks increases linearly from the inner (lead-in) track to the outer (lead-out) track, the number of frames per track increases in the same respect. This means that the frequency of the sync words also increases, which causes the motor speed to decrease, resulting in a constant linear velocity. The angular velocity typically decreases from 500 rpm (lead-in track) to 200 rpm (lead-out track).

# 12

## Signal Processing

### RF Amplification

The signal that is read from the compact disc and contains the data information is the RF signal, that consists of the sum of signals  $(A + B + C + D)$  from the main spot detector. At this stage, the signal is a weak current signal and requires current-to-voltage conversion, amplification and waveform shaping. The CDP-101 RF amplifier circuit is shown in Figure 12.1. IC402 is a current-to-voltage converter and amplifier stage, while IC403 is an offset amplifier, correcting the offset voltage of the RF signal and delivering the amplified RF signal.

Figure 12.2 shows the waveshaper circuit used in the CDP-101. Because




Figure 12.1 RF amplification circuit of the CDP-101 compact disc player



## 156 The Compact Disc




Figure 12.2 Waveshaping circuit used in the CDP-101




Figure 12.3 Timing diagram of the RF signal before and after waveshaping

the RF signal from the RF amplifier is a heterogeneous signal due to disc irregularities, the waveshaper circuit detects correct zero-cross points of the eye pattern and transforms the signal into a square wave signal. After waveshaping by IC404, the signal is integrated in the feedback loop through a low pass filter circuit to obtain a DC voltage applied to the input, so as to obtain correct slicing of the eye pattern signal.

Figure 12.3 shows a timing diagram of the RF signal before and after waveform shaping.

## Signal Decoding


The block diagram in Figure 12.4 represents the basic circuit blocks of a compact disc player. After waveshaping the RF signal is applied to a phase locked loop (PLL) circuit in order to detect the clock information from the signal which, in turn, synchronizes the data.

Also, the RF signal is applied to an EFM demodulator and associated error stages in order to obtain a demodulated signal. In the CDP-101 a single integrated circuit, the CX7933, performs EFM demodulation; a block diagram is shown in Figure 12.5.


This block diagram shows frame sync detection, fourteen-to-eight demodulation to a parallel 8-bit data output, subcode Q detection and generation by an internal counter and timing generator of the WFCk (write frame clock) and WRfQ (write request) synchronization signals. Figure 12.6 shows the EFM decoding algorithm (for comparison with the encoding scheme in Figure 9.2).

CIRC decoding is performed by a single integrated circuit, the CX7935 (Figure 12.7) on the data stored in the RAM memory. A RAM control IC, the CX7934 (Figure 12.8) is used to control data manipulations between the RAM and the rest of the demodulation stage circuits.

The data are checked, corrected if necessary, and deinterleaved during readout. If incorrigible errors are found, a pointer for this data word is stored in memory and the circuit corrects the data by interpolation. Figure 12.9



**Figure 12.4** Signal decoding within the compact disc player



**Figure 12.5** Block diagram of the CX7933 integrated circuit: which performs EFM demodulation in the CDP-101




Figure 12.6 CIRC decoding algorithm




Figure 12.7 Block diagram of the CX7935 CIRC decoder

shows the complete signal decoding circuit as used in the CDP-101. In the latest Sony CD players, signal decoding is performed by a single integrated circuit, the CX23035, shown in Figure 12.10.

### D/A Converter

The D/A converter follows the signal processing and decoding circuits. Figure 12.11 represents the CX20017 integrated circuit D/A converter as used in Sony CD players. The converter is formed around an integrating dual-slope A/D converter. Two counters, one for the eight most significant and one for the eight least significant bits, control the two constant current sources (which have a ratio:  $I_o/i_o = 256$ ) used for charging the integrator capacitor. Conversion is controlled by the LRCK (left/right clock), BCLK (bit clock) and WCLK (word clock) signals.

Figure 12.12 represents the operating principle: where 16-bit data are loaded into the two 8-bit counters by a latch signal. With data in the counters, no carry signals exist and the current switches are closed. The integration capacitor  $C$  charges with a total current  $I = I_1 + I_2$ .




Figure 12.8 Block diagram of the CX7934 RAM controller





Figure 12.9 Complete signal decoding circuit of the CDP-101



**Figure 12.10** Block diagram of the CX23035 integrated circuit, which performs all signal decoding within the latest Sony CD players






Figure 12.13 shows a practical application of a D/A converter circuit in a CD player.

### 18-Bit Digital Filter/8-Times Oversampling

The CXD-1144 is a digital filter allowing the conversion of 16 bit samples into 18 bit samples with very high precision (Figure 12.14). The remaining ripple in the audible range is reduced to  $\pm 0.00001$  dB. The attenuation is 120 dB and the echo rejection is about 124 dB. Especially the reproduction of pulse-





Figure 12.12 Operating principle of the CX20017 D/A converter






Figure 12.14 CXD-1144 digital filter

shaped tones, such as those of a keyboard or piano, is remarkably improved by enhancing the rising edges of the signal and the high echo rejection.

The digital filter is also used to create oversampling, calculating the intermediate values of the samples. An oversampling of 8 Fs or 352.8 kHz can be achieved. This increase in sampling rate gives an important reduction of quantization noise, which allows a more pure and analytic playback of music. Also a lower order LPF can be used, improving the group delay and linearity in the audio range.

In order to cope with 18 bit and such a high conversion rate great care must be taken in the designing of the D/A converter. To reduce the load imposed on the D/A converter Sony developed an 'Overlapped Staggered D/A Conversion System' (Figure 12.15). The basic idea is to use a digital filter circuit at 8 Fs output, combined with two D/A converters for each channel.





Figure 12.15 Overlapped staggered D/A conversion system

The conversion rate is  $4F_s$ , so the digital filter output is at  $2 \times 4 = 8F_s$  oversampling. The even and odd samples for each channel are applied to separate D/A converters. By adding the output of both DAC, corresponding to the formula:  $(L1 + L2)/2$ , a staircase signal is obtained which corresponds with an  $8F_s$  oversampled output signal. Since the outputs of the two DACs are added continuously a maximum improvement of 3 dB is realised in quantization noise with reduced distortion. The output current is also doubled, improving the S/N ratio of the analog noise by a maximum of 6 dB.

#### *High Density Linear Converter*

Figure 12.16 shows a block diagram of a single bit pulse D/A converter. The digital filter, CXD-1244, uses an internal 45 bit accumulator to perform accurate oversampling needed in the single bit converter. The pulse D/A converter combines a third-order noise shaper and a PLM (Pulse Length Modulation) converter to produce a train of pulses at its output. By using a low-order LPF the analog signal is obtained. A digital sync circuit is inserted between the DAC and the digital filter to prevent jitter of the digital signal.

Compared with conventional D/A converters the high density linear converter provides highly accurate D/A conversion with improved dynamic range and extremely low harmonic distortion.



**Figure 12.16** Single bit pulse D/A converter

# 13

## Outline

The advantages of digital techniques were first realized in the field of magnetic recording. Analog magnetic recording creates significant deterioration of the original sound: using analog techniques, for example, it is difficult to obtain a flat frequency response at all signal levels. Further, signal-to-noise ratio is limited to some 70 dB, the sound is deteriorated by speed variations of the recorder mechanism, there exist crosstalk and print-through problems, and any additional copying deteriorates the characteristics even further. In addition to this, to keep the equipment within close specifications, as required in a professional environment, frequent and costly realignment and maintenance are required.

Digital magnetic recording, on the other hand, virtually solves all of these drawbacks. Recording of digital data, however, presents some specific problems:

- required bandwidth is increased dramatically compared to the original signal
- specific codes must be used for recording (in contrast to the simple data codes mentioned before)
- error-correction data must be recorded
- synchronization of the recorded data stream is necessary to allow for reconstruction of the recorded words
- in contrast to analog recordings, editing is very complicated and requires complex circuits. For tape-cut editing, common practice in the analog recording field, a very strong error-correction scheme together with interleaving are needed. Even then, very careful handling is a must; for instance, the tape cannot be touched with bare fingers.

Several different techniques have been developed, outlined in the following chapters.

# 14

## PCM Adapters According to EIAJ

PCM adapters or processors convert the audio information into a pseudo-video signal for subsequent recording on a video recorder. The EIAJ standard was basically established as a format for consumer applications. The basic specifications of the EIAJ standard are listed in Table 14.1.

Sony processors such as the PCM-F1, PCM-701ES and PCM-501ES also have a 16-bit recording mode and have become very popular in the professional recording field. 16-bit mode recordings can be played back on either 16-bit or 14-bit machines. The PCM-F1 for instance has the following specification:

Frequency response:	10 – 20,000 Hz $\pm$ 0.5 dB
Dynamic range:	>86 dB (14-bit mode) >90 dB (16-bit mode)
Harmonic distortion:	<0.007% (14-bit mode) <0.005% (16-bit mode)
Wow and flutter:	Unmeasurable

The EIAJ format's error-correction system is called **b-adjacent coding**, a system which adds two error-correction words, called P and Q, to six data words. In the 16-bit mode the Q word is not used, and the space available is taken by the extra bits of the signal information. Therefore, the error-correction capability of the 16-bit format is slightly inferior to the 14-bit format. In practice, however, as a good concealment system takes care of possible uncorrected errors to the same extent as in the 14-bit mode, this is of no real consequence. A comparison of error-correction capabilities of EIAJ format processors and the PCM-F1 16-bit mode is given in Table 14.2. Time corresponding to a horizontal video line is given the symbol, H.

**Table 14.1** *EIAJ specification for digital audio tape recorders*

Item	Specification
Number of channels	2 (CH-1 = left, CH-2 = right)
Number of bits	14 bits/word
Quantization	linear
Digital code	2's complement
Modulation	non-return to zero
Sampling frequency	44.056 kHz (NTSC)/44.1 kHz (PAL)
Bit transmission rate	$2.634 \times 10^6$ bit s <sup>-1</sup> (NTSC)/ $2.625 \times 10^6$ bit s <sup>-1</sup> (PAL)
Video signal	NTSC standard/PAL standard

**Table 14.2** *Error-correction capabilities of EIAJ and PCM-F1 format audio digital tape recorders*

	Error-correction word	Error-correction capability	Range of compensation (concealment)	Muting condition
EIAJ 14-bit format	P, Q	Burst error less than 32H	32H–95H	Burst error more than 95H
PCM-F1 16-bit format	P only	Burst error less than 16H	16H–95H	Burst error more than 95H

## A/D Conversion

The EIAJ format specifies a 14-bit linear conversion system which allows a theoretical dynamic range of 86 dB. Pre-emphasis can be applied, with turn-over frequencies of 3.18 kHz and 10.6 kHz (i.e., the same as in the CD format). Characteristics of the EIAJ format pre-emphasis and de-emphasis are shown in Figure 14.1.

When a recording is made with pre-emphasis switched in, a control signal on the tape records this fact. During playback, switching of the de-emphasis circuit then occurs automatically.

The control signal also, among other things, contains a 'copy protect' bit which, when set, prevents copies being made of a recording.




Figure 14.1 EIAJ format pre-emphasis and de-emphasis characteristics

## Encoding System

The processor samples the left (L) and right (R) audio channels alternately and, after undergoing A/D conversion, data are fed to six input terminals of the encoder, in the sequence shown in Figure 14.2.

Two error-correction words P and Q are generated with an exclusive-or operation and a matrix operation. Then, the input data, together with the derived P and Q words, are **interleaved** by using time delays formed by RAM memory stages. The delays are in multiples of a horizontal video line time H, and one word is encoded through each input terminal of the encoder in time H.

Starting at time 0H, consider input word L0. As this word undergoes no delay, it appears at time 0H at the output A. Input word R0, on the other hand, will not appear at the output until time 16H. Hence during the time 0H to 15H, data line A comprises the sequence of words:

L0 L3 L6 L9 L12 L15 ... L45

while nothing comes out of the other lines.


At time 16H, line B starts to output data. Hence the data at lines A and B is:

Line A L48

Line B R0

Still, nothing comes out from the other lines.





B-adjacent code generator

Figure 14.2 Encoding system for a digital audio tape recorder

## 176 Digital Audio Recording Systems

Similarly, at time 32H, line C starts to output data and we have the following:

Line A L96

Line B R48

Line C L1

In general, for  $nH$ , data outputs at lines A, B and C are as follows:

Line A  $L_3n$

Line B  $R_3(n - 16)$

Line C  $L_3(n - 32) + 1$

As the process continues, the output data at lines A–H are as shown in Figure 14.3. Note that after this operation, R0 instead of L0 is paired with L48. Similarly, R1, R2 are paired with L49 and L50 respectively.

When data are recorded on the magnetic tape in this way, errors due to dropouts are effectively avoided. Even when a large dropout occurs and

Line A    Line B	
L48	R0
At Time = 16H	

A	B	C
L96	R48	L1
At Time = 32H		

A	B	C	D
L144	R96	L49	R1
At Time = 48H			


A	B	C	D	E	F
L240	R192	L145	R97	L50	R2
At Time = 80H					


A	B	C	D	E	F	G	H	I
L336	R288	L241	R193	L146	R98	P48	S0	CRCC
At Time = 112H								

**Figure 14.3** Output data from the encoder, at various times

• **14-Bit EIAJ Standard Format**  
Interleave method



• **16-Bit Format (PCM-F1)**  
Interleave method



$\underbrace{L_0 \quad R_0 \quad L_1 \quad R_1 \quad L_2 \quad R_2 \quad P_0}_{\text{① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩ ⑪ ⑫ ⑬ ⑭}}$ 
 The information of bits 15 and 16 of each data block will be stored in S0.

Figure 14.4 Interleaving formats of EIAJ and PCM-F1 systems

significant numbers of data words are lost, the spread of words over a wide area due to interleaving means that many words will still be available. Error correction can be applied in most cases of dropout.

Figure 14.4 shows the interleave formats of the EIAJ 14-bit system and the PCM-F1 16-bit system. In the 16-bit format, Q error correction words are not used. Instead, S words, which contain bits 15 and 16 of six data words and their corresponding P word, are recorded.

A significant amount of redundancy is incorporated into the data signal to ensure error detection and correction. As a percentage, redundancy is calculated as the ratio of the number of error-correction bits to the number of audio bits plus error-correction bits:

a) **14-bit mode**

There are  $6 \times 14 = 84$  audio data bits and  $(2 \times 14) + 16 = 44$  error correction and detection bits, so redundancy R, is:

$$\frac{44}{44 + 84} = \frac{44}{128} = 34.4\%$$

b) **16-bit mode**

There are  $6 \times 16 = 96$  data bits and  $14 + 16 = 30$  error correction and detection bits, so redundancy R, is:

$$\frac{30}{30 + 96} = \frac{30}{126} = 23.8\%$$

After interleaving, the CRCC (cyclic redundancy check code) error-detection word is added to complete one data block. Then, the whole data block is turned into a video signal prior to recording. During playback, **de-interleaving** is applied to recreate the original data.

## Video Format


The encoded data signals are modulated on a pseudo-video signal. One frame of a PAL video signal has 625 lines, comprising two fields of 312.5 lines each. NTSC video signals have a 525-line frame, with fields of 262.5 lines. Each field is preceded by vertical synchronization pulses, while each line is preceded by a horizontal sync pulse.

### Format in one field

At field level, the data are coded as shown in Figure 14.5a, where the data lines are preceded with one line that contains a control word C.

This control word is illustrated in Figure 14.5b, and comprises:

- a) cueing signal: a repetition of fourteen '1100' signals for detection purposes
- b) ID: content identification, normally not used
- c) address: not used
- d) control: only the last four bits have been defined, as listed in Table 14.3
- e) CRCC: a 16-bit error word on all the preceding data



**Figure 14.5** Video format of encoded data (a) in each field (b) the control word C

**Table 14.3** *Allocated control bits of the control word C*

BIT	MEANING	CODE
11	Copy-prohibiting	0 = none
12	P-correction identification	0 = present
13	Q-correction identification	0 = present
14	Pre-emphasis identification	0 = present


**Format in one line**

One horizontal line, shown in Figure 14.6, comprises 168 bits, 128 bits of which are data bits. This means that the PAL data rate is:

$$\frac{168}{64 \mu\text{s}} = 2.625 \times 10^6 \text{ bit s}^{-1}$$

and data rate in NTSC is:

$$\frac{168}{63.6 \mu\text{s}} = 2.643 \times 10^6 \text{ bit s}^{-1}$$

**Figure 14.6** *Video format as number of bits in a line***Basic Circuitry of a PCM Processor**

A block diagram of a PCM processor, such as the Sony PCM-F1, is given in Figure 14.7, and comprises:

- a recording circuit (A), which receives the analog audio input signals and, after processing, outputs a pseudo-video signal for recording using a standard video recorder
- a playback circuit (B), which receives the played back video signal from the video recorder and outputs, after processing, the reconstructed analog audio signal
- a support circuit (C), which provides the necessary timing and control signals for both processing circuits.




Figure 14.7 Block diagram of a PCM processor system




Figure 14.8 Input stage of the recording circuit

## The Recording Circuit

### Input circuit

A block diagram of the input stage of the recording circuit is shown in Figure 14.8, where the analog audio input signals are fed through an anti-aliasing, low-pass filter (LPF) which limits the bandwidth of the signal to half the sampling frequency.

These audio signals, analog and continuous in time, are transformed in the sample and hold (S/H) into analog signals which are discrete in time.

The analog-to-digital converter (A/D) converts the analog signals into digital ones (discrete in value *and* in time).

The parallel output signals are converted into a serial bit stream by a parallel to serial (P/S) circuit and both channels are combined in a multiplexer (MUX) which outputs a serial digital data bit stream.

### The signal processor


Figure 14.9 shows a block diagram of the signal processing stage of the recording circuit.

An error-protection circuit calculates an error-detection and correction word based upon the information contained in the input signal. Error-detection and corrections words are inserted at regular intervals, into the signal, giving a measure of protection against single-bit errors.

To protect the information against burst errors (caused by, say, tape drop-out), the signal is interleaved. This effectively converts burst errors into single-bit errors which can be corrected.

A time base corrector (TBC) compresses the signal in time, so that it matches the characteristics of a standard video signal. Frequently, a RAM arranged as a first-in-first-out (FIFO) buffer is used as a TBC.

A digital-to-video converter (DVC) finally adds the necessary horizontal and vertical synchronization signals and outputs a pseudo-video signal which can be recorded using a video recorder.




**Figure 14.9** *Signal processing stage of the recording circuit*

## The Playback Circuit

### The signal processor

A block diagram of the signal processing stage of the playback circuit is shown in Figure 14.10, where a video-to-digital converter (V/D) isolates the digital data from the horizontal and vertical synchronization signals.

A time base corrector (TBC) like that of the recording circuit; a FIFO buffer, receives the input signals. The horizontal synchronization signal is used as a clock signal for reading in the digital data while the processor's



**Figure 14.10** *Signal processing stage of the playback circuit*

## 182 Digital Audio Recording Systems

system clock (crystal controlled) controls data output. The TBC serves two main purposes:

- 1 removal of possible remaining jitter on the input signals, caused by unstable video recorder playback
- 2 time expansion of the video signal into a continuous data stream.

A de-interleave circuit rearranges the data bits into their correct sequence, at the same time converting possible burst errors into single-bit errors.

An error-correction circuit uses the redundant information, added to the signal in the error-protection circuit as recording, to detect and correct single-bit errors. A burst error exceeding the correction capability of the system will be concealed (by interpolation, previous word hold or simple muting means).

Output of this stage is a digital serial data stream, ready to be converted into analog.


### The output stage

The output stage of the playback circuit is shown in a block diagram in Figure 14.11.

A demultiplexer (DEMUX) separates the digital input signal into left and right channels. A serial to parallel converter (S/P) combines the serial data bits into parallel data words which are then converted into analog signals by a digital-to-analog converter (D/A). Output of the D/A converter is a pulse amplitude modulated (PAM) signal.

An aperture control circuit (AC), a sample and hold, removes glitches from the signal and corrects frequency response.

A low-pass filter (LPF) performs final reconstruction by removing images from the audio signal (for this reason, this type of filter is sometimes referred to as an **anti-imaging filter**).



**Figure 14.11** Output stage of the playback circuit



# 15

## PCM-1600/1610 Format

In professional recording studios, the PCM-1600/1610 format appears to be the de facto standard for compact disc mastering, as virtually all compact discs are mastered on either PCM-1610 or PCM-1630 processors. The format was established as a two-channel studio recording standard with extremely strong error-correction capabilities to enable electronic editing.

Basically, a professional PCM processor, such as the PCM-1610, has the same principles of operation as an EIAJ processor. There are, however, differences in the error-correction techniques used. Table 15.1 summarizes the main points of the PCM-1600/1610 format.

### Encoding Scheme

The error-correction system adopted in the PCM-1600/1610 format was developed by Sony and is called 'crossword code'. In the crossword system, error-correction and detection words are added as shown in Figure 15.1,

**Table 15.1** *PCM-1600/1610 format specification*

Item	Specification
Number of channels	2(CH-1 = left, CH-2 = right)
Number of bits	16 bits/word (per channel)
Quantization	linear
Digital code	2's complement
Sampling frequency	44.056 kHz or 44.1 kHz
Bit transmission rate	$3.5795$ or $3.5831 \times 10^6$ bit s <sup>-1</sup>
Video signal	NTSC standard

R1	L2	R3	C1
P1	P2	P3	C3
L1	R2	L3	C2

**Figure 15.1** Illustration of the crossword code error-detection system

where a block of six audio data words (three left channel words and three right channel words) is linked with three parity words and three CRCC words.

The parity words are generated by an exclusive OR function performed on the left and right channel words, where

$$P_n = L_n + R_n$$

The CRCC words are generated by the polynomial:

$$X^{16} + X^{12} + X^5 + 1$$

	1st BLOCK				2nd BLOCK				3rd BLOCK				34th BLOCK				35th BLOCK			
1 LINE	R1	L2	R3	C1	L4	R5	L6	C4	R7	L8	R9	C7	L100	R101	L102	C100	R103	L104	R105	C103
2 LINE	P1	P2	P3	C3	P4	P5	P6	C6	P7	P8	P9	C9	P100	P101	P102	C102	P103	P104	P105	C105
3 LINE	L1	R2	L3	C2	R4	L5	R6	C5	L7	R8	L9	C8	R100	L101	R102	C101	L103	R104	L105	C104

$$P_n = R_n + L_n$$

$$C = \text{CRCC}$$

$$1 \text{ INTERLEAVE} = 35\text{H}$$


**Figure 15.2** Interleaving data prior to recording

As a basic block consists of six audio words, and six error-correction and detection words, redundancy is 50%.


Figure 15.2 shows how data are then interleaved. A total of 420 interleaved words, i.e., 105 L-data words, 105 R-data words, 105 P-data words and 105 CRCC words make one interleave, recorded as 35 horizontal lines. A complete video field therefore stores some seven interleaves (i.e., 245 data lines).

## Video Format

The format of one video line is shown in Figure 15.3. This corresponds to the first 12 words of line 1 of Figure 15.2. As a complete interleave takes 35 video



**Figure 15.3** *Format of a single video line*



**Figure 15.4** *Showing a complete video interleave of data, along with skew bits*

**Table 15.2** *Settings and meanings of the two skew bits*

Skew bit (1st line)	Skew bit (2nd line)	Sampling frequency (kHz)	Emphasis ON/OFF
0	0	44.1	ON
0	1	44.056	ON
1	0	44.1	OFF
1	1	44.056	OFF

lines, the first 12 words of line 2 of Figure 15.2 will be written in the 36th line following that shown in Figure 15.3, and so on.

The 129th bit of each horizontal line is a **skew** bit, used to contain data regarding sampling frequency and emphasis. The skew bit of the first and second horizontal lines is set as shown in Table 15.2; the skew bits of the other horizontal lines are always 1. Use of the skew bit is illustrated in Figure 15.4, where signals corresponding to a complete interleave are shown.

# 16

## Video 8 PCM-Format

In 1985, a new consumer video format was launched, called Video 8. Sony expects this format to replace gradually the older Betamax and VHS consumer video formats. The video 8 format uses a much smaller cassette than older video formats, enabling construction of very small video recorders. Almost all major manufacturers in the field of consumer electronics are supporting this new format.

Audio information can be recorded on Video 8 recorders as either an FM signal, along with the picture, or as a PCM signal written in a section of the tape where no picture information is recorded. In some recorders, however, PCM data can be recorded in the video area, instead of the picture signal. By doing this, six channels of high-quality audio can be recorded on a tape.

The specification of the Video 8 PCM standard is summarized in Table 16.1.

### **A/D–D/A Conversion**

As only 8 bits per channel are used, audio characteristics would be poor if special measures were not taken. These measures include:

- audio compression and expansion for noise-reduction purposes
- 10-bit sampling
- non-linear quantization by 10-bit to 8-bit compression and expansion

and are illustrated, in a block diagram, in Figure 16.1. Characteristic of the noise-reduction (NR) system is shown in Figure 16.2, while Figure 16.3 shows the characteristic of the non-linear encoder. The upper limit of the frequency response of the system is limited to a maximum of 15,625 Hz, i.e., half of the sampling frequency of 31,250 Hz.



**Photo 16.1** Video 8 cassette

**Table 16.1** Specification of Video 8 format

Item	Specification
Number of channels	3 (CH-1 = left, CH-2 = right)
Number of bits	8 bits/word
Quantization	linear
Digital code	2's complement
Modulation	bi-phase (FSK) 2.9 MHz, 5.8 MHz
Sampling frequency	31,250 kHz (PAL)/ 31,468.53 Hz (NTSC)
Bit transmission rate	$5.8 \times 10^6$ bit s <sup>-1</sup>
Video signal	PAL/NTSC
Number of PCM tracks	6




Figure 16.1 Block diagram of Video 8 signal processing





Figure 16.2 Noise reduction system characteristic

With these measures, typical audio characteristics of Video 8 PCM audio recordings are:

- frequency response: 20–15,000 Hz
- dynamic range: more than 88 dB
- sampling frequency: 31.5 kHz
- quantization: 8-bit non-linear
- wow and flutter: less than 0.005%

### Description of the Format

One track on the section of tape used to record PCM audio information holds 157 blocks of data for a PAL machine, 132 blocks for an NTSC machine. Each block contains eight 8-bit data words, two 8-bit parity words (P and Q), one 16-bit error-detection word, one 8-bit address word, and three sync bits.



$Y = X$	$(0 \leq X < 16)$
$Y = \lfloor X/2 \rfloor + 8$	$(16 \leq X < 64)$
$Y = \lfloor X/4 \rfloor + 24$	$(64 \leq X < 320)$
$Y = \lfloor X/8 \rfloor + 64$	$(320 \leq X \leq 511)$

X: Input absolute value

Y: Output absolute value

(b) Conversion algorithm

Encode law	Input data	Output data
10bits $\rightarrow$ 10bits	0—15	0—15
10bits $\rightarrow$ 9bits	16—63	16—39
10bits $\rightarrow$ 8bits	64—319	40—103
10bits $\rightarrow$ 7bits	320—511	104—127

(c)

Figure 16.3 Non-linear encoder characteristic

So one block comprises 107 bits and each track comprises 16,799 bits in PAL mode, 14,017 bits in NTSC mode.

Error-correction and detection words are added as shown in Figure 16.4.

The error-correction code adopted for Video 8 PCM is a modified cross-interleaved code (MCIC) in which the code is composed of blocks which are related to the video fields. The version used is called **improved MCIC**, in which ICIC, the initial value, necessary for parity calculation, can be any value and has numerous applications, such as identification words.

As eight audio data words are combined with two parity words, the Video 8 system is often called an 8w-2p coding system. A CRCC word is also added as an error detector.

In encoding, the sequence can be expressed as follows:

### P – parity

$$P(n) = Q(n + D) + \sum_{i=2}^8 W_{i-2}(n + iD)$$





Figure 16.4 Error-correction encoding prior to recording

### Q – parity sequence

$$Q(n + D) = P(n + d) + \sum_{i=2}^8 W_{i-2}[n + i(D - d) + d]$$

where  $n$  is the block number ( $0 < n < 157$  for PAL recordings, and  $0 < n < 132$  for NTSC),  $D$  is the delay of the  $P$  parity sequence which converts a burst error into random errors (17 for PAL, 1514 for NTSC) and  $d$  is the  $Q$  parity sequence delay behind the  $P$  parity sequence (3 for PAL and 32 for NTSC).





**Figure 16.5** Data interleaving in Video 8 PCM

The error-detection code is a 16-bit CRCC and its polynomial is given by:

$$g(X) = X^{16} + X^{12} + X^5 + 1$$

In decoding, the pointer method is used, which corrects an erroneous word using a pointer flag.

The redundancy of the Video 8 format is as follows:

there are  $8 \times 8 = 64$  audio data bits and,  
 $(2 \times 8) + 16 = 32$  error-correction and detection bits, plus  
 $1 \times 8 = 8$  address bits

so, redundancy R, is:

$$\frac{32 + 8}{32 + 8 + 64} = 38.5\%$$


Words are interleaved onto the PCM section of tape as shown in Figure 16.5.

# 17

## Digital Audio Tape (DAT) Format

Although digital audio processors have been developed and used for many years, using conventional video recorders to store high-quality audio information, it is inevitable that some form of tape mechanism be required to do the job in a more compact way. Two main formats have been specified.

The first format, known as **rotary head, digital audio tape (R-DAT)**, is based on the same rotary head principle as a video recorder, and so has the same limitations in portability. The second format, known as **stationary head, digital audio tape (S-DAT)**, is currently in development and will use a stationary head technique mechanically similar to analog audio recorders.



**Photo 17.1** *DAT mechanism*




Figure 17.1

## R-DAT

One important difference between standard video recorder and R-DAT techniques is that in a video recorder the recorded signal is continuous; two heads on the drum make contact with the tape for 180° each (i.e., the system is said to have a 180° wrap angle, as shown in Figure 17.1a), or 221° each (a 221° wrap angle, as in Figure 17.1b). In the R-DAT system, where the digital audio signal is time-compressed meaning that the heads only need to make contact with the tape for a smaller proportion of the time (actually 50%), a smaller wrap angle may be used (90° – as shown in Figure 17.1c).

This means only a short length of tape is in contact with the drum at any one time. Tape damage is consequently reduced, and only a low tape tension is necessary with resultant increase in head life.

The R-DAT standard specifies three sampling frequencies:

- 48 kHz; this frequency is mandatory and is used for recording and playback.
- 44.1 kHz; this frequency, which is the same as for CD, is used for playback of pre-recorded tapes only.
- 32 kHz; this frequency is optional and three modes are provided.
- 32 kHz has been selected as it corresponds with the broadcast standard.

Quantization:

- A 16-bit linear quantization is the standard for all three sampling rates.
- A 12-bit non-linear quantization is provided for special applications such as long play mode at reduced drum speed, 1000 rpm (–mode III) and U-channel applications.

Figure 17.2 shows a simplified R-DAT track pattern.

Table 17.1

Mode		DAT (REC/PB mode)				Pre-recorded tape (PB only)	
Item	Standard	Option 1	Option 2	Option 3	Normal track	Wide track	
Channel number (CH)	2	2	2	4	2	2	
Sampling frequency (kHz)	48	32	32	32	44.1		
Quantization bit number (bit)	16 (Linear)	16 (Linear)	12 (Nonlinear)	12 (Nonlinear)	16 (Linear)	16 (Linear)	
Linear recording density (Kbit in <sup>-1</sup> )	61.0	61.0			61.0	61.1	
Surface recording density (Mbit in <sup>-2</sup> )	114	114			114	76	
Transmission rate (Mbit s <sup>-1</sup> )	2.46	2.46	1.23	2.46	2.46		
Subcode capacity (Kbit s <sup>-1</sup> )	273.1	273.1	136.5	273.1	273.1		
Modulation system	8–10 conversion						
Correction system	Double Reed-Solomon code						
Tracking system	Area sharing ATF						
Cassette size (mm)	73 × 54 × 10.5						
Recording time (min)	120	120	240	120	120	80	
Tape width (mm)	3.81						
Tape type	Metal powder						
Tape thickness (μm)	13 ± 1 μm						
Tape speed (mm s <sup>-1</sup> )	8.15	8.15	4.075	8.15	8.15	12.225	
Track pitch (μm)	13.591				13.591	20.41	
Track angle	6°22'59.5"						
Standard drum specifications	30 mm diameter 90° wrap						
Drum rotations (rpm)	2000		1000	2000	2000		
Relative speed m s <sup>-1</sup>	3.133		1.567	3.133	3.133	3.129	
Head azimuth angle	±20°						




Figure 17.2 Simplified R-DAT track pattern




Figure 17.3 Overwrite recording is used to ensure each track is as narrow as possible and no guard-band is required

The standard track width is  $13.591\mu\text{m}$ , the track length is  $23.5\text{mm}$ , the linear tape speed is  $8.1\text{mm s}^{-1}$ . The tape speed of the analog compact cassette (TM) is  $47.6\text{mm s}^{-1}$ . This results in a packing density of  $114\text{Mbits s}^{-1}\text{m}^{-2}$ . See Table 17.1.

The R-DAT format specifies a track width of only  $13.6\mu\text{m}$ , but the head width is about 1.5 times this value, around  $20\mu\text{m}$ . A procedure known as **overwrite recording** is used, where one head partially records over the track recorded by the previous head, illustrated in Figure 17.3. This means that as

Table 17.2


1	2	3 (SUB)	4	5	6	7	8	9 (PCM)	10	11	12	13	14 (SUB)	15	16	
Frequency								*Angle (deg)	Number of blocks				Time (μs)			
1	MARGIN						1/2 f <sub>ch</sub>	5.051	11				420.9			
2	PLL (SUB)						1/2 f <sub>ch</sub>	0.918	2				76.5			
3	SUB-1							3.673	8				306.1			
4	POST AMBLE						1/2 f <sub>ch</sub>	0.459	1				38.3			
5	IBG						1/6 f <sub>ch</sub>	1.378	3				114.8			
6	ATF							2.296	5				191.3			
7	IBG						1/6 f <sub>ch</sub>	1.378	3				114.8			
8	PLL (PCM)						1/2 f <sub>ch</sub>	0.918	2				76.5			
9	PCM							58.776	128				4898.0			
10	IBG						1/6 f <sub>ch</sub>	1.378	3				114.8			
11	ATF							2.296	5				191.3			
12	IBG						1/6 f <sub>ch</sub>	1.378	3				114.8			
13	PLL (SUB)						1/2 f <sub>ch</sub>	0.918	2				76.5			
14	SUB-2							3.673	8				306.1			
15	POST AMBLE						1/2 f <sub>ch</sub>	0.459	1				38.3			
16	MARGIN						1/2 f <sub>ch</sub>	5.051	11				420.9			
Total								90	196				7500			

Recording density  $61.0 \text{ Kbit in}^{-1}$  $f_{ch}$  9.408 MHz\*Values for 30 mm diameter,  $90^\circ$  wrap angle, 2000 rpm cylinder

much tape as possible is used – rotating head recorders without this overwrite record facility must leave a guardband between each track on the tape. Because of this, recorders using overwrite recording techniques are sometimes known as **guard-bandless**. To prevent crosstalk on playback (as each head is wide enough to pick up all of its own track and half of the next), the heads are set at azimuth angles of  $\pm 20^\circ$ . This enables, as will be explained later, automatic track following (ATF).

These overwrite record and head azimuth techniques are fairly standard approaches to rotating head video recording, and are used specifically to increase the recording density.

Figure 17.4 shows the R-DAT track format on the tape, while Table 17.2 shows the track contents. Table 17.2 lists each part of a track and gives the recording angle, recording period and number of blocks allocated to each part. Frequencies of these blocks which are not of a digital-data form are also listed.



**Figure 17.4** *R-DAT tape track format*

As specified in the standard, a head drum with 30 mm diameter is applied and rotates at a 2000 rpm speed. However, in future applications smaller drums with appropriate speeds can be used. At this size and speed, the drum has a resistance to external disturbances similar to that of a gyroscope.


Under these conditions, the  $2.46 \text{ Mbit s}^{-1}$  signal to be recorded, which includes audio as well as many other types of data, is compressed by a factor of 3 and processed at  $7.5 \text{ Mbit s}^{-1}$ . This enables the signal to be recorded continuously.

In order to overcome the well-known low frequency problems of coupling transformers in the record/playback head, an 8/10 modulation channel code converts the 8-bit signals to 10-bit signals.

This channel coding also gives the benefit of reducing the range of wave lengths to be recorded. The resultant maximum wave length is only four times the minimum wave length. This allows overwriting, eliminating the need for a separate erase head.

The track outline is given in Figure 17.4. Each helical track is divided into seven areas, separated by interblock gaps. As can be seen, each track has one PCM area, containing the modulated digital information (audio data and error codes), and is 128 blocks of 288 bits long. Table 17.2 lists all track parts of a track.

The PCM area is separated from the other areas by an IBG (inter-block






**Table 17.4** *Bit assignment of ID-codes*

Usage		Bit assignment	
ID1	Emphasis	B5	B4
		0	0: Off
		0	1: 50/15 $\mu$ sec
ID2	Sampling frequency	B7	B6
		0	0: 48 kHz
		0	1: 44.1 kHz
		0	1: 32 kHz
ID3	Number of channel	B5	B4
		0	0: 2 channels
		0	1: 4 channels
ID4	Quantization	B7	B6
		0	0: 16 bits linear
		0	1: 12 bits non linear
ID5	Track pitch	B5	B4
		0	0: Permitted
		1	0: Prohibited
		1	1: permitted only for the first generation
ID7	Pack	B5	B4: Pack contents


and the inter-block gaps around the ATF signals (which means that the PCM and subcode information can be overwritten independently without interference to surrounding areas). Parts are recorded successively along the track.

The PCM area format is shown in Table 17.3. PCM and subcode parts comprise similar data blocks, shown in Figure 17.5. Each block is 288 bits long.

Each block comprises 8 synchronization bits, the identification word (W1, 8 bit), the block address word (W2, 8 bit), 8-bit parity word and 256 bits ( $32 \times 8$ -bit symbol) data. The ID-code W1 contains control signals related to the main data. Table 17.4 shows the bit assignment of the ID codes. The W2 contains the block address. The MSB (most significant bit) of the W2 word defines whether the data block is of PCM or subcode form. Where the MSB is zero, the block consists of PCM audio data, and the remainder of word W2, i.e., seven bits, gives the block address within the track. The 7 bits therefore identify the absolute block address (as  $2^7$  is 128).



**Figure 17.5** PCM and subcode data blocks



**Figure 17.6** Subcode data blocks


On the other hand, when the MSB of word W2 is 1, the block is of subcode form and data bits in the word are as shown in Figure 17.6, where a further 3 bits are used to extend the W1 word subcode identity code, and the four least significant bits give the block address.

$$P = W1 (+) W2$$

## Automatic Track Following

The ATF track pattern is illustrated in Figure 17.7. One data frame is completed in two tracks and one ATF pattern completed in two frames (four tracks). Each frame has an A and a B track. A tracks are recorded by the head with  $+20^\circ$  azimuth and B tracks are recorded by the head with  $-20^\circ$  azimuth.

**ATF.**



**Figure 17.7** *ATF-signal frequencies*

As shown in Figure 17.7, the ATF uses a pilot signal  $f_1$ ; sync signal 1,  $f_2$ ; sync signal 2,  $f_3$ ; and erase signal,  $f_4$ . When the head passes along the track in the direction of the arrow (V-head) and detects an  $f_2$  or  $f_3$  signal, the adjacent 6 pilot signals  $f_1$  on both sides are immediately compared, which results in a correction of the tracking when necessary.

The  $f_2$  and  $f_3$  signals thus act as sync signals to start the ATF servo operation.

The  $f_1$  signal, a low frequency signal, i.e., 130.67 kHz, is used as low frequency signals are not affected by the azimuth setting, so crosstalk can be picked up and detected from both sides. The pilot signal  $f_1$  is positioned so not to overlap through the head scans across three successive tracks.

## Error-Correction

As with any digital recording format, the error-detection and -correction scheme is very important. It must detect and correct the digital audio data, as well as subcodes, ID codes and other auxiliary data.

Types of errors that must be corrected are burst errors: dropouts caused by dust, scratches, and head clogging, and random errors: caused by crosstalk from an adjacent track, traces of an imperfectly erased or overwritten signal, or mechanical instability.

### Error-correction strategy

In common with other digital audio systems, R-DAT uses a significant amount of error-correction coding to allow error-free replay of recorded information. The error-correction code used is a double-encoded Reed-Solomon code.

These two Reed-Solomon codes produce C1 (32,28) and C2 (32,26) parity symbols, which are calculated on  $G_F(2^8)$  by the polynomial:


$$g(x) = x^8 + x^4 + x^3 + x^2 + 1$$

C1 is interleaved on two neighbouring blocks, while C2 is interleaved on one entire track of PCM data every 4 blocks. See Figure 17.8 for the interleaving format.

In order to perform C1  $\rightleftharpoons$  C2 decoding/encoding, one track worth of data must be stored in memory.

One track contains 128 blocks consisting of 4096 ( $32 \times 128$ ) symbols. Of these, 1184 symbols (512 symbols C1 parity and 672 symbols C2 parity) are used for error correction, leaving 2912 data symbols ( $24 \times 104$ ).

In fact, C1 encoding adds 4 symbols of parity to the 28 data symbols: C1 (32,28); while C2 encoding adds 6 symbols of parity to every 26 PCM data symbols: C2 (32, 26).



**Figure 17.8** ECC interleaving format

The main data allocation is shown in Figure 17.9.

This double-Reed-Solomon code gives the format a powerful correction capability for random errors.

### PCM data interleave

In order to cope with burst errors, i.e., head clogging, tape dropouts, etc., PCM data is interleaved over two tracks called one frame, effectively turning burst errors into random errors which are correctable using the Reed-Solomon technique already described.

To interleave the PCM data, the contents of two tracks has first to be processed in a memory. The memory size required for one PCM interleave

	0	1	2	3		51	52	53		75	76	77		126	127	
0	D <sub>0,0</sub>	D <sub>1,0</sub>	D <sub>2,0</sub>	D <sub>3,0</sub>		D <sub>51,0</sub>	Q <sub>52,0</sub>	Q <sub>53,0</sub>		Q <sub>75,0</sub>	D <sub>76,0</sub>	D <sub>77,0</sub>		D <sub>126,0</sub>	D <sub>127,0</sub>	
1	D <sub>0,1</sub>	D <sub>1,1</sub>	D <sub>2,1</sub>	D <sub>3,1</sub>		D <sub>51,1</sub>	Q <sub>52,1</sub>	Q <sub>53,1</sub>		Q <sub>75,1</sub>	D <sub>76,1</sub>	D <sub>77,1</sub>		D <sub>126,1</sub>	D <sub>127,1</sub>	
2	D <sub>0,2</sub>	D <sub>1,2</sub>	D <sub>2,2</sub>	D <sub>3,2</sub>		D <sub>51,2</sub>	Q <sub>52,2</sub>	Q <sub>53,2</sub>		Q <sub>75,2</sub>	D <sub>76,2</sub>	D <sub>77,2</sub>		D <sub>126,2</sub>	D <sub>127,2</sub>	
3	D <sub>0,3</sub>	D <sub>1,3</sub>	D <sub>2,3</sub>	D <sub>3,3</sub>		D <sub>51,3</sub>	Q <sub>52,3</sub>	Q <sub>53,3</sub>		Q <sub>75,3</sub>	D <sub>76,3</sub>	D <sub>77,3</sub>		D <sub>126,3</sub>	D <sub>127,3</sub>	
4	D <sub>0,4</sub>	D <sub>1,3</sub>	D <sub>2,4</sub>	D <sub>3,4</sub>		D <sub>51,4</sub>	Q <sub>52,4</sub>	Q <sub>53,4</sub>		Q <sub>75,4</sub>	D <sub>76,4</sub>	D <sub>77,4</sub>		D <sub>126,4</sub>	D <sub>127,4</sub>	
5	D <sub>0,5</sub>	D <sub>1,5</sub>	D <sub>2,5</sub>	D <sub>3,5</sub>		D <sub>51,5</sub>	Q <sub>52,5</sub>	Q <sub>53,5</sub>		Q <sub>75,5</sub>	D <sub>76,5</sub>	D <sub>77,5</sub>		D <sub>126,5</sub>	D <sub>127,5</sub>	
6	D <sub>0,6</sub>	D <sub>1,6</sub>	D <sub>2,6</sub>	D <sub>3,6</sub>		D <sub>51,6</sub>	Q <sub>52,6</sub>	Q <sub>53,6</sub>		Q <sub>75,6</sub>	D <sub>76,6</sub>	D <sub>77,6</sub>		D <sub>126,6</sub>	D <sub>127,6</sub>	
7	D <sub>0,7</sub>	D <sub>1,7</sub>	D <sub>2,7</sub>	D <sub>3,7</sub>		D <sub>51,7</sub>	Q <sub>52,7</sub>	Q <sub>53,7</sub>		Q <sub>75,7</sub>	D <sub>76,7</sub>	D <sub>77,7</sub>		D <sub>126,7</sub>	D <sub>127,7</sub>	
8	D <sub>0,8</sub>	D <sub>1,8</sub>	D <sub>2,8</sub>	D <sub>3,8</sub>		D <sub>51,8</sub>	Q <sub>52,8</sub>	Q <sub>53,8</sub>		Q <sub>75,8</sub>	D <sub>76,8</sub>	D <sub>77,8</sub>		D <sub>126,8</sub>	D <sub>127,8</sub>	
9	D <sub>0,9</sub>	D <sub>1,9</sub>	D <sub>2,9</sub>	D <sub>3,9</sub>		D <sub>51,9</sub>	Q <sub>52,9</sub>	Q <sub>53,9</sub>		Q <sub>75,9</sub>	D <sub>76,9</sub>	D <sub>77,9</sub>		D <sub>126,9</sub>	D <sub>127,9</sub>	
10	D <sub>0,10</sub>	D <sub>1,10</sub>	D <sub>2,10</sub>	D <sub>3,10</sub>		D <sub>51,10</sub>	Q <sub>52,10</sub>	Q <sub>53,10</sub>		Q <sub>75,10</sub>	D <sub>76,10</sub>	D <sub>77,10</sub>		D <sub>126,10</sub>	D <sub>127,10</sub>	
11	D <sub>0,11</sub>	D <sub>1,11</sub>	D <sub>2,11</sub>	D <sub>3,11</sub>		D <sub>51,11</sub>	Q <sub>52,11</sub>	Q <sub>53,11</sub>		Q <sub>75,11</sub>	D <sub>76,11</sub>	D <sub>77,11</sub>		D <sub>126,11</sub>	D <sub>127,11</sub>	
12	D <sub>0,12</sub>	D <sub>1,12</sub>	D <sub>2,12</sub>	D <sub>3,12</sub>		D <sub>51,12</sub>	Q <sub>52,12</sub>	Q <sub>53,12</sub>		Q <sub>75,12</sub>	D <sub>76,12</sub>	D <sub>77,12</sub>		D <sub>126,12</sub>	D <sub>127,12</sub>	
13	D <sub>0,13</sub>	D <sub>1,13</sub>	D <sub>2,13</sub>	D <sub>3,13</sub>		D <sub>51,13</sub>	Q <sub>52,13</sub>	Q <sub>53,13</sub>		Q <sub>75,13</sub>	D <sub>76,13</sub>	D <sub>77,13</sub>		D <sub>126,13</sub>	D <sub>127,13</sub>	
14	D <sub>0,14</sub>	D <sub>1,14</sub>	D <sub>2,14</sub>	D <sub>3,14</sub>		D <sub>51,14</sub>	Q <sub>52,14</sub>	Q <sub>53,14</sub>		Q <sub>75,14</sub>	D <sub>76,14</sub>	D <sub>77,14</sub>		D <sub>126,14</sub>	D <sub>127,14</sub>	
15	D <sub>0,15</sub>	D <sub>1,15</sub>	D <sub>2,15</sub>	D <sub>3,15</sub>		D <sub>51,15</sub>	Q <sub>52,15</sub>	Q <sub>53,15</sub>		Q <sub>75,15</sub>	D <sub>76,15</sub>	D <sub>77,15</sub>		D <sub>126,15</sub>	D <sub>127,15</sub>	
16	D <sub>0,16</sub>	D <sub>1,16</sub>	D <sub>2,16</sub>	D <sub>3,16</sub>		D <sub>51,16</sub>	Q <sub>52,16</sub>	Q <sub>53,16</sub>		Q <sub>75,16</sub>	D <sub>76,16</sub>	D <sub>77,16</sub>		D <sub>126,16</sub>	D <sub>127,16</sub>	
17	D <sub>0,17</sub>	D <sub>1,17</sub>	D <sub>2,17</sub>	D <sub>3,17</sub>		D <sub>51,17</sub>	Q <sub>52,17</sub>	Q <sub>53,17</sub>		Q <sub>75,17</sub>	D <sub>76,17</sub>	D <sub>77,17</sub>		D <sub>126,17</sub>	D <sub>127,17</sub>	
18	D <sub>0,18</sub>	D <sub>1,18</sub>	D <sub>2,18</sub>	D <sub>3,18</sub>		D <sub>51,18</sub>	Q <sub>52,18</sub>	Q <sub>53,18</sub>		Q <sub>75,18</sub>	D <sub>76,18</sub>	D <sub>77,18</sub>		D <sub>126,18</sub>	D <sub>127,18</sub>	
19	D <sub>0,19</sub>	D <sub>1,19</sub>	D <sub>2,19</sub>	D <sub>3,19</sub>		D <sub>51,19</sub>	Q <sub>52,19</sub>	Q <sub>53,19</sub>		Q <sub>75,19</sub>	D <sub>76,19</sub>	D <sub>77,19</sub>		D <sub>126,19</sub>	D <sub>127,19</sub>	
20	D <sub>0,20</sub>	D <sub>1,20</sub>	D <sub>2,20</sub>	D <sub>3,20</sub>		D <sub>51,20</sub>	Q <sub>52,20</sub>	Q <sub>53,20</sub>		Q <sub>75,20</sub>	D <sub>76,20</sub>	D <sub>77,20</sub>		D <sub>126,20</sub>	D <sub>127,20</sub>	
21	D <sub>0,21</sub>	D <sub>1,21</sub>	D <sub>2,21</sub>	D <sub>3,21</sub>		D <sub>51,21</sub>	Q <sub>52,21</sub>	Q <sub>53,21</sub>		Q <sub>75,21</sub>	D <sub>76,21</sub>	D <sub>77,21</sub>		D <sub>126,21</sub>	D <sub>127,21</sub>	
22	D <sub>0,22</sub>	D <sub>1,22</sub>	D <sub>2,22</sub>	D <sub>3,22</sub>		D <sub>51,22</sub>	Q <sub>52,22</sub>	Q <sub>53,22</sub>		Q <sub>75,22</sub>	D <sub>76,22</sub>	D <sub>77,22</sub>		D <sub>126,22</sub>	D <sub>127,22</sub>	
23	D <sub>0,23</sub>	D <sub>1,23</sub>	D <sub>2,23</sub>	D <sub>3,23</sub>		D <sub>51,23</sub>	Q <sub>52,23</sub>	Q <sub>53,23</sub>		Q <sub>75,23</sub>	D <sub>76,23</sub>	D <sub>77,23</sub>		D <sub>126,23</sub>	D <sub>127,23</sub>	
24	D <sub>0,24</sub>	P <sub>1,24</sub>	D <sub>2,24</sub>	P <sub>3,24</sub>		P <sub>51,24</sub>	Q <sub>52,24</sub>	P <sub>53,24</sub>		P <sub>75,24</sub>	D <sub>76,24</sub>	P <sub>77,24</sub>		D <sub>126,24</sub>	P <sub>127,24</sub>	
25	D <sub>0,25</sub>	P <sub>1,25</sub>	D <sub>2,25</sub>	P <sub>3,25</sub>		P <sub>51,25</sub>	Q <sub>52,25</sub>	P <sub>53,25</sub>		P <sub>75,25</sub>	D <sub>76,25</sub>	P <sub>77,25</sub>		D <sub>126,25</sub>	P <sub>127,25</sub>	
26	D <sub>0,26</sub>	P <sub>1,26</sub>	D <sub>2,26</sub>	P <sub>3,26</sub>		P <sub>51,26</sub>	Q <sub>52,26</sub>	P <sub>53,26</sub>		P <sub>75,26</sub>	D <sub>76,26</sub>	P <sub>77,26</sub>		D <sub>126,26</sub>	P <sub>127,26</sub>	
27	D <sub>0,27</sub>	P <sub>1,27</sub>	D <sub>2,27</sub>	P <sub>3,27</sub>		P <sub>51,27</sub>	Q <sub>52,27</sub>	P <sub>53,27</sub>		P <sub>75,27</sub>	D <sub>76,27</sub>	P <sub>77,27</sub>		D <sub>126,27</sub>	P <sub>127,27</sub>	
28	D <sub>0,28</sub>	P <sub>1,28</sub>	D <sub>2,28</sub>	P <sub>3,28</sub>		P <sub>51,28</sub>	Q <sub>52,28</sub>	P <sub>53,28</sub>		P <sub>75,28</sub>	D <sub>76,28</sub>	P <sub>77,28</sub>		D <sub>126,28</sub>	P <sub>127,28</sub>	
29	D <sub>0,29</sub>	P <sub>1,29</sub>	D <sub>2,29</sub>	P <sub>3,29</sub>		P <sub>51,29</sub>	Q <sub>52,29</sub>	P <sub>53,29</sub>		P <sub>75,29</sub>	D <sub>76,29</sub>	P <sub>77,29</sub>		D <sub>126,29</sub>	P <sub>127,29</sub>	
30	D <sub>0,30</sub>	P <sub>1,30</sub>	D <sub>2,30</sub>	P <sub>3,30</sub>		P <sub>51,30</sub>	Q <sub>52,30</sub>	P <sub>53,30</sub>		P <sub>75,30</sub>	D <sub>76,30</sub>	P <sub>77,30</sub>		D <sub>126,30</sub>	P <sub>127,30</sub>	
31	D <sub>0,31</sub>	P <sub>1,31</sub>	D <sub>2,31</sub>	P <sub>3,31</sub>		P <sub>51,31</sub>	Q <sub>52,31</sub>	P <sub>53,31</sub>		P <sub>75,31</sub>	D <sub>76,31</sub>	P <sub>77,31</sub>		D <sub>126,31</sub>	P <sub>127,31</sub>	

128 blocks


1 block (= 32 symbols)

**Figure 17.9** Data allocation

block is:  $(128 \times 32)$  symbols  $\times 8$  bit  $\times 2$  tracks = 65.536 bit, which means a 128 bit memory is required.

The symbols are interleaved, based on the following method, according to the respective number of the audio data symbol. The interleaving format depends on whether a 16-bit or 12-bit quantization is used. The interleave format discussed here is for 16-bit quantization; the most important format.

One 16-bit audio data word indicated as  $A_i$  or  $B_i$  is converted to two audio data symbols each consisting of 8 bits. The audio data symbol converted from the upper 8 bits of  $A_i$  or  $B_i$  is expressed as  $A_{iu}$  or  $B_{iu}$ . The audio data symbol converted from the lower 8 bits of  $A_i$  or  $B_i$  is expressed as  $A_{il}$  or  $B_{il}$ .



**Note:** A stands for left channel, B for right channel.

If the audio data symbol is equal to  $A_{iu}$  or  $A_{ij}$ , let  $a = 0$ .

If the audio data symbol is equal to  $B_{iu}$  or  $B_{ij}$ , let  $a = 1$ .

If the audio data symbol is equal to  $A_{iu}$  or  $B_{iu}$ , let  $v = 0$ .

If the audio data symbol is equal to  $A_{ij}$  or  $B_{ij}$ , let  $u = 1$ .

Table 17.5 a and b represents an example of the data assignment for both tracks (+ azimuth and - azimuth) respectively, for 16-bit sampled data words.

### Subcode

The data subcode capacity is about four times that of a CD and various applications will be available in the future. A subcode format which is essentially the same as the CD subcode format is currently specified for pre-recorded tapes.

The most important control bits, such as the sampling frequency bit and copy inhibit bit, are recorded in the PCM-ID area, so it is impossible to change these bits without rewriting the PCM data. As the PCM data is protected by the main error-correction process, subcodes requiring a high reliability are usefully stored here.

Data to allow fast accessing, programme number, time code, etc., are recorded in subcode areas (sub-1 and sub-2) which are located at both ends of

Table 17.5a

Block address

	0	1	2	3	35	50	51	52	75	76	77	78	79	111	126	127
0	A 0u	A 832u	A 2u	A 834u	A 866u	A 50u	A 882u	Q 52. 0 Q 75. 0 B	1u	B 833u	B 3u	B 835u	B 867u	B 51u	B 883u	
1	A 52u	A 884u	A 54u	A 886u	A 918u	A 102u	A 934u	Q 52. 1 Q 75. 1 B	53u	B 885u	B 55u	B 887u	B 919u	B 103u	B 935u	
2	A 01	A 8321	A 21	A 8341	A 8661	A 581	A 8821	Q 52. 2 Q 75. 2 B	11	B 8331	B 31	B 8351	B 8671	B 511	B 8831	
3	A 521	A 8841	A 541	A 8861	A 9181	A 1021	A 9341	Q 52. 3 Q 75. 3 B	531	B 8851	B 551	B 8871	B 9191	B 1031	B 9351	
4	A 104u	A 936u	A 106u	A 938u	A 970u	A 154u	A 986u	Q 52. 4 Q 75. 4 B	105u	B 937u	B 187u	B 939u	B 971u	B 155u	B 987u	
5	A 156u	A 988u	A 158u	A 990u	A 1022u	A 206u	A 1038u	Q 52. 5 Q 75. 5 B	157u	B 989u	B 159u	B 991u	B 1023u	B 207u	B 1039u	
6	A 1040	A 9361	A 1061	A 9381	A 9701	A 1541	A 9861	Q 52. 6 Q 75. 6 B	1051	B 9371	B 1071	B 9391	B 9711	B 1551	B 9871	
7	A 1561	A 9881	A 1581	A 9901	A 10221	A 2061	A 10381	Q 52. 7 Q 75. 7 B	1571	B 9891	B 1591	B 9911	B 10231	B 2071	B 10391	
8	A 208u	A 1040u	A 210u	A 1042u	A 1074u	A 258u	A 1090u	Q 52. 8 Q 75. 8 B	209u	B 1041u	B 211u	B 1043u	B 1075u	B 259u	B 1091u	
9	A 260u	A 1092u	A 262u	A 1094u	A 1126u	A 310u	A 1142u	Q 52. 9 Q 75. 9 B	261u	B 1093u	B 263u	B 1095u	B 1127u	B 311u	B 1143u	
10	A 2081	A 10401	A 2101	A 10421	A 10741	A 2581	A 10901	Q 52. 10 Q 75. 10 B	2091	B 10411	B 2111	B 10431	B 10751	B 2591	B 10911	
11	A 2601	A 10921	A 2621	A 10941	A 11261	A 3101	A 11421	Q 52. 11 Q 75. 11 B	2611	B 10931	B 2631	B 10951	B 11271	B 3111	B 11431	
12	A 312u	A 1144u	A 314u	A 1146u	A 1178u	A 362u	A 1194u	Q 52. 12 Q 75. 12 B	313u	B 1145u	B 315u	B 1147u	B 1179u	B 363u	B 1195u	
13	A 364u	A 1196u	A 366u	A 1198u	A 1230u	A 414u	A 1246u	Q 52. 13 Q 75. 13 B	365u	B 1197u	B 367u	B 1199u	B 1231u	B 415u	B 1247u	
14	A 3121	A 11441	A 3141	A 11461	A 11781	A 3621	A 11941	Q 52. 14 Q 75. 14 B	3131	B 11451	B 3151	B 11471	B 11791	B 3631	B 11951	
15	A 3641	A 11961	A 3661	A 11981	A 12301	A 4141	A 12461	Q 52. 15 Q 75. 15 B	3651	B 11971	B 3671	B 11991	B 12311	B 4151	B 12471	
16	A 416u	A 1248u	A 418u	A 1202u	A 1282u	A 466u	A 1298u	Q 52. 16 Q 75. 16 B	417u	B 1249u	B 419u	B 1251u	B 1283u	B 467u	B 1299u	
17	A 468u	A 1300u	A 478u	A 1302u	A 1334u	A 518u	A 1350u	Q 52. 17 Q 75. 17 B	469u	B 1301u	B 471u	B 1303u	B 1335u	B 519u	B 1351u	
18	A 4161	A 12481	A 4181	A 12501	A 12821	A 4661	A 12981	Q 52. 18 Q 75. 18 B	4171	B 12491	B 4191	B 12511	B 12831	B 4671	B 12991	
19	A 4681	A 13001	A 4701	A 13021	A 13341	A 5181	A 13501	Q 52. 19 Q 75. 19 B	4691	B 13011	B 4711	B 13031	B 13351	B 5191	B 13511	
20	A 520u	A 1352u	A 522u	A 1354u	A 1386u	A 570u	A 1402u	Q 52. 20 Q 75. 20 B	521u	B 1353u	B 523u	B 1355u	B 1387u	B 571u	B 1403u	
21	A 572u	A 1404u	A 574u	A 1406u	A 1438u	A 622u		Q 52. 21 Q 75. 21 B	573u	B 1405u	B 575u	B 1407u	B 1439u	B 623u		
22	A 5201	A 13521	A 5221	A 13541	A 13861	A 5701	A 14021	Q 52. 22 Q 75. 22 B	5211	B 13531	B 5231	B 13551	B 13871	B 5711	B 14031	
23	A 5721	A 14041	A 5741	A 14061	A 14381	A 6221		Q 52. 23 Q 75. 23 B	5731	B 14051	B 5751	B 14071	B 14391	B 6231		
24	A 624u	P 1.24	A 626u	P 3.24	P 35.24	A 674u	P 51.24	Q 52. 24 Q 75. 24 B	625u	P 77.24	B 627u	P 79.24	P 111.24	B 675u	P 127.24	
25	A 676u	P 1.25	A 678u	P 3.25	P 35.25	A 726u	P 51.25	Q 52. 25 Q 75. 25 B	627u	P 77.25	B 679u	P 79.25	P 111.25	B 727u	P 127.25	
26	A 6241	P 1.26	A 6261	P 3.26	P 35.26	A 6741	P 51.26	Q 52. 26 Q 75. 26 B	6251	P 77.26	B 6271	P 79.26	P 111.26	B 6751	P 127.26	
27	A 6761	P 1.27	A 6781	P 3.27	P 35.27	A 7261	P 51.27	Q 52. 27 Q 75. 27 B	6271	P 77.27	B 6791	P 79.27	P 111.27	B 7271	P 127.27	
28	A 728u	P 1.28	A 730u	P 3.28	P 35.28	A 778u	P 51.28	Q 52. 28 Q 75. 28 B	729u	P 77.28	B 731u	P 79.28	P 111.28	B 779u	P 127.28	
29	A 780u	P 1.29	A 782u	P 3.29	P 35.29	A 830u	P 51.29	Q 52. 29 Q 75. 29 B	701u	P 77.29	B 783u	P 79.29	P 111.29	B 831u	P 127.29	
30	A 7201	P 1.30	A 7301	P 3.30	P 35.30	A 7781	P 51.30	Q 52. 30 Q 75. 30 B	7291	P 77.30	B 7311	P 79.30	P 111.30	B 7791	P 127.30	
31	A 7801	P 1.31	A 7821	P 3.31	P 35.31	A 8301	P 51.31	Q 52. 31 Q 75. 31 B	7811	P 77.31	B 7831	P 79.31	P 111.31	B 8311	P 127.31	

Recording direction

Symbol number



Table 17.5b

Block address

	0	1	2	3	35	50	51	52	75	76	77	78	79	111	126	127
0	B 0u	B 832u	B 2u	B 834u	B 866u	B 50u	B 882u	Q 52. 0 Q 75. 0 A	1u A 833u	A 3u	A 835u	A 867u	A 51u	A 883u		
1	B 52u	B 884u	B 54u	B 886u	B 918u	B 102u	B 934u	Q 52. 1 Q 75. 1 A	53u A 885u	A 55u	A 887u	A 919u	A 103u	A 935u		
2	B 01	B 8321	B 21	B 8341	B 8661	B 501	B 8821	Q 52. 2 Q 75. 2 A	11 A 8331	A 31	A 8351	A 8671	A 511	A 8831		
3	B 521	B 8841	B 541	B 8861	B 9181	B 1021	B 9341	Q 52. 3 Q 75. 3 A	531 A 8851	A 551	A 8871	A 9191	A 1031	A 9351		
4	B 104u	B 936u	B 106u	B 938u	B 970u	B 154u	B 986u	Q 52. 4 Q 75. 4 A	105u A 937u	A 107u	A 939u	A 971u	A 155u	A 987u		
5	B 156u	B 988u	B 158u	B 990u	B 1022u	B 206u	B 1038u	Q 52. 5 Q 75. 5 A	157u A 989u	A 159u	A 991u	A 1023u	A 207u	A 1039u		
6	B 104u	B 9361	B 1061	B 9381	B 9701	B 1541	B 9861	Q 52. 6 Q 75. 6 A	1051 A 9371	A 1071	A 9391	A 9711	A 1551	A 9871		
7	B 1561	B 9881	B 1581	B 9901	B 10221	B 2061	B 10381	Q 52. 7 Q 75. 7 A	1571 A 9891	A 1591	A 9911	A 10231	A 2071	A 10391		
8	B 208u	B 1040u	B 210u	B 1042u	B 1074u	B 258u	B 1090u	Q 52. 8 Q 75. 8 A	209u A 1041u	A 211u	A 1043u	A 1075u	A 259u	A 1091u		
9	B 260u	B 1092u	B 262u	B 1094u	B 1126u	B 318u	B 1142u	Q 52. 9 Q 75. 9 A	261u A 1093u	A 263u	A 1095u	A 1127u	A 311u	A 1143u		
10	B 2081	B 10401	B 2101	B 10421	B 10741	B 2581	B 10981	Q 52. 10 Q 75. 10 A	2091 A 10411	A 2111	A 10431	A 10751	A 2591	A 10911		
11	B 2601	B 10921	B 2621	B 10941	B 11261	B 3101	B 11421	Q 52. 11 Q 75. 11 A	2611 A 10931	A 2631	A 10951	A 11271	A 3111	A 11431		
12	B 312u	B 1144u	B 314u	B 1146u	B 1178u	B 362u	B 1194u	Q 52. 12 Q 75. 12 A	313u A 1145u	A 315u	A 1147u	A 1179u	A 363u	A 1195u		
13	B 364u	B 1196u	B 366u	B 1198u	B 1230u	B 414u	B 1246u	Q 52. 13 Q 75. 13 A	365u A 1197u	A 367u	A 1199u	A 1231u	A 415u	A 1247u		
14	B 3121	B 11441	B 3141	B 11461	B 11701	B 3621	B 11941	Q 52. 14 Q 75. 14 A	3131 A 11451	A 3151	A 11471	A 11791	A 3631	A 11951		
15	B 3641	B 11961	B 3661	B 11981	B 12301	B 4141	B 12461	Q 52. 15 Q 75. 15 A	3651 A 11971	A 3671	A 11991	A 12311	A 4151	A 12471		
16	B 416u	B 1248u	B 418u	B 1202u	B 1282u	B 466u	B 1298u	Q 52. 16 Q 75. 16 A	417u A 1249u	A 419u	A 1251u	A 1283u	A 467u	A 1299u		
17	B 468u	B 1300u	B 470u	B 1302u	B 1334u	B 518u	B 1350u	Q 52. 17 Q 75. 17 A	469u A 1381u	A 471u	A 1303u	A 1335u	A 519u	A 1351u		
18	B 4161	B 12481	B 4181	B 12501	B 12021	B 4661	B 12981	Q 52. 18 Q 75. 18 A	4171 A 12491	A 4191	A 12511	A 12831	A 4671	A 12991		
19	B 4681	B 13001	B 4701	B 13021	B 13341	B 5181	B 13501	Q 52. 19 Q 75. 19 A	4691 A 13011	A 4711	A 13031	A 13351	A 5191	A 13511		
20	B 520u	B 1352u	B 522u	B 1354u	B 1386u	B 570u	B 1402u	Q 52. 20 Q 75. 20 A	521u A 1353u	A 523u	A 1355u	A 1387u	A 571u	A 1403u		
21	B 572u	B 1404u	B 574u	B 1406u	B 1438u	B 622u		Q 52. 21 Q 75. 21 A	573u A 1405u	A 575u	A 1407u	A 1439u	A 623u			
22	B 5201	B 13521	B 5221	B 13541	B 13861	B 5781	B 14021	Q 52. 22 Q 75. 22 A	5211 A 13531	A 5231	A 13551	A 13871	A 5711	A 14031		
23	B 5721	B 14041	B 5741	B 14061	B 14301	B 6221		Q 52. 23 Q 75. 23 A	5731 A 14051	A 5751	A 14071	A 14391	A 6231			
24	B 624u	P 1.24	B 626u	P 3.24	P 35.24	B 674u	P 51.24	Q 52. 24 P 75. 24 A	625u P 77.24	A 627u	P 79.24	P 111.24	A 675u	P 127.24		
25	B 676u	P 1.25	B 678u	P 3.25	P 35.25	B 726u	P 51.25	Q 52. 25 P 75. 25 A	625u P 77.25	A 627u	P 79.25	P 111.25	A 675u	P 127.25		
26	B 6241	P 1.26	B 6261	P 3.26	P 35.26	B 6741	P 51.26	Q 52. 26 P 75. 26 A	6251 P 77.26	A 6271	P 79.26	P 111.26	A 6751	P 127.26		
27	B 6761	P 1.27	B 6781	P 3.27	P 35.27	B 7261	P 51.27	Q 52. 27 P 75. 27 A	6251 P 77.27	A 6271	P 79.27	P 111.27	A 6751	P 127.27		
28	B 728u	P 1.28	B 730u	P 3.28	P 35.28	B 778u	P 51.28	Q 52. 28 P 75. 28 A	729u P 77.28	A 731u	P 79.28	P 111.28	A 779u	P 127.28		
29	B 780u	P 1.29	B 782u	P 3.29	P 35.29	B 836u	P 51.29	Q 52. 29 P 75. 29 A	781u P 77.29	A 783u	P 79.29	P 111.29	A 831u	P 127.29		
30	B 7251	P 1.30	B 7301	P 3.30	P 35.30	B 7781	P 51.30	Q 52. 30 P 75. 30 A	7291 P 77.30	A 7311	P 79.30	P 111.30	A 7791	P 127.30		
31	B 7801	P 1.31	B 7821	P 3.31	P 35.31	B 8301	P 51.31	Q 52. 31 P 75. 31 A	7811 P 77.31	A 7831	P 79.31	P 111.31	A 8311	P 127.31		

Recording direction

Symbol number

## 208 Digital Audio Recording Systems




Figure 17.10 PCM data interleave format




Figure 17.11




Figure 17.12 Subcode area format




Figure 17.13 PACK format

Table 17.6

Item	Mode
0000	No information
0001	Programme time
0010	Absolute time
0011	Running time
0100	TOC
0101	Calendar
0110	Catalogue
0111	ISRC
1000	Reserved
1110	Reserved
1111	For tape maker

the helical tracks. These subcode areas are identical. Figure 17.11 illustrates the sub-1 and sub-2 areas, along with the PCM area containing subcode information.

An example of the subcode area format is shown in Figure 17.12. Data are recorded in a **pack** format.

Figure 17.13 shows the pack format, and the pack item codes are listed in Table 17.6. All the CD-Q channel subcodes are available to be used.




Figure 17.14

Each pack block comprises an item code of 4 bits, indicating what information is stored in the pack data area. The item code 0100 indicates that the related pack data is a TOC (table of contents) pack. This TOC is recorded repeatedly throughout the tape, in order to allow high-speed access and search (at  $200 \times$  normal speed). Every subcode datablock is controlled by an 8-bit C1 parity word allowing appropriate control of data validity.

Subcode data in the subarea can be rewritten or modified independently from the PCM data.

Figure 17.14 shows an example of subcode information for pre-recorded tape. The figure shows the use of different codes and pack data on a tape, such as programme time, absolute time, programme number, etc.

### Tape Duplication

High-speed duplication of R-DAT tapes can be done by using the magnetic contact printing technique. In this method a master tape of the mirror type is produced on a master tape recorder (Figure 17.15a).

The magnetic surfaces of the master tape and the copy tape are mounted in contact with each other on a printing machine as shown in Figure 17.15b.




Figure 17.15

By controlling the pressure of both tapes between pinch drum and bias head, the magnetizing process is performed, applying a magnetic bias to the contact area. Special tape and a special bias head are required (see Figures 17.16 and 17.17).

### Cassette

The cassette is a completely sealed structure and measures  $73 \times 54 \times 10.5$  mm. It weighs about 20 g. See Figure 17.18.




Figure 17.16




Figure 17.17




Figure 17.18b




Figure 17.18a




Figure 17.18c



# Appendix 1

## Error Correction

Error correction is one of the most advanced areas in the entire field of digital audio. It is purely because of error-correction techniques that reliable digital recordings can be made, despite the frequent occurrence of tape dropouts.

In the next two sections, we are going to discuss the theory behind the EIAJ format P, Q and CRC codes. Because of the special nature and the complexity involved, a mathematical treatment of this topic is unavoidable. However, every attempt has been made to pull all material together in a concise and systematic manner. Examples are included to help you see the situations more vividly. For your part, the only prerequisite in reading them is some knowledge of matrix algebra.

### P, Q and the cyclic redundancy check code

In Figure A1.1, the P codes are generated by feeding the input data  $L_0 - R_2$  to an exclusive-or gate. Hence, we have:

$$P_0 = L_0 \oplus R_0 \oplus L_1 \oplus R_1 \oplus L_2 \oplus R_2 \dots \quad (1)$$

$$P_1 = L_3 \oplus R_3 \oplus L_4 \oplus R_4 \oplus L_5 \oplus R_5$$

$$P_n = L_{3n} \oplus R_{3n} \oplus L_{3n+1} \oplus R_{3n+1} \oplus L_{3n+2} \oplus R_{3n+2}$$

The symbol  $\oplus$  (pronounced ring-sum) indicates **modulo-2 summation**, which obeys the following rules:

$$0 \oplus 0 = 0$$

$$0 \oplus 1 = 1$$

$$1 \oplus 0 = 1$$

$$1 \oplus 1 = 0$$




Figure A1.1

$$Q_0 = T^6 L_0 + T^5 R_0 + T^4 L_1 + T^3 R_1 + T^2 L_2 + T R_2$$




Figure A1.2

which is an **exclusive-or** operation. When considering expression (1) and applying the rules, the parity bit  $P_0$  will be 0 for even numbers of logic levels, and 1 for odd numbers.

$Q$  codes are generated by a **matrix operation circuit**, the principle of which is shown in Figure A1.2.

Initially,  $L_0$ , a 14-bit data word comprising bits  $a_1$  to  $a_{14}$ , is applied to the summing nodes and the shift register contents are all 0s. After one shift to the right, the shift register contents change to those shown in Figure A1.3. The single shift operation on word  $L_0$  can be defined as  $TL_0$ .

Now, a second data word  $R_0$ , comprising bits  $b_1$  to  $b_{14}$ , is applied to the summing nodes. When the next shift occurs, the shift register contents

1Shift




Figure A1.3

2 Shift




Figure A1.4

change to those shown in Figure A1.4. This time,  $L_0$  undergoes two shifts while  $R_0$  is subjected to only one, the combined effect can be defined as  $TTL_0 \oplus TR_0$ , or  $T^2L_0 \oplus TR_0$ .

After six shift operations, the shift register contents constitute the code word  $Q_0$ . Mathematically we can write:

$$Q_0 = T^6L_0 \oplus T^5R_0 \oplus T^4L_1 \oplus T^3R_1 \oplus T^2L_2 \oplus TR_2$$

Similarly we have,

$$Q_1 = T^6L_3 \oplus T^5R_3 \oplus T^4L_4 \oplus T^3R_4 \oplus T^2L_5 \oplus TR_5$$

and

$$Q_n = T^6L_{3n} \oplus T^5R_{3n} \oplus \dots \oplus T^2L_{3n+2} \oplus TR_{3n+2}$$

The 1-bit shift and 2-bit modulo-3 summation are functions of  $T$  having the following forms:

$$T = \begin{bmatrix} 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 1 \\ 1 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 1 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 1 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 1 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 & 0 & 0 & 0 & 0 & 1 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 \end{bmatrix}$$

and

$$TL_0 = T \begin{bmatrix} a_1 \\ a_2 \\ a_3 \\ a_4 \\ a_5 \\ a_6 \\ a_7 \\ a_8 \\ a_9 \\ a_{10} \\ a_{11} \\ a_{12} \\ a_{13} \\ a_{14} \end{bmatrix} = \begin{bmatrix} a_{14} \\ a_1 \\ a_2 \\ a_3 \\ a_4 \\ a_5 \\ a_6 \\ a_7 \\ a_8 \oplus a_{14} \\ a_9 \\ a_{10} \\ a_{11} \\ a_{12} \\ a_{13} \end{bmatrix}$$

If we let:

$$[L_0 = a_1 a_2 \dots a_{14}]$$

$$[R_0 = b_1 b_2 \dots b_{14}]$$

$$[L_1 = c_1 c_2 \dots c_{14}]$$

.

.

.

$$[R_2 = f_1 f_2 \dots f_{14}]$$

Then we have the following:

$$\begin{aligned}
 TR_2 &= \begin{bmatrix} f_{14} \\ f_1 \\ f_2 \\ f_3 \\ f_4 \\ f_5 \\ f_6 \\ f_7 \\ f_8 \oplus f_{14} \\ f_9 \\ f_{10} \\ f_{11} \\ f_{12} \\ f_{13} \end{bmatrix} & T^2L_2 &= \begin{bmatrix} e_{13} \\ e_{14} \\ e_1 \\ e_2 \\ e_3 \\ e_4 \\ e_5 \\ e_6 \\ e_7 \oplus e_{13} \\ e_8 \oplus e_{14} \\ e_9 \\ e_{10} \\ e_{11} \\ e_{12} \end{bmatrix} & T^3R_1 &= \begin{bmatrix} d_{12} \\ d_{13} \\ d_{14} \\ d_1 \\ d_2 \\ d_3 \\ d_4 \\ d_5 \\ d_6 \oplus d_{12} \\ d_7 \oplus d_{13} \\ d_8 \oplus d_{14} \\ d_9 \\ d_{10} \\ d_{11} \end{bmatrix}
 \end{aligned}$$

$$\begin{aligned}
 T^4L_2 &= \begin{bmatrix} c_{11} \\ c_{12} \\ c_{13} \\ c_{14} \\ c_1 \\ c_2 \\ c_3 \\ c_4 \\ c_5 \oplus c_{11} \\ c_6 \oplus c_{12} \\ c_7 \oplus c_{13} \\ c_8 \oplus c_{14} \\ c_9 \\ c_{10} \end{bmatrix} & T^5R_0 &= \begin{bmatrix} b_{10} \\ b_{11} \\ b_{12} \\ b_{13} \\ b_{14} \\ b_1 \\ b_2 \\ b_3 \\ b_4 \oplus b_{10} \\ b_5 \oplus b_{11} \\ b_6 \oplus b_{12} \\ b_7 \oplus b_{13} \\ b_8 \oplus b_{14} \\ b_9 \end{bmatrix} & T^6L_0 &= \begin{bmatrix} a_9 \\ a_{10} \\ a_{11} \\ a_{12} \\ a_{13} \\ a_{14} \\ a_1 \\ a_2 \\ a_3 \oplus a_9 \\ a_4 \oplus a_{10} \\ a_5 \oplus a_{11} \\ a_6 \oplus a_{12} \\ a_7 \oplus a_{13} \\ a_8 \oplus a_{14} \end{bmatrix}
 \end{aligned}$$

Now, let us see how a Q code can be generated if data are input serially.

Consider the following scheme:

- (1) One of the feedback loops is controlled by a switch that turns on whenever 15 shifts are made.
- (2) The exclusive-or operation is only active during a SR (shift register) shift.

## 220 Appendix 1

With the following configuration:




Figure A1.5

Then, after 14 shifts the contents of the two SRs are:




Figure A1.6a

For an additional shift we have,




Figure A1.6b

which we recognize as  $TL_0$ . As we continue we have,




Figure A1.6c

After the 30th shift, the contents of the SRs are:




Figure A1.6d

which is  $T^2 L_0 + TR_0$  (when compared with the two column matrixes  $TR_2$  and  $T^2 L_2$ ). Note that for this scheme to work, the serial data have to be sent in the following format:

$$a_{14} a_{13} a_{12} a_{11} \dots a_1 \quad bb_{14} b_{13} b_{12} \dots b_1 \quad bc_{14} c_{13} c_{12} \dots c_1$$

Where  $b = 0$ . Finally, the reader can easily verify that after 90 shifts, the contents of the two SRs constitute the word  $Q$ .

The PCM-F1 employs cyclic redundancy check code (CRCC) for **detecting** code errors. The encoding can be easily implemented by using shift registers while the decoding scheme becomes simple because of the inherent well-defined mathematical structure. In mathematical terms, a **code word** is a **code vector** because it is an  $n$ -tuple from the **vector space** of all  $n$ -tuples. For a linear code  $C$  with length  $n$  and containing  $r$  information digits, if an  $n$ -tuple

$$V^{(1)} = (V_{n-1}, V_1, \dots, V_{n-2})$$

obtained by shifting the code vector of  $C$

$$V = (V_0, V_1, V_2, \dots, V_{n-1})$$

cyclically one place to the right is also a code vector of  $C$ , then linear code  $C$  is called a cyclic code. From this definition, it follows that no matter how many times the digits in  $V$  are shifted cyclically to the right, the resulting  $n$ -tuple is also a code vector. The components of a code vector define the coefficients of a polynomial. Therefore, if we denote  $V(X)$  the code polynomial of  $V$ , we then have:

$$V(X) = V_0 + V_1 X + V_2 X^2 + \dots + V_{n-1} X^{n-1}$$

or, in a particular case, where we have the following code word,

14	13	12	11	10	9	8	7	6	5	4	3	2	1
0	0	1	1	0	1	0	0	1	0	1	0	0	1
		$x^{11}$	$x^{10}$		$x^8$			$x^5$		$x^3$			$x^0 = 1$

**Figure A1.7**

The code polynomial is written as,

$$V(X) = X^{11} + X^{10} + X^8 + X^5 + X^3 + 1$$

## 222 Appendix 1

where  $+$  stands for modulo-2 summation. Moreover, every code polynomial  $V(x)$  can be expressed in the following form:

$$\begin{aligned} V(X) &= M(X)g(X) \dots \dots \dots (2) \\ &= (M_0 + M_1X + M_2X^2 + \dots + M_{r-1}X^{r-1})(1 + g_1X + g_2X^2 + \dots + \\ &\quad g_{n-r-1}X^{n-r-1} + X^{n-r}) \end{aligned}$$

where  $M_0, M_1, \dots, M_{r-1}$  are the information digits to be encoded and  $g(X)$  is defined as a **generator polynomial**. Hence, the encoding of a message  $M(X)$  is equivalent to multiplying it by  $g(X)$ . Note that in any particular cyclic code, there only exists one generator polynomial  $g(X)$ . However, if we encode the information digits according to (2), the orders of the message digits are altered. Hence, a different scheme must be used. The code can be put into a systematic form (see example 3 below) by first multiplying  $M(X)$  by  $X^{n-r}$  and then divide the result by  $g(X)$ , hence,

$$X^{n-r}M(X) = Q(X)g(X) + R(X)$$

Adding  $R(X)$  to both sides, we have

$$X^{n-r}M(X) + R(X) = Q(X)g(X) \dots \dots \dots (3)$$

Where  $Q(X)$  is the quotient.

$R(X)$  is the remainder.

And, in modulo-2 summation  $R(X) + R(X) = 0$

If we define the left-hand side of (3) as our transmission polynomial  $T(X)$ , then

$$T(X) = Q(X)g(X)$$

which means that  $T(X)$  can be **divided exactly** by  $g(X)$ . In this case, the encoding is equivalent to converting the information polynomial  $M(X)$  into  $T(X)$ .

If, in the recording process,  $T(X)$  changes to  $E(X)$  and errors are detected. In the PCM-F1, when the CRCC indicates that one word in a horizontal scanning period  $H$  is incorrect, the remaining words in that period will all be considered erroneous.

At this point it is natural to ask what kind of properties  $g(X)$  must have in order to generate an  $(n, r)$  cyclic code, i.e., generating an  $n$ -bit code from a message of  $r$  bits. We have the following theorem.

**Theorem.** If  $g(X)$  is a polynomial of degree  $n-r$  and is a factor of  $X^n + 1$ , then  $g(X)$  generates an  $(n, r)$  cyclic code.



Now, we shall show you how a 4-bit cyclic code can be generated from a message of 3 bits. We hope that the whole situation will be clarified by the following simple examples.

**Example 1.** Since  $n = 4$  and  $r = 3$ , we are searching for a polynomial of degree 1. Because:

$$X^4 + 1 = (X + 1)(X^3 + X^2 + X + 1)$$

Our  $g(X)$  will be  $X + 1$

Note that  $g(X)$  is primitive (irreducible).

**Example 2.** Consider the messages 000, 100, 010, ... 111 where the LSB is at the extreme left of each word. From (2), we have

$$\text{for } 100, V(X) = 1(1 + X) = 1 + X$$

$$101, V(X) = (1 + X^2)(1 + X) = 1 + X + X^2 + X^3$$

For these two cases, the coded words are 1100 and 1111 respectively.

Proceeding as before, we have the following:

MESSAGES			CODE			
LSB		MSB	LSB			MSB
0	0	0	0	0	0	0
1	0	0	1	1	0	0
0	1	0	0	1	1	0
1	1	0	1	0	1	0
0	0	1	0	0	1	1
1	0	1	1	1	1	1
0	1	1	0	1	0	1
1	1	1	1	0	0	1

This code has a minimum distance of 2, hence it can detect a single error in the message, it is not systematic, i.e., we do not have a code where the first 3 digits are the unaltered message digits and the last one is a check bit.

It is not difficult to see that this code can be implemented by the circuit shown below:




Figure A1.8


## 224 Appendix 1

which employs two exclusive-or gates and two SRs. For this scheme to work, the message should be input as:

$$M_1M_2M_3M_1'0M_1'M_2'M_3'M_1'0 \dots \text{etc.}$$

The SRs reset whenever 5 shifts are made.

The decoder has the following configuration:



**Figure A1.9**


After 4 data bits come out of the AND gate, we look at the 4th bit. If this bit is zero, the three message bits are considered correct; otherwise, an error is made. Hence, the SRs reset after every 4 shifts. Also, the message input sequence is:

$$C_1C_2C_3C_4C_1'C_2'C_3'C_4' \dots \text{etc.}$$

The circuit works because when we multiply  $a_1a_2a_3$  by 11 we get the following:

$a_1$	$a_2$	$a_3$	
	$1$	$1$	
$a_1$	$a_2$	$a_3$	
	$a_1$	$a_2$	$a_3$
$a_1$	$a_1 + a_2$	$a_2 + a_3$	

Hence, with the following circuit



**Figure A1.10**

2nd shift,  $a_1$  is out.

From these 5 shifts, we get 0,  $a_1$ ,  $a_1 + a_2$ ,  $a_2 + a_3$ ; which matches the elements generated the multiplication.

However, for this to work, the message input must have the following format:

$$M_1M_2M_3M_40M_1'M_3'M_1'0\dots$$

and the SRs reset whenever 5 shifts are made.

Hence, for the decoded message  $D_1D_2D_3$ , we have:

$$D_1 = a_1 \cdot 1$$

$$D_2 = ((a_1 \cdot 1) + a_2) \cdot 1$$

$$D_3 = (((a_1 \cdot 1) + a_2) \cdot 1 + a_3) \cdot 1$$

$$\text{Also, } R = D_3 + a_4$$

For zero error detection,  $D_3$  equals to  $a_4$ . This is true when we look at the LSB columns of the message and code table. It is also clear that the decoder circuit implements the above division.

**Example 3.** We can form a systematic code by using equation (3). Take the last message word (1110 in the above example), then, the message polynomial is  $M(X) = 1 + X + X^2$ .

Since  $X^{n-r} = X$  in this case, we have  $XM(X) = X + X^2 + X^3$ .

Dividing  $XM(X)$  by the generator polynomial  $g(X) = 1 + X$  we have

$$\begin{array}{r} X^2 \quad + 1 \\ X+1 \overline{) \begin{array}{l} X^3 + X^2 + X \\ X^3 + X^2 \end{array}} \\ \underline{\phantom{X^3 + X^2 + X} X} \\ X + 1 \\ \underline{\phantom{X^3 + X^2 + X} X + 1} \\ 1 \end{array}$$

The remainder  $R(X) = 1$

Thus the code polynomial is

$$T(X) = X^3 + X^2 + X + 1$$

which is 1111

## 226 Appendix 1

Proceeding as before, we get the following systematic code:

MESSAGES			CODE			
LSB		MSB	LSB			MSB
0	0	0	0	0	0	0
1	0	0	1	1	0	0
0	1	0	1	0	1	0
1	1	0	0	1	1	0
0	0	1	1	0	0	1
1	0	1	0	1	0	1
0	1	1	0	0	1	1
1	1	1	1	1	1	1

Assuming that message bits are input as

$$M_1M_20M_1'M_2'M_3'M_0\dots,$$

The code can be implemented by the following circuit.




Figure A1.11

Initially, S2 is off and S1 is on. After  $M_3$  is fed into the circuit, S1 switches off, S2 turns on and an additional shift by the SR generates the parity check code. Then, S2 switches off and S1 turns on to repeat the process.




Figure A1.12

The decoder operates in the same manner as the encoder. However, an AND gate is inserted to check the parity received and the one generated by the SR. If they do not match, an error is detected.

### Erasure and B-adjacent decoding

After the CRCC decoder detects a code error in each data block, error correction is implemented in the parity decoder. First the **syndrome**  $S_{p0}$  (corrector) is calculated as follows:

$$S_{p0} = L_0 + R_0 + L_1 + L_2 + P_0$$

where

$$P_0 = L_0 + R_0 + L_1 + R_1 + L_2 + R_2$$

If there is no error,  $S_{p0} = 0$ , because in modulo-2 summation, adding any two identical quantities is **zero**.

On the other hand, suppose a single error  $R_1'$  (i.e., all 16 bits are incorrect) in a single message block is made. In this case,  $S_{p0} = 1$ .

If we add this to  $R_1'$ , correction can be made because:

If  $R_{1X} = 0, R_{1,X} = 1$  where  $R_{1X}$  is any bit in  $R_1$

$R_{1X} = 1, R_{1,X} = 0$  where  $R_{1,X}$  is any bit in  $R_1$ ,

and, in either case, we have  $R_1' + S_{p0} = R_1$ . However, if two errors occur, this method of correction – called the **erase method** – fails to recover the original information. Since interleaving is employed in the PCM-F1, original bits in a block are **shuffled** to the other blocks by a 16H delay. Effectively, this method is capable of correcting errors occurring successively in 2048 bits.

In B-ADJACENT decoding, the syndromes  $S_{p0}$  and  $S_{Q0}$  are calculated as follows:

$$S_{p0} = L_{0r} + R_{0r} + L_{1r} + L_{2r} + R_{2r} + P_{0r} \dots \quad (4)$$

$$S_{Q0} = T^6 L_{0r} + T^5 R_{0r} + T^4 L_{1r} + T^3 R_{1r} + T^2 L_{2r} + Q_{0r} \dots \quad (5)$$

where

$$P_0 = L_0 + R_0 + L_1 + R_1 + L_2 + R_2^*$$

$$Q_0 = T^6 L_0 + T^5 R_0 + T^4 L_1 + T^3 R_1 + T^2 L_2 + TR_{2r}^*$$

\* $L_{0r}, \dots, R_{2r}, P_{0r}, Q_{0r}$  are the info received.

## 228 Appendix 1

Suppose the received information  $R_{1r}$  and  $R_{2r}$  contain error, then:

$$R_1' = R_1 + E_{R1} \dots \dots \dots (6)$$

$$R_2' = R_2 + E_{R2} \dots \dots \dots (7)$$

where  $R_1$  and  $R_2$  are the original messages transmitted

$E_{R1}$  and  $E_{R2}$  are the errors added.

Substituting  $R_1'$  and  $R_2'$  in place of  $R_{1r}$  and  $R_{2r}$  in (4) and (5), we can easily get,

$$S_{p0} = E_{R1} + E_{R2} \dots \dots \dots (8)$$

$$S_{Q0} = T^3 E_{R1} + T E_{R2} \dots \dots \dots (9)$$

adding  $T^{-1}$  to both sides of (9), then

$$T^{-1} S_{Q0} = T^2 E_{R1} + E_{R2} \dots \dots \dots (10)$$

adding  $S_{p0}$  to both sides of (10),

$$\begin{aligned} S_{p0} + T^{-1} S_{Q0} &= (T^2 E_{R1} + E_{R2}) + S_{p0} \\ &= (T^2 E_{R1} + E_{R2}) + (E_{R1} + E_{R2}) \\ &= (T^2 + I) E_{R1} \dots \dots \dots \end{aligned} \quad (11)$$

rearrange 11:

$$E_{R1} = (T^2 + I)^{-1} (S_{p0} + T^{-1} S_{Q0}) \dots \dots \dots (12)$$

from 8:

$$E_{R2} = E_{R1} + S_{p0} \dots \dots \dots (13)$$

Before we go on, let us summarize the situation as follows: we first calculate the syndromes  $S_{p0}$  and  $S_{Q0}$  according to (4) and (5). After some algebraic manipulations (if only 2 or less errors are made during the transmission of data), the error pattern can be calculated by (12) and (13). Once these are known, we can correct the error by (6) and (7) where:

$$R_1 = R_1' + E_{R1}$$

$$R_2 = R_2' + E_{R2}$$

Note that in modulo-2 summation, since  $1 + 1 = 0$ ,  $1 = -1$ . By this method, 4096 successive bit errors can be corrected.

In what follows we shall demonstrate how the decoding is done by going through an example.

Unfortunately, the matrix  $T$  consists of  $14 \times 14$  elements. Even for a simple example such as shown below, a lot of algebraic manipulations are involved.

Therefore, in order to avoid the many steps of purely mechanical computation from clouding the main issue, we shall show only the important steps or results. Anyway, what is important here is to get a 'feel' of how decoding is carried out.

Example. We have the following data:

	LSB													MSB
$L_0$	0	0	0	0	0	0	0	0	0	0	0	0	0	0
$R_0$	1	0	0	0	0	0	0	0	0	0	0	0	0	0
$L_1$	0	1	0	0	0	0	0	0	0	0	0	0	0	0
$R_1$	0	0	1	0	0	0	0	0	0	0	0	0	0	0
$L_2$	0	0	0	1	0	0	0	0	0	0	0	0	0	0
$R_2$	0	0	0	0	1	0	0	0	0	0	0	0	0	0
$P_0$	1	1	1	1	1	0	0	0	0	0	0	0	0	0
$Q_0$	0	0	0	0	0	0	1	0	0	0	0	0	0	0

Suppose that, after the data is transmitted, the received data becomes:

$L_0$	0	0	0	0	0	0	0	0	0	0	0	0	0	0
$R_0$	1	0	0	0	0	0	0	0	0	0	0	0	0	0
$L_1$	0	1	0	0	0	0	0	0	0	0	0	0	0	0
$R_1'$	0	0	1	1	1	0	0	0	0	0	0	0	0	0
$L_2$	0	0	0	1	0	0	0	0	0	0	0	0	0	0
$R_2'$	0	0	0	0	0	0	0	0	1	1	1	0	0	0
$P_0$	1	1	1	1	1	0	0	0	0	0	0	0	0	0
$Q_0$	0	0	0	0	0	0	1	0	0	0	0	0	0	0

We can find  $E_{R1}$  and  $E_{R2}$  as follows:

First, we have to find  $S_{P0}$  and  $S_{Q0}$ .

Using (4) it is easy to see that

$$S_{p0} = \begin{bmatrix} 0 \\ 0 \\ 0 \\ 1 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 1 \\ 1 \\ 1 \\ 0 \\ 0 \end{bmatrix}$$

Similarly, from (5) and the column matrixes  $TR_2, T^2L_2, \dots, T^6L_0$  listed in the previous section, we find,

$$S_{00} = \begin{bmatrix} 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 1 \\ 1 \\ 1 \\ 0 \\ 0 \\ 1 \\ 1 \\ 1 \\ 0 \end{bmatrix}$$

After going through some algebraic manipulations, we find  $T - 1, (T^2 + 1)$  and finally  $(T^2 + 1)^{-1}$ . We have,



$$S_{P0} + T^{-1}S_{Q0} = \begin{bmatrix} 0 \\ 0 \\ 0 \\ 1 \\ 1 \\ 1 \\ 1 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \end{bmatrix}$$

Moreover, using (12), we obtain:

$$E_{R1} = \begin{bmatrix} 0 \\ 0 \\ 0 \\ 1 \\ 1 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \end{bmatrix}$$

## 232 Appendix 1

and finally from (13),

$$E_{R2} = \begin{bmatrix} 0 \\ 0 \\ 0 \\ 0 \\ 1 \\ 0 \\ 0 \\ 0 \\ 0 \\ 1 \\ 1 \\ 1 \\ 0 \\ 0 \end{bmatrix}$$

Now, you can verify that by taking the modulo-2 summation of  $R_1$  and  $E_{R1}$ ,  $R_2$ , and  $R_{R2}$ , the correct transmitted data are obtained.

Notes:

1  $(T^2 + 1)^{-1}$  can be constructed as follows:

We have,

$$(T^2 + I)L_0 = \begin{bmatrix} a_1 + a_{13} \\ a_2 + a_{14} \\ a_1 + a_3 \\ a_2 + a_4 \\ a_3 + a_5 \\ a_4 + a_6 \\ a_5 + a_7 \\ a_6 + a_8 \\ a_7 + a_9 + a_{13} \\ a_8 + a_{10} + a_{14} \\ a_9 + a_{11} \\ a_{10} + a_{12} \\ a_{11} + a_{13} \\ a_{12} + a_{14} \end{bmatrix} = M$$

Because  $(T^2 = 1)^1 M = L_0$ , then for the first row of  $(T^2 + 1)^{-1}$  we must have

$$\begin{bmatrix} 0 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 \end{bmatrix}$$

so that

[illegible]

- 2 We can find  $T^{-1}$  and  $(T^2 + 1)$  in a manner similar to the above.
- 3 It can be verified easily that  $(T^2 + 1)^{-1}(T^2 + 1) = 1$ .

When we multiply the first row and the first matrix by the first column of the second one, we have,

$$(0.1) + (0.0) + (1.1) + (0.0) + (1.0) + (0.0) + (1.0) + (0.0) + (1.0) + (0.0) + (1.0) + (0.0) + (1.0) + (0.0) = 1$$

Thus, the first element of the matrix is 1. Similarly, we can verify that all the other elements, except the ones at the diagonal, are zero.

$$\mathbf{Q}_0 = \mathbf{T}^6 \mathbf{L}_0 + \mathbf{T}^5 \mathbf{R}_0 + \mathbf{T}^4 \mathbf{L}_1 + \mathbf{T}^3 \mathbf{R}_1 + \mathbf{T}^2 \mathbf{L}_2 + \mathbf{T} \mathbf{R}_2$$

[illegible]

[illegible]

$$(T^2 + I)^{-1} = \begin{bmatrix} 0 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 \\ 0 & 0 & 0 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 \\ 0 & 0 & 0 & 0 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 \\ 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 & 1 & 0 & 1 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 & 1 & 0 & 1 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 & 1 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 & 1 \\ 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 0 & 0 & 0 \\ 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 0 & 0 \\ 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 0 \\ 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 \\ 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 \\ 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 0 & 1 & 1 \end{bmatrix}$$

# Appendix 2

## Anatomy of a PAL Composite Video Signal (Monochrome)


Within a period of  $64\ \mu\text{s}$ , the digital data processing circuit of the PCM-F1 outputs 168 bits of data. If these data are to be recorded on tape, the tape recorder has to handle about  $2.6 \times 10^6\ \text{bit s}^{-1}$ . Presently, only video tape recorders have the required bandwidth to perform this task, which means that digital data have to be turned into a video signal before it can be recorded.

This appendix looks at the components of a composite video signal. At the end, a list of video signal parameters and definitions of video terms are included as reference.

In a television set, two independent free-running oscillators are employed to generate sawtooth voltages that deflect an electron beam horizontally and vertically over the entire display screen. The sweep is from left to right, and top to bottom. The time required for an electron beam to make a horizontal 'round-trip', i.e., from the left edge to the right edge and then back is defined as H. Similarly, a vertical round-trip is termed V.


The frequency of H intervals per second, called the horizontal frequency, is set at 15,625 Hz. To minimize interference on the television screen caused by beating, the vertical frequency (i.e., intervals per second) is chosen to be the same as the frequency of mains power: 50 Hz. (Although modern TVs are immune to mains power beat interference, the 50 Hz standard remains.) These two frequencies determine the line and field rates of the display. From these two numbers, we get, in 1 field,  $15,625/50 = 312.5$  lines. Also, 1H occurs in a period of  $64\ \mu\text{s}$ .

For meaningful pictures to be displayed on the screen, the free-running oscillators must be triggered by some means so that they are synchronized to

**Figure A2.1**


both line and field rates. Hence, both horizontal and vertical sync pulses are inserted into the video signal. Refer to figure A2.2. However, the television receiver must have some way of detecting which sync pulse is being received at any one time. Figure A2.2a shows horizontal sync pulses at the end of one field and the beginning of the next. Between the times  $T_1$  and  $T_2$ , therefore, vertical sync pulses must be inserted, and must be sufficiently different from the horizontal sync pulses so that the receiver knows the difference. The technique is to use pulses of a different width, called field broad pulses, (Figure A2.2b). Thus a simple differentiator circuit will detect horizontal sync pulses, while a similarly simple integrator circuit will detect vertical sync pulses.

As we have mentioned before, in one field, 312.5 lines are scanned. However, the horizontal resolution of the raster can be increased,




**Figure A2.2** Sync signals in a PAL signal (a) horizontal sync signals at the end of one field and the beginning of the next (b) composite sync signal with field broad pulses (vertical sync pulses) added

theoretically, to 625 lines by dividing the total display into two interlaced fields, such that odd lines are scanned in one field and even lines in another. The two fields form what is called a frame. With this technique, although the frame rate is only half the field frequency i.e., 25Hz, which could give rise to annoying flicker of the picture, the raster refresh rate is a 'flicker free' 50Hz.




**Figure A2.3** Interlaced fields (a) interlaced display (b) using a  $\frac{1}{2}H$  shift in the vertical sync pulses



**Figure A2.4** Problems created in timing when a  $\frac{1}{2}H$  shift in vertical sync pulses is used to interlace fields

**Figure A2.6** *Vertical blanking intervals of odd and even fields*





**Figure A2.7** Horizontal line sync signals are combined with analog display data during the display time

All the pulses discussed are combined in Figure A2.6, where the vertical blanking intervals of odd and even fields of a composite video signal are shown. Figure A2.7 shows how horizontal live sync pulse and analog display data are combined for the rest of the signal, along with nomenclature. Finally, Table A2.1 lists main specifications of the PAL and NTSC composite video signal formats.

**Table A2.1** Main specification of PAL and NTSC composite video signals

	PAL	NTSC
Lines per frame	625	525
Field rate (Hz)	50	60
Line period ( $\mu$ s)	64	63.5
Field period (ms)	20	16.67
Horizontal sync pulse ( $\mu$ s)	5.8	5.1
Vertical sync pulse ( $\mu$ s)	160	158.75
Horizontal blanking ( $\mu$ s)	12.05	11.4
Vertical blanking (ms)	1.28	1.27

## **240 Appendix 2**

### **Definition of video terms**

#### **Blanking level**

The level which shuts off CRT current, resulting in the blackest possible picture.

#### **Composite sync signal**

The portion of the composite video signal which synchronizes the scanning process.

#### **Composite video signal**

The display signal plus the composite sync signal.

#### **Reference black level**

The maximum peak excursion of the display signal in the negative direction.

#### **Reference white level**

The maximum peak excursion of the display signal in the positive direction.

#### **Setup**

The difference between the reference black level and the blanking level.

#### **Sync level**

The peak level of the composite sync signal.

# Appendix 3

## Sampling theorem

Sampling picks out values  $f(nT)$  from a signal  $f(t)$ , at regular intervals. This is equivalent to the multiplication of  $f(t)$  with the signal  $s(t)$ , given by the expression:

$$f_s(t) = \sum_{n=-\infty}^{\infty} T f(nT) \delta(t - nT)$$

where  $\delta(t)$  is a delta function.

The Fourier transform  $F_s(\omega)$  of  $F_s(t)$ , is given by the expression:

$$F_s(\omega) = \int_{-\infty}^{\infty} \sum_{n=-\infty}^{\infty} T f(nT) \delta(t - nT) e^{-j\omega t} dt$$

where  $\omega_s = 2\pi/T$ . When two functions are multiplied in time their transforms in the frequency domain are convoluted. For this reason, the spectrum  $F(\omega)$  is repeated at multiples of the sampling frequency. Function  $f(t)$  may be recovered from  $F_s(\omega)$  by first multiplying by a gating function  $G(\omega)$ , illustrated in Figure A3.1. This results in the expression:


$$F(\omega) = F_s(\omega) G(\omega)$$

Now, the inverse transform of  $G(\omega)$  is given by the expression:

$$\frac{\sin \omega_0 t}{t}$$

and if:

$$F_s(\omega) \leftrightarrow f_s(t)$$



**Figure A3.1** Recovery of a sampled signal

then:

$$G(\omega) \leftrightarrow g(t)$$

so that:

$$F_s(\omega) G(\omega) \leftrightarrow f_s(t) * g(t)$$

where the symbol  $*$  denotes convolution. This gives:

$$\begin{aligned} f(t) &= \sum_{n=-\infty}^{\infty} T f(nT) \delta(t - nT) * \frac{\sin \omega_0 t}{T_0 \omega_0 t/2} \\ &= \sum_{n=-\infty}^{\infty} T f(nT) \frac{\sin \omega_0(t - nT)}{T_0 \omega_0(t - nT)/2} \end{aligned}$$

and, when:  $T_0 = 2T$ :

$$f(t) = \sum_{n=-\infty}^{\infty} f(nT) \frac{\sin \omega_0(t - nT)}{\omega_0(t - nT)}$$

This result, the **sampling theorem**, relates the samples  $f(nT)$  taken at regular intervals to the function  $f(t)$ .

The sampling theorem is important when considering the bandwidth of a sampled signal. For example, a function  $f(t)$  can only be properly reconstructed when samples have been taken at the **Nyquist rate**,  $1/T = 2/T_0$ . In practical terms, this means that the sampling frequency should be twice that of the highest signal component frequency, i.e.:

$$F_s = 2f_0$$

and so, to make sure that signal component frequencies greater than half the sampling frequency are not sampled, an anti-aliasing filter is used.

# Index

- A law, 53–4
- Absorption, optical, 130–31
- Acquisition time, 40–41
- Aliasing, 32–3
- Analog audio recording, 6–7
- Analog/digital (A/D) conversion, 27–8
  - EIAJ format, 173
  - see also* Converters, A/D
- Analog filter, 76–7
- Anti-imaging filter, *see* Low-pass filter
- Aperture control circuit (AC), 38–40, 182
- Aperture time/uncertainty/jitter, 41
- Audio Engineering Society (AES), 9
- Automatic track following (ATF), 195, 197, 201–2
  - area divided, 201
- B-adjacent coding, 94, 172
  - decoding, 227
- Bandwidth requirements, 9, 52
- Bar coding, 117
- BCD conversion code, 48
- BCH correction code, 95
- Beam splitter, 140
- Bi-phase code, 81
- Bipolar system, 43
  - conversion codes, 49
- Bit error rate (BER), 114
- Block codes, 90
- Block conversion, 57
- Broadcasting, FM, 16–19
- Bursts (errors), 83
- CDP-101:
  - amplifier circuits, 155
  - servo circuits, 148
- Channel coding, 80
- Code errors, 83–5
  - compensation, 85
  - concealment, 96
  - correction, 89–94
  - detection, 86–90
- Code rate, 89–90
- Code vector, 221
- Code word, 221
- Coding theorem, 89–90
- Collimator, 134–5
- Combinational parity checking, 91
- Compact disc (CD), 101–3
  - development, 12, 14–15
  - emphasis codes, 106–7
  - player servo circuit, 146–54
  - production, 109–112
  - readout, 104
  - recording, 104
  - sampling rate, 33
  - signal parameters, 107–10
- Composite video signal, PAL, 235–9
- Control word, information, 116–17, 178
- Conversion, 27–8, 48–51, 173, 186
- Converters, A/D, 27–8
  - D/A, 160–7
  - dual slope integrating, 60–63
  - dual slope single-integration, 72–4
  - flash, 67
  - parallel, 65
  - ramp, 65
  - successive approximation, 63
  - video, 8, 73, 186
  - voltage-to-frequency, 68–9
- Convolutional codes, 90
- Cross-interleave Reed-Solomon

- (CIRC) code, 95, 113–16
  - decoding, 157
- Crossword code, 91–4, 183–4
- CX7933 IC, 157
- CX7934 IC, 157
- CX20017 IC, 160
- CX23034 IC, 78
- CX23035 IC, 56
- Cyclic filter, *see* recursive filter
- Cyclic redundancy check code (CRCC), 87–90, 178, 215
  - theory, 221–7
- Decoding, 157–60, 227
- De-emphasis, use of, 16
- Deglitcher, *see* Sample-hold circuits
- Delay modulation code, 81
- Delta modulation, 58–9
  - adaptive, 58–9
- Delta-sigma modulator, 68–9
- Demultiplexer (DEMUX), 182
- Differential PCM, 57–9
  - adaptive, 59
- Diffraction gratings, 136
- Digital/analog (D/A) conversion, 73–9, 160–65
- Digital audio broadcasting, 17–19
  - equipment history, 20–23
- Digital audio disc (DAD), 14–15
- Digital audio peripheral equipment, 15, 17
- Digital audio processing, 27–8
- Digital audio production system, 17
- Digital audio stationary head (DASH), 12
- Digital audio tape (DAT) format, 192–214
- Digital editing console, 15, 17
- Digital filter, 77–8
- Digital magnetic recording, 139, 171
- Digital mixer, 15
- Digital multimeter (DMM), 63
- Digital panel meter (DPM), 63
- Digital reverberator, 17
- Digital-to-video converter (DVC), 181
- Digital transversal filter, 76
- Digital voltmeter (DVM), 63
- Disc motor servo circuit, 154
- Dither noise, 48
- Droop (voltage drop), 40
- Dropouts, 83
- Dynamic range, 56
- Editing errors 85
- Eight-to-fourteen modulation (EFM)
  - code, 82, 122–5
  - demodulation, 157
- Electronic Industry Association of Japan (EIAJ)
  - 14 bit standard, 10, 173, 177
  - recorder specification, 172–3
  - sampling frequency, 33
- Encoding, 58–9, 174–5
  - EFM modulation, 122–5
  - PCM-1600/1610, 183–4
- Erasur correction method, 227
- Error concealment, 96
- Error correction:
  - b-adjacent coding, 172
  - code forms, 90
  - DAT format, 202–3
  - theories, 215–34
- Exclusive-or-operation, 216
- Exponent output, 55
- Feedback control circuits, 146–54
- Field broad pulses, 236
- Filters, 76–9
- Final bit rate, 126
- Finite impulse response filter, *see* Digital transversal filter
- First-in-first-out buffer (FIFO), 181
- Floating point conversion, 55–6
  - block, 57
- FM broadcasting, 17–19
- Focus coil, 143
- Focus search circuit, 149
- Focus servo circuit, 148
- Frame, signal, 116, 126
- Generator polynomial, 222
- Glitches (transients), 38
- Granulation noise, 48
- Gray conversion code, 49
- Guard-bandless recorders, 193
- High-density modulation (HDM-1)
  - code, 81
- Hold time (sampling), 72
- Injection laser diode (ILD), 137–9
- Input stage, recording circuit, 180
- Inter-block gap (IBG), 197
- Interlacing, 237–8
- Interleaving, 97, 174–7
  - DAT format, 203–4
  - EIAJ system, 177
  - PCM-F1 system, 177
  - Video 8 format, 191

## 246 Index

- International Standard Recording Code (ISRC), 121
- Intersymbol interference, 84
- Jitter, 83
  - margin, 83
- Lasers, 139–40
- Least significant bit (LSB), 48
- Lens, optical, 132–3
- Low-pass filter (LPF), 180, 182
- $\mu$ -law, 53
- Main spot detector, 148
- Manchester code, *see* Bi-phase code
- 'Mantissa' output, 55
- Masers, 139–40
- Matrix operation circuit, 216
- Merging bits, 124
- Miller code, *see* Modified frequency modulation code
- Modified cross-interleaved code (MCIC), 189
  - improved, 189
- Modified frequency modulation (MFM) code, 81
  - modified ( $M^2FM$ ), 81
- Modulo-2 summation technique, 215
- Most significant bit (MSB), 43, 48
- Multiplexer (MUX), 180
- Music start flags, 108
- Natural binary code, 54
- Near-instantaneous companding, *see* Block conversion
- NHK (Japan Broadcasting Corporation), 7
- NICAM-3 system, 57
- Nippon Columbia, 9
- Noise effects, 85
- Noise-reduction (NR) system:
  - Video 8 format, 186
- Noise shaping 69–70
- Non-return to Zero (NRZ) code, 81, 124
- NTSC 525-line TV system:
  - parity blocks, 190
  - sampling frequency, 33, 35
  - signal specification, 178, 239
- Nyquist theorem, 29
  - rate, 243
- Offset binary conversion code, 55
- One's complement conversion code, 55
- Open reel recorders, 4–5
- Optical components, 131–7
  - pick-ups, 140–5
- Optical spectrum, 128–9
- Optical waves interaction, 129–31
- Output stage, playback circuit, 182
- Oversampling, 75–6
- Overwrite recording, 193
- P parity words, 94, 189
  - theory, 215
- P subcodes, 116–17
- Pack format, 208
- PAL625-line TV system:
  - parity blocks, 190
  - sampling frequency, 33, 35
  - signal specification, 178, 239
- Parity checking, 86
- PCM-1, 9, 10
- PCM-F1, 10
  - basic circuitry, 179
  - CRCC, 221
  - interleaving, 197
  - 16-bit format, 172
- PCM-1600/1610 format, 9, 11, 91, 183–5
- PCM-3324 recorder, 12
- Phase locked loop (PLL), 157
- Philips:
  - CIRC, 95, 113
  - DAD, 15
- Pick-ups, optical, 140–5
- Planck's Law, 139
- Playback circuit, 181–2
- Predictive encoding, 58
- Pre-emphasis, use of, 173
- Prism, optical, 133
- Pulse amplitude modulated (PAM)
  - signal, 38–40, 182
- Pulse code modulated (PCM) system:
  - basic circuitry, 179
  - commercial processors, 9–11
  - data interleave, 203–4
  - differential, 57–9
  - early development, 7–9
  - see also specific models eg. PCM-1*
- Q-parity sequence:
  - Video 8 format, 190–1
- Q parity words, 94
  - theory, 216–21
- Q subcodes, 117–25
- Quantization, 48–50
  - companding systems, 52–5
  - linear systems, 52



- non-linear systems, 52–5
- Quantization error, 44–5
  - masking, 47–8
- Quantization intervals, 43–4
- Quantization noise, *see* Quantization error
- Quantization processor, 17
- Quarter-wave plate (QWP), 137
- Radio frequency (RF) amplification, 155–6
- Raster, 236–7
- Recording circuit, 180–1
- Recursive filter, 77
- Redundancy:
  - data sequence, 90
  - Video 8 format, 191
- Reed-Solomon code, 95, 113
  - double-encoded, 203–5
- Reflection, optical, 129–30
- Refraction, optical, 131
- Regulators, feedback control, 146–7
- Rotary head digital audio tape
  - recorder (R-DAT), 20, 192, 213–4
  - sampling frequency, 36
  - tape duplication, 211
- Rotary head principles, 12–13
- Round-off error, *see* Quantization error
- Sample hold circuits, 36–8, 40–1
- Sample interpolation rate, 114
- Sampling frequency, 33–6
  - professional standards, 35–6
  - standard, 9
- Sampling frequency unit, 17
- Sampling principles, 29–33
- Sampling theorem, 241–3
- Sampling time, 72
- Scrambling (encoding), 115
- S-domain, 69–70
- Servo circuits, 147–54
- Settling time (sampling), 46–7
- Shannon theorem, *see* Nyquist theorem
- Side beams, 140
- Side spot detectors, 151
- Sign bit, 43
- Sign magnitude conversion code, 49
- Signal decoding, 157–60
- Signal processing stage:
  - playback, 181
  - recording, 181
- Signal-to-noise ratio, 45–7, 56
- Skew bits, 185
- Sled servo circuit, 151–3
  - motor, 151–3
- Sony:
  - A/D converter, 70–3
  - CDP-101 player, 148, 155, 160
  - CIRC code, 95, 113–16
  - crossword code, 91–94, 175, 183
  - DAD system, 15
  - digital audio developments, 20–3
  - PCM-1, 9
- Stationary head digital audio tape (S-DAT), 20
  - format, 192
  - sampling frequency, 36
- Stationary head system, 12–13
- Subcodes, 116–7
  - DAT format, 200, 205–8, 209
- Sync word, 126, 148, 152
- Syndrome words, 93
- Table of contents (TOC), 106, 211
- Tape duplication:
  - R-DAT tapes, 211, 214
- Tape recorders, early developments, 4–5
- 3-position modulation (3PM) code, 81
- Time base corrector (TBC), 181–2
- Time crosstalk, *see* Intersymbol interference
- Timing diagram, 156
- Tracking coil, 143
- Tracking servo circuit, 149–50
- Transmission, optical, 131
- Turntables, early developments, 3
- 2-axis device, 140, 143
- 2's complement code, 43, 49
- U-matic standard, 11
- Unipolar conversion codes, 48
- Vector space, 221
- Vertical blanking intervals, 239
- Video 8 PCM:
  - format, 186–91
  - sampling frequency, 33
- Video format, PCM, 178–9
- Video tape recorder (VTR), early
  - developments, 9–11
- Video-to-digital converter, 181
- Voltage-memory device, 37
- Wave shaper circuit, 155–6
- Word (series of bits), 44